


KV-27TS29 / 27TS32 / 27TS36

RM-Y116 RM-Y117 RM-Y118

KV-32TS36 / 32TS46

RM-Y118 RM-Y118
SA-W200

SERVICE MANUAL



US Model

KV-27TS29 Chassis No. SCC-F84C-A

KV-27TS32 Chassis No. SCC-F84E-A

KV-27TS36 Chassis No. SCC-F84D-A

KV-32TS36 Chassis No. SCC-F84A-A

KV-32TS46 Chassis No. SCC-F84B-A

Canadian Model

KV-27TS29 Chassis No. SCC-F85C-A

KV-27TS36 Chassis No. SCC-F85D-A

KV-32TS36 Chassis No. SCC-F85A-A

KV-32TS46 Chassis No. SCC-F85B-A

AA-1 CHASSIS

MODELS OF THE SAME SERIES

KV-27TS29/27TS32/27TS36

KV-32TS36/32TS46

KV-2970RS/2970M/2975M

SPECIFICATIONS

Television system American TV standards

Channel coverage VHF: 2-13
UHF: 14-69
Cable TV: 1-125

Picture tube Hi-Black™ Trinitron® tube
27-inch picture measured diagonally
29-inch picture tube measured
diagonally (KV-27TS29/27TS32/27TS36)

32-inch picture measured diagonally
34-inch picture tube measured
diagonally (KV-32TS36/32TS46)

Antenna 75-ohm external antenna terminal for
VHF/UHF

Input

VIDEO and S VIDEO

S VIDEO IN (S terminal)

Y: 1 Vp-p, 75-ohms unbalanced,
sync negative

C: 0.286 Vp-p (Burst signal),
75-ohms

Video (phono jacks): 1 Vp-p,
75-ohms unbalanced, sync
negative

Audio (phono jacks): 500 mVrms
(100% modulation)
Impedance: 47 kilohms

— Continued on next page —



TRINITRON® COLOR TV

SONY®

KV-27TS29/27TS32/27TS36
 RM-Y116 RM-Y117 RM-Y118
KV-32TS36/32TS46
 RM-Y118 RM-Y118
 SA-W200

Output AUDIO OUT (phono jacks)
 More than 408 mVrms at the
 maximum volume setting (variable)
 More than 408 mVrms (fix)
 Impedances: 5 kilohms

Speaker output 5 W x 2

Audio frequency response : FRONT 80Hz - 20kHz

Power requirements 120 V AC, 60 Hz

Power consumption

KV-27TS29	165 W
KV-27TS32	165 W
KV-27TS36	170 W
KV-32TS36	195 W
KV-32TS46	205 W

standby mode 5 W

Dimensions/Weight

	Dimensions (w/h/d)	Weight
KV-27TS29	661 x 603 x 522 mm (26 ¹ / ₈ x 23 ³ / ₄ x 20 ⁵ / ₈ in.)	45 kg (99 lbs 4 oz)
KV-27TS32	661 x 603 x 522 mm (26 ¹ / ₈ x 23 ³ / ₄ x 20 ⁵ / ₈ in.)	45 kg (99 lbs 4 oz)
KV-27TS36	661 x 603 x 522 mm (26 ¹ / ₈ x 23 ³ / ₄ x 20 ⁵ / ₈ in.)	45 kg (99 lbs 4 oz)
KV-32TS36	781 x 712 x 612 mm (30 ³ / ₄ x 28 ¹ / ₈ x 24 ¹ / ₈ in.)	71 kg (156 lbs 9 oz)
KV-32TS46	781 x 712 x 612 mm (30 ³ / ₄ x 28 ¹ / ₈ x 24 ¹ / ₈ in.)	71 kg (156 lbs 9 oz)

Supplied accessories

(KV-27TS29)
 Remote Commander RM-Y116(1) with 2
 size AA (R6) EVEREADY batteries
 (KV-27TS32)
 Remote Commander RM-Y117(1) with 1
 size AA (R6) EVEREADY battery
 (KV-27TS36/32TS36/32TS46)
 Remote Commander RM-Y118(1) with 1
 size AA (R6) EVEREADY battery
 (KV-32TS46)
 Active Super Woofer

Recommended accessories

U/V mixer EAC-66
 Connecting cable
 VMC-810S/820S, VMC-720M,
 YC-15V/30V, RK-74A

Design and specifications are subject to change without
 notice.

WARNING!!

AN ISOLATION TRANSFORMER SHOULD BE USED DURING ANY
 SERVICE TO AVOID POSSIBLE SHOCK HAZARD, BECAUSE OF
 LIVE CHASSIS.
 THE CHASSIS OF THIS RECEIVER IS DIRECTLY CONNECTED TO
 THE AC POWER LINE.

SAFETY-RELATED COMPONENT WARNING !!

COMPONENTS IDENTIFIED BY SHADING AND MARK Δ ON THE
 SCHEMATIC DIAGRAMS, EXPLODED VIEWS AND IN THE PARTS
 LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE
 COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS
 APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS
 PUBLISHED BY SONY. CIRCUIT ADJUSTMENTS THAT ARE
 CRITICAL TO SAFE OPERATION ARE IDENTIFIED IN THIS
 MANUAL. FOLLOW THESE PROCEDURES WHENEVER CRIT-
 ICAL COMPONENTS ARE REPLACED OR IMPROPER OPERA-
 TION IS SUSPECTED.

ATTENTION!!

AFIN D'EVITER TOUT RISQUE D'ELECTROCUTION PROVENANT
 D'UN CHÂSSIS SOUS TENSION, UN TRANSFORMATEUR
 D'ISOLEMENT DOIT ETRE UTILISÉ LORS DE TOUT DÉPANNAGE.
 LE CHÂSSIS DE CE RÉCEPTEUR EST DIRECTEMENT RACCORDÉ
 À L'ALIMENTATION SECTEUR.

**ATTENTION AUX COMPOSANTS RELATIFS À LA
 SÉCURITÉ!!**


LES COMPOSANTS IDENTIFIÉS PAR UNE TRAME ET PAR UNE
 MAPQUE Δ SUR LES SCHÉMAS DE PRINCIPE, LES VUES
 EXPLOSÉES ET LES LISTES DE PIÉCES CONT D'UNE
 IMPORTANCE CRITIQUE POUR LA SÉCURITÉ DU
 FONCTIONNEMENT. NE LES REMPLACER QUE PAR DES
 COMPOSANTS SONY DONT LE NUMÉRO DE PIÉCE EST INDIQUÉ
 DANS LE PRÉSENT MANUEL OU DANS DES SUPPLÉMENTS
 PUBLIÉS PAR SONY. LES RÉGLAGES DE CIRCUIT DONT
 L'IMPORTANCE EST CRITIQUE POUR LA SÉCURITÉ DU
 FONCTIONNEMENT SONT IDENTIFIÉS DANS LE PRÉSENT
 MANUEL. SUIVRE CES PROCÉDURES LORS DE CHAQUE
 REMPLACEMENT DE COMPOSANTS CRITIQUES, OU
 LORSQU'UN MAUVAIS FONCTIONNEMENT EST SUSPECTÉ.

SAFETY CHECK-OUT

(US Model only)

After correcting the original service problem, perform the following safety checks before releasing the set to the customer:

1. Check the area of your repair for unsoldered or poorly-soldered connections. Check the entire board surface for solder splashes and bridges.
2. Check the interboard wiring to ensure that no wires are "pinched" or contact high-wattage resistors.
3. Check that all control knobs, shields, covers, ground straps, and mounting hardware have been replaced. Be absolutely certain that you have replaced all the insulators.
4. Look for unauthorized replacement parts, particularly transistors, that were installed during a previous repair. Point them out to the customer and recommend their replacement.
5. Look for parts which, though functioning, show obvious signs of deterioration. Point them out to the customer and recommend their replacement.
6. Check the line cord for cracks and abrasion. Recommend the replacement of any such line cord to the customer.
7. Check the condition of the monopole antenna (if any).
Make sure the end is not broken off, and has the plastic cap on it. Point out the danger of impalement on a broken antenna to the customer, and recommend the antenna's replacement.
8. Check the B+ and HV to see they are at the values specified. Make sure your instruments are accurate; be suspicious of your HV meter if sets always have low HV.
9. Check the antenna terminals, metal trim, "metallized" knobs, screws, and all other exposed metal parts for AC leakage. Check leakage as described below.


**LEAKAGE TEST**

The AC leakage from any exposed metal part to earth ground and from all exposed metal parts to any exposed metal part having a return to chassis, must not exceed 0.5 mA (500 microamperes). Leakage current can be measured by any one of three methods.

1. A commercial leakage tester, such as the Simpson 229 or RCA WT-540A. Follow the manufacturers' instructions to use these instruments.
2. A battery-operated AC milliammeter. The Data Precision 245 digital multimeter is suitable for this job.
3. Measuring the voltage drop across a resistor by means of a VOM or battery-operated AC voltmeter. The "limit" indication is 0.75 V, so analog meters must have an accurate low-voltage scale. The Simpson 250 and Sanwa SH-63Trd are examples of a passive VOM that is suitable. Nearly all battery operated digital multimeters that have a 2 V AC range are suitable. (See Fig. A)

HOW TO FIND A GOOD EARTH GROUND

A cold-water pipe is guaranteed earth ground; the cover-plate retaining screw on most AC outlet boxes is also at earth ground. If the retaining screw is to be used as your earth-ground, verify that it is at ground by measuring the resistance between it and a cold-water pipe with an ohmmeter. The reading should be zero ohms. If a cold-water pipe is not accessible, connect a 60-100 watts trouble light (not a neon lamp) between the hot side of the receptacle and the retaining screw. Try both slots, if necessary, to locate the hot side of the line, the lamp should light at normal brilliance if the screw is at ground potential. (See Fig. B)



V-27TS29/27TS32/27TS36

RM-Y116 RM-Y117 RM-Y118


V-32TS36/32TS46RM-Y118 RM-Y118
SA-W200**TABLE OF CONTENTS**

<u>Section</u>	<u>Title</u>	<u>Page</u>	<u>Section</u>	<u>Title</u>	<u>Page</u>
1.	GENERAL		4.	SAFETY RELATED ADJUSTMENTS	41
1-1.	Introducing the Sony TRINITRON® Color TV	5	5.	CIRCUIT ADJUSTMENTS	
1-2.	Locating the Controls	5	5-1.	Electrical Adjustment by Remote Commander	43
1-3.	Using the ON-SCREEN Menus	8	5-2.	M Board Adjustments	45
1-4.	Turning the Cable Mode ON or OFF	9	5-3.	P Board Adjustments	48
1-5.	Presetting TV Channels	10	6.	DIAGRAMS	
1-6.	Connecting Other Equipment	12	6-1.	Block Diagrams (1)	49
1-7.	Watching TV Programs	14		Block Diagrams (2)	51
1-8.	Using Convenient Features	15	6-2.	Frame Schematic Diagram	57
1-9.	Using Closed Caption (U.S.A. models only)	15	6-3.	Circuit Boards Location	61
1-10.	Watching two Pictures at Once (Picture-in-Picture)	16	6-4.	Printed Wiring Boards and Schematic Diagrams	61
1-11.	Using the Timer-Activated Functions	19		• A, C Boards	62
1-12.	Customizing the Screen Display	22		• UA Board	67
1-13.	Using the Pre-Programmed Remote Commander	24		• P Board	73
2.	DISASSEMBLY			• E Board	77
2-1.	Rear Cover Removal	26		• H Board	80
2-2.	Chassis Assy Removal	26		• M Board	81
2-3.	Service Position	26		• D Board	87
2-4.	P Board and P Bracket Removal	26		• Super woofer Board	94
2-5.	UA Board Removal	27	6-4.	Semiconductors	99
2-6.	Extension Cable	27	7.	EXPLODED VIEW	
2-7.	Picture Tube Removal (1)		7-1.	Chassis	101
	(KV-27TS36/27TS32/27TS29)	28	7-2.	Picture Tube	102
2-7.	Picture Tube Removal (2)		7-3.	Speaker (KV-32TS46 only)	103
	(KV-32TS46/32TS36)	28	8.	ELECTRICAL PARTS LIST	104
2-8.	Repair of Chip Component Circuit Board	30			
3.	SET-UP ADJUSTMENTS				
3-1.	Beam Landing	35			
3-2.	Convergence	36			
3-3.	Focus Adjustment	39			
3-4.	G2 (Screen) and White Balance Adjustment	40			

SECTION 1 GENERAL

This section is extracted from
instruction manual.


1-1. INTRODUCING THE SONY TRINITRON® COLOR TV



1-2. LOCATING THE CONTROLS

Screen Displays

For details, see the pages indicated by the numbered black circles ●.




KV-32TS36
(The screen displays, except for certain features
as noted above, are the same for all models.)


Front Panel

KV-27TS29

KV-27TS32 KV-27TS36
KV-32TS36 KV-32TS46



DEMO button**
TV/VIDEO button*
VOLUME +/- buttons*
CHANNEL +/- buttons*
POWER button*
TIMER/STAND BY indicator
STEREO indicator
Remote control detector




DEMO button**
TV/VIDEO button*
VOLUME +/- buttons*
CHANNEL +/- buttons*
POWER button*
TIMER/STAND BY indicator
STEREO indicator
VIDEO 2/INPUT jacks
Remote control detector


- * Buttons with the same function are also located on the Remote Commander (pp. 10 - 11).
- ** If you press this button, functions and menus are displayed one by one. Press any button to stop DEMO.

Rear Panel


KV-27TS29




KV-27TS36 KV-32TS36



KV-27TS32




KV-32TS46



Remote Commander

For details, see the pages indicated by the numbered black circles ●.




RM-Y118: KV-27TS36 KV-32TS46
(RM-Y117: KV-27TS32)

- * Buttons with the same function are also located on the TV (p. 7).
- ** Buttons not included on RM-Y117

Note

If the TV/CABLE selector is set to CABLE, the Remote Commander is able to control a connected cable box, not the TV. Set the selector to TV to control the TV set with the Remote Commander (You can use POWER button at any case).




RM-Y116: KV-27TS29

WARNING
Batteries may explode if mistreated. Do not recharge, disassemble, or dispose of in fire.

Installing Batteries


(RM-Y116)



Battery life
With normal operation, batteries will last up to half a year. If the Remote Commander does not operate properly, the batteries might be exhausted. Replace both of them with new ones.

To avoid damage from possible battery leakage
Remove the batteries if you do not plan to use the Remote Commander for a fairly long time.


(RM-Y117, RM-Y118)




1-3. USING THE ON-SCREEN MENUS

The following flow chart shows the different levels of on-screen menus that you can use to make various adjustments and settings. See the indicated pages for instructions on using each feature.


For picture quality adjustment




For sound quality adjustment



For time-related settings



For language setting (p.16) (KV-27TS32 only)




ON/OFF TIMER screen (pp. 46-47)




CHANNEL BLOCK screen (pp. 48-49)



For presetting and other functions




For closed caption setting



Navigating through the Menus

Remote Commander



To display the main menu
Press MENU.

To return to the previous menu
Press Δ+ or ∇- to select "MENU."
Then press RETURN.


To return to the main menu
Repeat the above, until you reach the main menu.

To return to the normal screen
Press MENU on the Remote Commander.

Note

The menus disappear automatically if you do not press a button within 90 seconds.
The menu you cannot select appears in black.


CABLE ON/OFF screen (p. 17)




AUTO PROGRAM screen (p. 18)



CHANNEL ERASE/ADD screen (pp. 19-21)



CHANNEL CAPTION/GUIDE screen (pp. 50-51)





S VIDEO ON/OFF screen (p. 28)



VIDEO LABEL screen (pp. 53-54)





RM-Y118

To return to the normal screen
Press MENU.

Changing the Menu Language (KV-27TS32:2970RS only)

The menu language is factory-set to ENGLISH. Follow these instructions to change the menu language to Spanish or back to English.

- 1 Press POWER on the TV or the Remote Commander to turn the TV on.

POWER
- 2 Press MENU. The main menu appears.

MENU

VIDEO
AUDIO
TIME
SET UP
CLOSED CAPTION
ENGLISH
Use Δ ∇ Exit
- 3 Press Δ or ∇ to select ENGLISH. Then press RETURN.

RETURN

VIDEO
AUDIO
TIME
SET UP
CLOSED CAPTION
ENGLISH
Use Δ ∇ Exit
- 4 Press Δ or ∇ to select language. Each time you press Δ or ∇ , ESPAÑOL and ENGLISH menus appear.

RETURN

VIDEO
AUDIO
TIME
SET UP
CLOSED CAPTION
ESPAÑOL
Use Δ ∇ Salir

VIDEO
AUDIO
TIME
SET UP
CLOSED CAPTION
ENGLISH
Use Δ ∇ Exit

Note
Certain parts of the ESPAÑOL menus remain in English.
- 5 Press RETURN. The language is selected.


RETURN

VIDEO
AUDIO
HORA
AJUSTES
CLOSED CAPTION
ESPAÑOL
Use Δ ∇ Salir

Spanish menu

1-4. TURNING THE CABLE MODE ON OR OFF

All of the controls are on the Remote Commander.



RM-Y118

To return to the normal screen
Press MENU.

If you have cable connected to your TV (pp.12-13), follow the steps below to turn the cable connection on or off. CABLE is preset to ON when you use your TV for the first time. Then turn CABLE to OFF to preset or watch VHF or UHF channels (pp.18-21 and 29).

- 1 Press MENU. The main menu appears.

MENU

VIDEO
AUDIO
TIME
SET UP
CLOSED CAPTION
Use Δ ∇ Exit
- 2 Press Δ or ∇ to select SET UP.

RETURN

VIDEO
AUDIO
TIME
SET UP
CLOSED CAPTION
Use Δ ∇ Exit

Note
If the CABLE display appears in black, the TV is in VIDEO mode and you cannot select CABLE. Press TV/VIDEO to change to TV mode.
- 3 Press RETURN again.

RETURN

SET UP
CABLE: ON
AUTO PROGRAM
CH ERASE/ADD
CH CAPTION/GUIDE
S VIDEO
VIDEO LABEL
>MENU



Press Δ or ∇ to select ON or OFF alternately.

SET UP
CABLE: ON
AUTO PROGRAM
CH ERASE/ADD
CH CAPTION/GUIDE
S VIDEO
VIDEO LABEL
>MENU

SET UP
CABLE: OFF
AUTO PROGRAM
CH ERASE/ADD
CH CAPTION/GUIDE
S VIDEO
VIDEO LABEL
>MENU

Press RETURN. The setting is completed.

1-5. PRESETTING TV CHANNELS




RM-Y118

Channels that can be received on this TV:

VHF	UHF	Cable
2-13	14-69	1-125

Presetting TV Channels Automatically

1 Press POWER on the TV or the Remote Commander to turn the TV on.



2 Set the cable connection on or off, depending on if you want to preset cable or VHF/UHF channels.
(Follow the steps in "Turning the Cable Mode On or Off", p.17)

If "VIDEO" is displayed on the screen, press the TV/VIDEO button on the TV or the Remote Commander so that a channel number appears.

3 Press MENU.



VIDEO
AUDIO
TIME
SET UP
CLOSED CAPTION
Use Δ RETURN Exit

4 Press Δ or ∇ to select SET UP.
Then press RETURN.



SET UP
CABLE: ON
AUTO PROGRAM
CH ERASE/ADD
CH CAPTION/GUIDE
S VIDEO
VIDEO LABEL
>MENU


5 Press Δ or ∇ to select AUTO PROGRAM.
Then press RETURN.



SET UP
CABLE: ON
AUTO PROGRAM
CH ERASE/ADD
CH CAPTION/GUIDE
S VIDEO
VIDEO LABEL
>MENU

"AUTO PROGRAM" appears on the screen and receivable channels (other than the channels already preset) are preset in numerical sequence. The channels previously preset will not remain in the TV's memory.
When no more channels can be found, the programming stops and the lowest numbered channel is displayed.

To erase unnecessary channels, or to add channels that could not be preset automatically because their signal was too weak, follow the steps in "Erasing Unnecessary Channels — CHANNEL ERASE" (pp.19-20) and "Presetting Only Desired Channels — CHANNEL ADD" (p. 21).



RM-Y118

Erasing Unnecessary Channels—CHANNEL ERASE

Use this feature to erase unnecessary TV channels, so that when you press CH Δ or ∇ , the channel(s) are skipped.

1 Press MENU.
The main menu appears.



VIDEO
AUDIO
TIME
SET UP
CLOSED CAPTION
Use Δ RETURN Exit

2 Press Δ or ∇ to select SET UP.



VIDEO
AUDIO
TIME
SET UP
CLOSED CAPTION
Use Δ RETURN Exit

Press RETURN.
The SET UP menu appears.



SET UP
CABLE: ON
AUTO PROGRAM
CH ERASE/ADD
CH CAPTION/GUIDE
S VIDEO
VIDEO LABEL
>MENU

3 Press Δ or ∇ to select CH ERASE/ADD.



SET UP
CABLE: ON
AUTO PROGRAM
CH ERASE/ADD
CH CAPTION/GUIDE
S VIDEO
VIDEO LABEL
>MENU


Press RETURN.
The CH ERASE/ADD screen appears, and the cursor points to "ERASE".



CH ERASE/ADD
ERASE
ADD
>MENU
Select the channel
Use Δ RETURN Exit

Note

If CH ERASE/ADD display appears in black, the TV is in video mode and you cannot select CH ERASE/ADD.
Press TV/VIDEO to change to TV mode.




RM-Y118

To return to the normal screen
Press MENU.

Note

When you erase a VHF or UHF channel, the cable TV channel with the same number is also erased, and vice versa.

- 4** Press the CH +/- button to select the channel you want to erase.
For example, to erase channel 8, press CH +/- until 8 appears.



CH ERASE/ADD 8
▶ERASE
ADD
▶MENU
Select the channel
Use ◀ F10 ▶ Exit F12

Press RETURN.

A "-" sign appears in front of the channel number display, indicating that the channel is erased from the channel scan memory.



CH ERASE/ADD - 8
▶ERASE
ADD
▶MENU
Use ◀ F10 ▶ Exit F12

The next time you press the CH +/- buttons, channel 8 will be skipped.


To erase other channels
Repeat step 4.

Cable TV channel chart*

Cable TV systems use letters or numbers to designate channels. To tune in a channel, refer to the chart below.

Number on the TV	Corresponding cable TV channel	Number on the TV	Corresponding cable TV channel
1	A-8	33	T
5	A-7	34	U
6	A-6	35	V
14	A	36	W
15	B	37	W+1
16	C	38	W+2
17	D	39	W+3
18	E	40	X
19	F	93	W+57
20	G	94	W+58
21	H	95	A-5
22	I	96	A-4
23	J	97	A-3
24	K	98	A-2
25	L	99	A-1
26	M	100	W+59
27	N	101	W+60
28	O	102	W+61
29	P	103	W+62
30	Q	123	W+82
31	R	124	W+83
32	S	125	W+84

* This designation of cable TV channels conforms to the EIA/NCTA recommendation. Check with your local cable TV company for more complete information on the available channels.



RM-Y118

To return to the normal screen
Press MENU.

Note

If you add a VHF or UHF channel, the cable TV channel with the same number is also added, and vice versa.

Presetting Only Desired Channels—CHANNEL ADD

Use this feature to add channels one by one to the channel scan memory.

1-3 (Follow steps 1-3 in "Erasing Unnecessary Channels—CHANNEL ERASE," p.19.)

Note

If the CH ERASE/ADD display appears in black, the TV is in video mode and you cannot select CHANNEL ERASE/ADD. Press TV/VIDEO to change to TV mode.

- 4** Press Δ or ▽ to select ADD.



CH ERASE/ADD 10
ERASE
▶ADD
▶MENU
Select the channel
Use ◀ F10 ▶ Exit F12

- 5** Press 0-9 and ENTER to select the channel you want to add.
For example, to add channel 25, press 2, 5 and ENTER.



CH ERASE/ADD 25
ERASE
▶ADD
▶MENU
Select the channel
Use ◀ F10 ▶ Exit F12

Press RETURN.

A "+" sign appears in front of the channel number display, indicating that the channel is added to the channel scan memory.




CH ERASE/ADD +25
ERASE
▶ADD
▶MENU
Use ◀ F10 ▶ Exit F12

To add other channels
Repeat step 5.

1-6. CONNECTING OTHER EQUIPMENT

Connecting two VCRs for tape editing (KV-27TS32 only)



Watching a different image while duplicating


You can duplicate your recorded tapes by connecting two VCRs.

The VIDEO 3 OUT jacks only output the signal from the VIDEO 3 IN jacks. Connect a VCR for playback to VIDEO 3 IN jacks, and a VCR for recording to the VIDEO 3 OUT jacks. You can watch a TV program or images from VIDEO 1 IN or VIDEO 2 IN during duplicating.

To watch a different input image

Press TV/VIDEO on the TV or on the Remote Commander to select the input image you want to watch.

Connecting camcorders (except for KV-27TS29)




Preparing for use

Same as p. 23.

Audio System

Listening to TV or connected VCR sound through an audio system



Preparing for use

Display the mode set menu and set **SPEAKER** to **OFF** to cut off the TV speaker sound (p. 37), and listen to the TV's sound solely through the audio system speakers.

Note

By setting **AUDIO OUT** variable, you can adjust the bass, treble and balance, or select surround or an **MTS** (Multichannel TV Sound) mode, using the on-screen menus (pp. 34-36).

Connecting active super woofer (supplied with KV-32TS46 only)


Preparing for use

To enjoy the active super woofer sound, make sure the connections are made as illustrated on the next page.

The woofer volume varies according to the TV volume. Adjust the woofer level control properly.

The active super woofer outputs the signal input to its **AUDIO IN** jacks. If you connect an audio system to the active super woofer's **AUDIO OUT** jacks, you can enjoy the sound from the audio system and the active super woofer simultaneously.

To make the active super woofer stable, attach the felt feet (supplied) to the bottom.




Notes

- Do not place the woofer on the TV set. To enjoy good sound, place the woofer on a hard object near the TV avoiding soft objects like carpets, sofas, etc.
- If you do not use the TV for more than 20 seconds, the active super woofer is turned off automatically to save on power consumption.
- When you release **MUTING**, the sound of the woofer is heard before that of the TV. This is normal.
- If you set **SPEAKER** to **OFF** in the **AUDIO** menu and select **FIX** in the **AUDIO OUT** menu (p. 37), the volume of the woofer may be excessive. We recommend that you set **SPEAKER** to **ON** when you use the active super woofer.
- You should only connect the KV-32TS46 to the AC outlet on the active super woofer.

Active Super Woofer Specification


Input: 500 mVrms (100% modulation)
Output: 500 mVrms (100% modulation)
Impedance: 20 kilohms
Speaker output: 9 W (100 Hz)
Dimensions: 435 x 165 x 164 mm (W x H x D)
(17 1/4 x 6 1/2 x 6 1/2 in.)
Mass: 3.9 kg
(8 lbs 10 oz)



Using TV stand

When you place the active super woofer on a TV stand (not supplied), remove the rear panel of the stand.


Sony or other manufacture's stand



Note

For good sound quality, avoid placing the stand in front of a curtain or close to a wall.

1-7. WATCHING TV PROGRAMS



RM-Y118

To return to the normal screen
Press MENU.

Note

If you set S VIDEO to ON, the TV automatically receives S video signals whenever a VCR with S video is connected.

Watching a Video with Your S Video-Equipped VCR (except for KV-27TS29/2970RS)

Use this feature to set S VIDEO to ON or OFF depending on the kind of video equipment you have connected to the TV. For instructions on connecting video equipment, see pp.22-25.

Note

If the TV is in TV, VIDEO 2 or VIDEO 3 mode, the S VIDEO display appears in black and cannot be selected.

Press TV/VIDEO to change to VIDEO 1 mode.

- 1 Press MENU.
The main menu appears.



VIDEO
AUDIO
TIME
SET UP
CLOSED CAPTION
Use Δ ∇ Exit

- 2 Press Δ or ∇ to select SET UP.



VIDEO
AUDIO
TIME
SET UP
CLOSED CAPTION
Use Δ ∇ Exit

Press RETURN.
The SET UP menu appears.



SET UP
CABLE: ON
AUTO PROGRAM
CH ERASE/ADD
CH CAPTION/GUIDE
S VIDEO: ON
VIDEO LABEL
>MENU

- 3 Press Δ or ∇ to select S VIDEO.
Then press RETURN.



SET UP
CABLE: ON
AUTO PROGRAM
CH ERASE/ADD
CH CAPTION/GUIDE
S VIDEO: ON
VIDEO LABEL
>MENU


Press Δ or ∇ to select ON or OFF alternately.

SET UP
CABLE: ON
AUTO PROGRAM
CH ERASE/ADD
CH CAPTION/GUIDE
S VIDEO: ON
VIDEO LABEL
>MENU




SET UP
CABLE: ON
AUTO PROGRAM
CH ERASE/ADD
CH CAPTION/GUIDE
S VIDEO: OFF
VIDEO LABEL
>MENU

Press RETURN.
The setting is completed.



- 1 Press POWER on the TV or the Remote Commander to turn the TV on.
The TIMER/STAND BY indicator blinks until the picture appears.




- 2 Turn the cable mode on or off to select the type of channel you want to watch, VHF/UHF or cable TV.
(Follow the steps in "Turning the Cable Mode On or Off," p. 17.)

If "VIDEO" or "S VIDEO" is displayed on the screen, press the TV/VIDEO button on the TV or on the Remote Commander so that the channel number appears.

- 3 Select a channel in one of the following two ways:

To scan the preset channels* in numerical sequence
Press CH +/-.




* For more information on presetting channels, see pp. 18 - 21.


To select a channel directly

Press 0 - 9 and ENTER.


For example, to select channel 14, press 1, 4 and ENTER.



- 4 Press VOL +/- to adjust the volume.




The display will disappear automatically after 3 seconds.



Press + to increase the volume.
Press - to decrease the volume.

To turn off the TV
Press POWER on the TV or the Remote Commander again.

1-8. USING CONVENIENT FEATURES



RM-Y118

Muting the Sound — MUTING

Press **MUTING**.
The display "MUTING" will appear on the screen.

To restore the sound
Press **MUTING** again, or press **VOL +**.



Keeping the Displays On-Screen — DISPLAY

To display the channel
Press **DISPLAY**.
All the existing displays appear: channel number, channel caption (if set), MTS mode ("SAP" only), window picture input mode and the current time ("AM" or "PM" disappears after about three seconds).



To cancel the display
Press **DISPLAY** again.
The channel display will disappear.

Using the Sleep Timer — SLEEP

The sleep timer turns off the TV automatically after the amount of time you select.

Press **SLEEP**.
Each time you press **SLEEP**, the time increments "30", "60", "90" and "OFF" mode appear in sequence.



SLEEP 30
SLEEP 60
SLEEP 90
SLEEP OFF

The **SLEEP** display appears about one minute before the TV turns off.


To cancel the setting
Press **SLEEP** until "OFF" mode appears.
The "SLEEP OFF" display appears for about three seconds.
OR
Turn the TV off.
The sleep timer setting is cancelled.

Switching Quickly Between Two Channels—JUMP

Press **JUMP** once to recall the channel you were watching previously. Press **JUMP** again to switch back. Use this feature to keep track of two programs alternately.



1-9. USING CLOSED CAPTION (U.S.A. models only)




RM-Y118

1 Press **MENU**.
The main menu appears.




VIDEO
AUDIO
TIME
SET UP
CLOSED CAPTION
Use Δ ∇ Exit

2 Press Δ or ∇ to select **CLOSED CAPTION**.
Then press **RETURN**.
The **CLOSED CAPTION** screen appears.



CLOSED CAPTION
CC/TEXT OFF
CC1
CC2
TEXT1
TEXT2
MENU
Use Δ ∇ Exit

3 Press Δ or ∇ to select closed caption mode.



Select **CC1** or **CC2** to view Captions.
A Caption is a printed version of the dialogue or sound effects of a program. (The mode should be set to **CC1** for most programs.)

CLOSED CAPTION
CC/TEXT OFF
CC1
CC2
TEXT1
TEXT2
MENU
Use Δ ∇ Exit

Select **TEXT1** or **TEXT2** to view Text.
Text is information that is presented using the half to full television screen. It is usually not related to the program.

CLOSED CAPTION
CC/TEXT OFF
CC1
CC2
TEXT1
TEXT2
MENU
Use Δ ∇ Exit


Select **CC/TEXT OFF** if you do not want to use the **CLOSED CAPTION** mode.

Press **RETURN**.
The setting is completed.



CLOSED CAPTION
CC/TEXT OFF
CC1
CC2
TEXT1
TEXT2
MENU
Use Δ ∇ Exit

1-10. WATCHING TWO PICTURES AT ONCE (Picture-in-Picture)




RM-Y118

Note

To operate your VCR with the supplied Remote Commander, See "Using the Pre-Programmed Remote Commander", pp. 55-57.

You can watch both the main picture and a window picture simultaneously by using the Picture-in-Picture (PIP) function. Model KV-32TS46 is equipped with two-tuner PIP, allowing you to watch two TV channels at once. Other models are equipped with one-tuner PIP. To watch two different TV channels, you must first connect a VCR to the TV, to watch a second TV channel through the VCR tuner. (See "Connecting Other Equipment", pp. 22-27.)




Picture-in-Picture special features

When watching the main picture and a window picture, you can:


- Swap the main and window pictures (SWAP).
- Change the position of the window picture (POSITION).
- Display a still picture as a window (FREEZE).
- Choose the sound from the main or window picture (AUDIO).

Displaying a window picture—PIP

Press PIP to display a window picture



Press PIP again to display a smaller window picture



To disappear the window picture
Press PIP once more.

Changing the window picture input mode

1 Press PIP to display a window picture.




2 Press TV/VIDEO in the Picture-in-Picture control area to select the input mode. Each time you press TV/VIDEO, "TV", "VIDEO 1", "VIDEO 2" and "VIDEO 3" appear in sequence.



A window picture will appear in the same input mode as the last time you used PIP.

To receive the window picture sound

Press AUDIO.


The  display appears for a few seconds, indicating that the window picture sound is being received.



To restore the main picture sound
Press AUDIO again.

Notes


- If the main picture is not receiving an image, the window picture may be in black and white.
- When you turn PIP on or when you turn the TV on with PIP mode on the window picture will appear at the bottom right of the screen.
- The window picture may be affected by the condition of the main picture.
- The window picture sound is also output from the VARIABLE/FIX AUDIO OUT jacks.




RM-Y110

Changing TV channels in the window picture

- 1 Press PIP to display a window picture.




- 2 Press CH +/- in the PIP control area.




Changing the position of the window picture—POSITION

- 1 Press PIP to display a window picture.




- 2 Press POSITION.
Each time you press POSITION, the window picture will move counterclockwise on the screen, as illustrated below.




Displaying a still picture — FREEZE

Use the FREEZE function to display a still picture as a window. This function is useful when you want to write down a recipe from a cooking program, a displayed address or a phone number and so on.

- 1 Press PIP to display a window picture.



- 2 Press FREEZE.
The window picture image remains still on the screen.



To restore the normal picture
Press FREEZE again.


Swapping the main and window pictures — SWAP

- 1 Press PIP to display a window picture.



- 2 Press SWAP.
Each time you press SWAP, the images from the main and window pictures switch places.






RM-Y118

Displaying a pay cable TV channel as a window picture

To display a pay cable TV channel as a window picture, connect your decoder box as illustrated below.



Note

The channels being received through the AUX terminal cannot be displayed as a window picture. (KV-32TS46 only)

After making the connections, turn the cable mode on by following the steps "Turning the Cable Mode On or Off", p. 17. Then continue with steps below.

- 1 Press PIP to display a window picture.




- 2 Press TV/VIDEO in the Picture-in-Picture control area to select the input mode. Each time you press TV/VIDEO, "TV", "VIDEO 1", "VIDEO 2" and "VIDEO 3" appear in sequence.



- 3 Put your VCR on an inactive channel (CH 3 or 4).

- 4 Change pay cable TV channels with the decoder box.

1-11. USING THE TIMER-ACTIVATED FUNCTIONS



RM-Y118

Setting the Clock—CURRENT TIME SET

Follow these instructions to set the current time. The correct time must be set in order to use the timer-activated functions (ON/OFF TIMER, CHANNEL BLOCK).

EXAMPLE: Set the time to 3:15 PM, Monday.

- 1** Press MENU.
The main menu appears.



VIDEO
AUDIO
TIME
SET UP
CLOSED CAPTION
Use Δ ∇ Exit

- 2** Press Δ or ∇ to select TIME.



VIDEO
AUDIO
TIME
SET UP
CLOSED CAPTION
Use Δ ∇ Exit

Press RETURN.
The TIME menu appears, and the cursor points to "CURRENT TIME SET".



TIME
CURRENT TIME SET
ON/OFF TIMER
CHANNEL BLOCK
MENU
Use Δ ∇ Exit

- 3** Press RETURN.
The CURRENT TIME SET screen appears.



CURRENT TIME SET
MON 12:00 M
MENU
Use Δ ∇ Exit

- 4** Press RETURN again.
"Set the day:" appears on the screen.



CURRENT TIME SET
SUN 12:00 M
MENU
Set the day.
Use Δ ∇ Exit

- 5** Press Δ or ∇ to set the day.
Each time you press Δ or ∇ , the day changes consecutively.



Press RETURN.
"Set the time:" appears on the screen.



CURRENT TIME SET
MON 12:00 M
MENU
Set the time.
Use Δ ∇ Exit

- 6** Press Δ or ∇ to set the hour.
Each time you press Δ or ∇ , the hour changes starting with "12:00 AM."



Press RETURN.



CURRENT TIME SET
MON 3:00 M
MENU
Set the time.
Use Δ ∇ Exit

- 7** Press Δ or ∇ to set the minutes.
Each time you press Δ or ∇ , the minutes change in sequence.



Press RETURN.
The setting is completed, and the clock starts.



CURRENT TIME SET
MON 3:15 M
MENU
Set the time.
Use Δ ∇ Exit

CURRENT TIME SET
MON 3:15 M
MENU
Use Δ ∇ Exit

To reset the time
Press RESET while in the CURRENT TIME screen, and repeat steps 4-7.

To display the time
Press DISPLAY.


To return to the normal screen
Press MENU.

Notes

- The internal clock of this TV operates on a 12-hour cycle. If a 24-hour cycle number (for instance, 13:00) is entered, it will be cleared when you press RETURN.

12:00 AM stands for midnight.
12:00 PM stands for noon.

- All the settings including CURRENT TIME SET will be erased if you unplug the TV or a power failure occurs. Reset the current time by following steps 1-7.



RM-Y118

Setting the ON/OFF TIMER

With this function you can set your favorite program to appear on the screen at the time that you set.

EXAMPLE: Set the timer to turn on the TV every Monday through Friday at 3:15 PM for 2 hours, on channel 21.

- 1 Press MENU.
The main menu appears.



VIDEO
AUDIO
TIME
SET UP
CLOSED CAPTION
Use Δ (R) Exit (L)

- 2 Press Δ or ∇ to select TIME.
Then press RETURN.
The TIME menu appears.



TIME
CURRENT TIME SET
ON/OFF TIMER
CHANNEL BLOCK
MENU
MON 3:15 M
Use Δ (R) Exit (L)

- 3 Press Δ or ∇ to select ON/OFF TIMER.
Then press RETURN.
The ON/OFF TIMER screen appears.



ON/OFF TIMER
EVERY SUN-SAT
12:00M_h CH____
MENU
Use Δ (R) Exit (L)

Note

If the ON/OFF TIMER display appears in black, the current time has not been set and you cannot select ON/OFF TIMER. To set the clock, see "Setting the Clock—CURRENT TIME SET", pp. 44–45.

- 4 Press RETURN again.
"Set the day." appears on the screen.



ON/OFF TIMER
EVERY SUN-SAT
12:00M_h CH____
MENU
Set the day.
Use Δ (R) Exit (L)

- 5 Press Δ or ∇ to set the day.
Each time you press Δ or ∇ , the days of the week change as shown in Fig. 1.
Then press RETURN.
"Set the time." appears on the screen.



ON/OFF TIMER
EVERY MON-FRI
12:00M_h CH____
MENU
Set the time.
Use Δ (R) Exit (L)

- 6 Press Δ or ∇ to set the hour that you want the TIMER to start.
Each time you press Δ or ∇ , the hour changes in sequence.
Then press RETURN.



ON/OFF TIMER
EVERY MON-FRI
3:00M_h CH____
MENU
Set the time.
Use Δ (R) Exit (L)

- 7 Press Δ or ∇ to set the minutes.
Each time you press Δ or ∇ , the minutes change in sequence.
Then press RETURN.
"Set the duration." appears on the screen.



ON/OFF TIMER
EVERY MON-FRI
3:15M_h CH____
MENU
Set the duration.
Use Δ (R) Exit (L)

- 8 Press Δ or ∇ to set the duration of time.
Each time you press Δ or ∇ , the duration changes from "1" to "6" in sequence.
Then press RETURN.
"Select the channel" appears on the screen.



ON/OFF TIMER
EVERY MON-FRI
3:15M 2h CH____
MENU
Select the channel
Use Δ (R) Exit (L)

- 9 Press Δ or ∇ to set the channel that you want the TV to tune in.
Each time you press Δ or ∇ , the channel number changes from 1 to 125 in sequence.



Press RETURN.

The setting is completed, and the TIMER indicator on the front of the TV lights up.



ON/OFF TIMER
EVERY MON-FRI
3:15M 2h CH 21
MENU
Select the channel
Use Δ (R) Exit (L)

ON/OFF TIMER
EVERY MON-FRI
3:15M 2h CH 21
MENU
Use Δ (R) Exit (L)


To clear the ON/OFF TIMER setting
Press RESET while in the ON/OFF TIMER screen.


To return to the normal screen
Press MENU.

Notes

- While the TIMER is set, the TIMER indicator on the TV is on.
- One minute before the timer goes off, the "TV will turn off" display will appear on the screen.
- All the settings including ON/OFF TIMER will be erased if you unplug the TV or a power failure occurs. Reset the ON/OFF TIMER by following steps 1-9.
- If you have not set the clock correctly, the ON/OFF TIMER will not operate at the proper time. To set the clock, see "Setting the Clock—CURRENT TIME SET", pp. 44–45.

Fig. 1
Selecting the day(s) of the week
When you press Δ , the days of the week appear in the following order.





RM-Y118

Setting CHANNEL BLOCK

Use this function to block a channel from appearing on the screen during the time you specify. You can use this function to prevent children from watching undesirable programs.

EXAMPLE: Set CHANNEL BLOCK every Sunday at 8:45 PM for one hour, on channel 38.

- 1 Press MENU.
The main menu appears.



VIDEO
AUDIO
TIME
SET UP
CLOSED CAPTION
Use Exit

- 2 Press Δ or ∇ to select TIME.
Then press RETURN.
The TIME menu appears.



TIME
CURRENT TIME SET
ON/OFF TIMER
CHANNEL BLOCK
MENU
Use Exit

- 3 Press Δ or ∇ to select CHANNEL BLOCK.
Then press RETURN.
The CHANNEL BLOCK screen appears.



CHANNEL BLOCK
EVERY SUN-SAT
12:00M _h CH____
MENU
Use Exit

Note

If the CHANNEL BLOCK display appears in black, the current time has not been set and you cannot select CHANNEL BLOCK. To set the clock, see "Setting the Clock—CURRENT TIME SET", pp. 44–45.

- 4 Press RETURN again.
"Set the day," appears on the screen.



CHANNEL BLOCK
EVERY SUN-SAT
12:00M _h CH____
MENU
Set the day.
Use Exit

- 5 Press Δ or ∇ to set the day.
Each time you press Δ or ∇ , the days of the week change as shown in Fig. 1. (See p. 47.)
Then press RETURN.
"Set the time," appears on the screen.



CHANNEL BLOCK
SUNDAY
12:00M _h CH____
MENU
Set the time.
Use Exit

- 6 Press Δ or ∇ to set the hour.
Each time you press Δ or ∇ , the hour changes in sequence.
Then press RETURN.



CHANNEL BLOCK
SUNDAY
8:00M _h CH____
MENU
Set the time.
Use Exit

- 7 Press Δ or ∇ to set the minutes.
Each time you press Δ or ∇ , the minutes change in sequence.
Then press RETURN.
"Set the duration," appears on the screen.



CHANNEL BLOCK
SUNDAY
8:45M _h CH____
MENU
Set the duration.
Use Exit

- 8 Press Δ or ∇ to set the duration of time that you want the TV remain blocked.
Each time you press Δ or ∇ , the duration changes from 1 to 6 in sequence.
Then press RETURN.
"Select the channel" appears on the screen.



CHANNEL BLOCK
SUNDAY
8:45M 1h CH____
MENU
Select the channel
Use Exit

- 9 Press Δ or ∇ to set the channel that you want to block.
Each time you press Δ or ∇ , the channel number changes from 1 to 125 in sequence.




Press RETURN.
The setting is completed.



CHANNEL BLOCK
SUNDAY
8:45M 1h CH 38
MENU
Select the channel
Use Exit

CHANNEL BLOCK
SUNDAY
8:45M 1h CH 38
MENU
Use Exit

If you select a channel which has been blocked, the message of "BLOCKED" appears.




To clear the BLOCK setting
Press RESET while in the CHANNEL BLOCK screen.

To return to the normal screen
Press MENU.

Notes

- If you set a new CHANNEL BLOCK by following steps 1-9, the original setting will be erased.
- If you have not set the clock correctly, CHANNEL BLOCK will not operate at the proper time. To set the clock, see "Setting the Clock—CURRENT TIME SET", pp. 44–45.

1-12. CUSTOMIZING THE SCREEN DISPLAY



RM-Y118

Setting Channel Captions — CH CAPTION

Use this feature to caption up to 12 channel number displays with the matching channel call letters.

EXAMPLE: Caption channel 20 with ESPN at the caption position number 4.

- 1 Press MENU.
The main menu appears.



► VIDEO
AUDIO
TIME
SET UP
CLOSED CAPTION
Use Δ ∇ Exit

- 2 Press Δ or ∇ to select SET UP.
Then press RETURN.
The SET UP menu appears.



SET UP
► CABLE: ON
AUTO PROGRAM
CH ERASE/ADD
CH CAPTION/GUIDE
S VIDEO
VIDEO LABEL
► MENU

- 3 Press Δ or ∇ to select CH CAPTION/GUIDE.
Then press RETURN.
The CH CAPTION/GUIDE screen appears.



CH CAPTION/GUIDE
1 2 3
4 5 6
7 8 9
0 00
Select the letter.
Use Δ ∇ Exit

Note

If the CH CAPTION display appears in black, the TV is in video mode and you cannot select CH CAPTION/GUIDE. Press TV/VIDEO to change to TV mode.

- 4 Press RETURN again.
"Select a position." appears on the screen.



CH CAPTION/GUIDE
1 2 3
4 5 6
7 8 9
0 00
Select a position.
Use Δ ∇ Exit

- 5 Press Δ or ∇ to select a caption position number.
Each time you press Δ or ∇ , the caption position number is marked in sequence.
Then press RETURN.
"Select the channel" appears on the screen.



CH CAPTION/GUIDE
1 2 3
4 5 6
7 8 9
0 00
Select the channel
Use Δ ∇ Exit

- 6 Press Δ or ∇ to select the channel you want to caption.
Each time you press Δ or ∇ , the channel number changes from 1 to 125.
Then press RETURN.
"Select the letter." appears on the screen.



CH CAPTION/GUIDE
1 2 3
4 5 6
7 8 9
0 00
Select the letter.
Use Δ ∇ Exit

- 7 Press Δ or ∇ to select the first letter.
Each time you press Δ or ∇ , "0-9", "A-Z", " ", "-", and "." (blank space) appear in sequence.



CH CAPTION/GUIDE
1 2 3
4 5 6
7 8 9
0 00
Select the letter.
Use Δ ∇ Exit

- 8 Repeat step 7 to select each remaining letter.
(For a 3-letter caption, leave a space by pressing RETURN only.)



CH CAPTION/GUIDE
1 2 3
4 5 6
7 8 9
0 00
Select the letter.
Use Δ ∇ Exit

- 9 Press RETURN.
The setting is completed.




CH CAPTION/GUIDE
1 2 3
4 5 6
7 8 9
0 00
Use Δ ∇ Exit

To caption other channels
Repeat steps 4-9.

To erase unneeded captions
Call the caption setting screen by following steps 1-5, and press RESET.

To return to the normal screen
Press MENU.



RM-Y118

Viewing the Captioned Channels — CH GUIDE

Use this feature to display the captions you set, and to select a channel directory for viewing.



- 1 Press CH GUIDE.
A directory appears, corresponding to the directory keys on the Remote Commander.

CH GUIDE



To cancel the CHANNEL GUIDE screen
Press CH GUIDE again.

- 2 Press the directory key of the channel you want to watch.



RM-Y118

Setting VIDEO LABEL (except for KV-27TS29/2970RS)

Use this feature to label each input mode in order to identify the equipment connected to each input terminal.

EXAMPLE: Label VIDEO 1 IN as VHS.

- 1 Press MENU.
The main menu appears.



- 2 Press Δ+ or ∇- to select SET UP.



Press RETURN.
The SET UP menu appears.




- 3 Press Δ+ or ∇- to select VIDEO LABEL.



Press RETURN.
The VIDEO LABEL screen appears.





To return to the normal screen
Press MENU.

4 Press Δ or ∇ to select the input mode you want to label.

Press RETURN.

5 Press Δ or ∇ to select VHS.

Each time you press Δ +, the label changes:

VIDEO 1
VIDEO 1 \rightarrow S VIDEO \rightarrow BETA \rightarrow 8 mm \rightarrow VHS \rightarrow LD

VIDEO 2
VIDEO 2 \rightarrow BETA \rightarrow 8 mm \rightarrow VHS \rightarrow LD


VIDEO 3
VIDEO 3 \rightarrow BETA \rightarrow 8 mm \rightarrow VHS \rightarrow LD

(∇ -: reverse order)

Press RETURN.

To label other input modes
Repeat steps 4-5.

1-13. USING THE PRE-PROGRAMMED REMOTE COMMANDER



You can operate your video equipment and cable converter box that has an infrared remote detector with this supplied pre-programmed Remote Commander.

Operating Sony or non-Sony Video Equipment—Pre-Programmed Function

With the supplied Remote Commander, you can operate a Sony video cassette recorder (Beta, 8 mm, VHS) or a multi disc player as well as most non-Sony video equipment connected to your TV by following the steps below.

- While pressing CODE SET, press 0 - 9 to enter the manufacturer's code number (see chart on p. 56). For example, to operate a Sony 8 mm VCR, press 0, 2 and ENTER.



- Use the video operating buttons on the Remote Commander to operate the video equipment.

Operating a VCR

To turn on or off
To change channels
(when watching TV programs through the VCR's tuner)

Press VIDEO POWER.
Press CH +/-.

To record
To play
To stop
To fast forward
To rewind the tape
To pause
To search the picture forward and backward

Press \bullet (2 buttons simultaneously).
Press \blacktriangleright .
Press \blacksquare .
Press $\blacktriangleright\blacktriangleright$.
Press $\blacktriangleleft\blacktriangleleft$.
Press II .
Press $\blacktriangleright\blacktriangleright$ or $\blacktriangleleft\blacktriangleleft$ during playback.

Operating a Video Disc Player

To play
To stop
To pause

Press \blacktriangleright .
Press \blacksquare .
Press II .

To resume normal playback, press again.

*This function is effective only for CAV (standard-play disc). With CLV (extended-play disc), the TV will go into the standby mode if II is pressed.

To search the picture forward and backward

Keep pressing $\blacktriangleright\blacktriangleright$ or $\blacktriangleleft\blacktriangleleft$ during playback.
To resume normal playback, release the button.

Manufactures and Code Numbers (VCR/video disc player)

Manufacturer	Code number
SONY	01, 02, 03, 04
CANON	05
EMERSON	22, 30, 33
FISHER	10, 11, 12, 15
FUNAI	29
GENERAL ELECTRIC	05, 08
GOLDSTAR	25
HITACHI	07, 08
JVC	16
MAGNAVOX	05, 06, 09
DAEWOO	18, 19, 26, 27
MITSUBISHI	29
MULTITECH	16, 23, 31
NEC	05, 06
PANASONIC	05, 06
PHILCO	05, 06
PHILIPS	05, 06, 09
QUASAR	05, 06
RCA	07, 08
SAMSUNG	24, 32
SANYO	11, 15
SCOTT	21
SHARP	13, 14
SHINTOM	34
SYLVANIA	05, 06, 09
SYMPHONIC	29
TEKNIKA	28, 29
TOSHIBA	20, 21
TOTE VISION	25
ZENITH	17

The code numbers for Sony equipment are assigned as follows:


- 01 Beta, ED Beta VCR
- 02 8 mm VCR
- 03 VHS VCR
- 04 Video disc player

Notes

- If more than one code number is listed for manufacturers other than Sony, try entering them one by one, until you come to the correct code for your equipment.
- If the video equipment does not have a certain function, the corresponding button on this Remote Commander will not operate.
- In some rare cases, you may not be able to operate your non-Sony video equipment with the supplied Remote Commander. This is because your equipment may use a code that is not provided with this Remote Commander. In this case, please use the equipment's own remote control unit.

CAUTION

When you remove the batteries from the Remote Commander, all the settings will revert to the Sony Beta setting. Reset the codes by following the steps on p. 55.



RM-Y118

Manufactures and Code Numbers (cable box)

MANUFACTURER	CODE
JERROLD	60, 61, 62, 63, 64, 65
PIONEER	69, 70
SCIENTIFIC ATLANTA	66, 67
TOCOM	71, 72
ZENITH	68

Operating a Cable Converter Box

Follow these instructions to set the manufacturer's code which will enable you to operate a connected cable converter box with the pre-programmed Remote Commander.

EXAMPLE: Operate a connected Zenith cable converter box.

- 1 Set the TV/CABLE selector to CABLE.



Notes

- If more than one code number is listed, try entering them one by one until you come to the correct code for your equipment.
- If you enter a new code number, the code number you previously entered at that setting is erased.
- In some rare cases, your equipment may use a code that is not provided with this Remote Commander and you may not be able to operate your cable converter box with the supplied Remote Commander. In this case, use the equipment's own remote control unit.

- 2 While pressing CODE SET, press 6 and 8 (Zenith's code number - see chart below) and ENTER.



A long beep sound's, indicating that the code has been set.

Note

If you press a wrong code or if the code has not been set, four short beeps sound. Repeat step 2 to set the code.

- 3 Use CABLE POWER and the TV control buttons (0 - 9, ENTER, JUMP and CH +/-) to operate the cable converter box.




To operate the TV

Set the TV/CABLE selector to TV, then use the TV control buttons to control the TV.


For more details on operating the cable box
Refer to the operating instructions that come with the cable box.

SECTION 2 DISASSEMBLY


2-1. REAR COVER REMOVAL



2-2. CHASSIS ASSY REMOVAL




2-3. SERVICE POSITION




2-4. P BOARD AND P BRACKET REMOVAL



(KV-32TS46 (UC/CND)/32TS36 (US/CND)
 /27TS36 (US/CND) only)



2-5. UA BOARD REMOVAL




2-6. EXTENSION CABLE



2-7. PICTURE TUBE REMOVAL (1)


(KV-27TS36 (US/CND)/27TS32/27TS29 (US/CND) only)



• REMOVAL OF ANODE-CAP


NOTE : Short circuit the anode of the picture tube and the anode cap to the metal chassis, CRT chield or carbon painted on the CRT, after removing the anode.

• REMOVING PROCEDURES




• HOW TO HANDLE AN ANODE-CAP

- ① Don't hurt the surface of anode-caps with sharp shaped material!
- ② Don't press the rubber hardly not to hurt inside of anode-caps!
A material fitting called as shatter-hook terminal is built in the rubber.
Don't turn the foot of rubber over hardly!
The shatter-hook terminal will stick out or hurt the rubber.
- ③



2.7. PICTURE TUBE REMOVAL (2)


(KV-32TS46 (US/CND)/32TS36 (US/CND) only)



• REMOVAL OF ANODE-CAP

NOTE : Short circuit the anode of the picture tube and the anode cap to the metal chassis, CRT shield or carbon painted on the CRT, after removing the anode.

• REMOVING PROCEDURES





① Turn up one side of the rubber cap in the direction indicated by the arrow ㉑.

② Using a thumb pull up the rubber cap firmly in the direction indicated by the arrow ㉒.

③ When one side of the rubber cap is separated from the anode button, the anode-cap can be removed by turning up the rubber cap and pulling up it in the direction of the arrow ㉓.

• HOW TO HANDLE AN ANODE-CAP

- ① Don't hurt the surface of anode-caps with sharp shaped material!
- ② Don't press the rubber hardly not to hurt inside of anode-caps!
A material fitting called as shatter-hook terminal is built in the rubber.
- ③ Don't turn the foot of rubber over hardly!
The shatter-hook terminal will stick out or hurt the rubber.



2-8. REPAIR OF CHIP COMPONENT CIRCUIT BOARD

2-8-1. POINTS OF COMPONENT REMOVAL

Handling of blower type soldering iron

If hot blast is too strong or applied from a slanting direction, small components and solder near the component being removed can be blown off. Do not use blower type without temperature control.

2-8-2. NOTES ON SOLDERING FOR CHIP COMPONENTS

- 1) During soldering a chip component, if a soldering iron is applied for a long time, the heat may damage the component or cause pattern peeling.
- 2) Do not reuse a removed component. The characteristics of such a component may deteriorate.
- 3) Use wire solder containing silver (ϕ 0.3 or ϕ 0.6).
(The pin electrodes of the laminated chip capacitor are silver +palladium, so if wire solder which does not contain silver is used, the silver of the pin electrode will be sucked into the solder.)


2-8-3. REMOVAL AND MOUNTING OF COMPONENTS

Chip resistor and chip capacitor


REMOVAL

- Using two soldering irons


1) Mounted state



2) Melt the solder.




3) Remove the component.




SOLDERING

1) Preparation




2) Location


Be careful not to misposition.




3) Tack soldering and flux application



4) Soldering



5) Soldering (Fix the fillet.)



6) Visual inspection

Check for the following defects :


- No-soldered part
- Bridge (to other components or lands)
- Mispositioning
- Other defects

2-8-4. MINI-TRANSISTOR


REMOVAL

- Using two soldering irons

1) Put a little solder on the tip of two soldering irons.



2) Apply the tip of one soldering iron to the point "a" and the other to the points "b" → "c" (or "b" → "d" → "c") and move the component in the directions indicated by arrows in the figure to remove it.




MOUNTING


1) Apply a little flux to the land with a brush.




2) Place the component in position using tweezers.



3) Put a little solder on the tip of the soldering iron and solder the point "a" to fix the component.




4) Bring the tip of the soldering iron and the wire solder close to the point to be soldered. Solder the points "b" → "c" (or "b" → "d" → "c") in order.




2-8-5. TWO-DIRECTIONAL FLAT PACKAGE IC

MOUNT CONDITION




- When the solder melts, lift the IC with a pair of tweezers and remove.




REMOVAL

- Apply some solder on the inside and the tip of the iron tip jig.




- Place the iron tip jig over the IC, and move the jig to and fro as shown in the figure.




INSTALLATION

- Place the two-directional flat package IC at the appointed position, solder pins a and b on the diagonal, and fasten it.





- Solder the remaining pins with the soldering iron.




2-8-6. FOUR-DIRECTIONAL FLAT PACKAGE IC

MOUNT CONDITION




REMOVAL

- 1) Apply solder on the tip of the iron tip jig.



- 2) Place the iron tip jig over the IC, wait about two to three seconds, rotate the iron slightly and lift it up.



Note: For flat ICs of above 52P, the IC may not be completely attracted when the iron tip jig is lifted up. In these cases, use a pair of tweezers to remove.

INSTALLATION


- 1) Place the four-directional flat package IC at the appointed position.




- 2) Apply a slight amount of solder on the iron tip, and solder the three sections in the order of a → b → c, and fix.




- 3) Apply a slight amount of flux with a pen on all four directions.



- 4) Apply solder on the iron tip and the string solder, and slide and solder in the directions of the arrows.




Note: 1) After soldering, if there are bridged sections, correct by sliding the soldering iron in the direction of the arrow.








If the bridges cannot be corrected using the above method, apply some flux with a pen and try again.

2) Soldering can be carried out more easily by sliding the iron tip near the tip of the IC leg. (Fig. A)



Be careful not to slide the bent sections of the leg as shown in Fig. B as soldering bridges will be formed.



Exterior	Description	Part No.	Measure (mm)			
			A	B	C	D
	jig for removing 4-sided flat package IC	3-702-554-01	12.5	9.5	12.5	9.5
		" 11	15.5	12.5	15.5	12.5
		" 21	16.3	13.3	16.3	13.3
		" 31	17.0	14.0	17.0	14.0
		" 41	23.0	20.0	17.0	14.0
		" 51	20.0	17.0	20.0	17.0
	jig for removing 2-sided flat package IC	3-702-555-01	6.0	5.0		
		" 11	6.0	10.0		
		" 21	7.0	12.5		
		" 31	9.0	15.2		
		" 41	9.0	18.0		
	soldering iron	3-702-552-01	55W 60g length 210mm			
	soldering holder	3-702-553-01				

SECTION 3 SET-UP ADJUSTMENTS

- The following adjustments should be made when a complete realignment is required or a new picture tube is installed.
- These adjustments should be performed with rated power supply voltage unless otherwise noted.

Controls and switch should be set as follows unless otherwise noted :

PICTURE control RESET
BRIGHTNESS control center

Perform the adjustments in order as follows :

1. Beam Landing
2. Convergence
3. Focus
4. White Balance

Note : Test Equipment Required.

1. Color-bar/Pattern Generator
2. Degausser
3. Oscilloscope

Preparations :

- In order to reduce the influence of geomagnetism on the set's picture tube face it east or west.
- Switch on the set's power and degauss with the degausser.

3-1. BEAM LANDING

1. Input the white signal with the pattern generator.
Contrast } normal
Brightness }
2. Set the pattern generator raster signal to green.
3. Move the deflection yoke to the rear and adjust with the purity control so that the green is at the center and the blue and the red take up equally sized areas on each side.
(See Figures 3-1 through 3-3.)
4. Move the deflection yoke forward and adjust so that entire screen is green. (See Figure 3-1.)
5. Switch the raster signal to blue, then to red and verify the condition.
6. When the position of the deflection yoke has been decided, fasten the deflection yoke with the screws.
7. If the beam does not land correctly in all the corners, use a magnet to adjust it.
(See Figure 3-4.)




Fig.3-1




Fig.3-2




Fig.3-3





Fig.3-4

3-2. CONVERGENCE

Preparation :


- Before starting this adjustment, adjust the focus, horizontal size, and vertical size.
- Minimize the brightness setting.
- Provide dot pattern.

(1) Horizontal and Vertical Static Convergence




1. (Moving horizontally), adjust the H.STAT control so that the red, green, and blue points are on top of each other at the center of the screen.
2. (Moving vertically), adjust the V.STAT magnet so that the red, green, and blue points are on top of each other at the center of the screen.
3. If the H.STAT variable resistor cannot bring the red, green, and blue points together at the center of the screen, adjust the horizontal convergence with the H.STAT variable resistor and the V. STAT magnet in the manner given below.
(In this case, the H.STAT variable resistor and the V. STAT magnet influence each other)


- Tilt the V.STAT magnet and adjust the static convergence by opening or closing the V.STAT magnet.



4. If the V.STAT magnet is moved in the direction of the ① and ② arrows, the red, green, and blue points move as shown below.



• Operation of BMC (Hexapole) Magnet




- The respective dot positions resulting from moving each magnet interact, so be sure to perform adjustment while tracking. Use the H.STAT VR to adjust the red, green, and blue dots so they coincide at the center of screen (by moving the dots in the horizontal direction).

(2) Dynamic Convergence Adjustment

Preparations :

- Before starting this adjustment, adjust the horizontal static convergence and the vertical static convergence.


1. Slightly loosen the deflection yoke screws.
2. Remove the deflection yoke spacer.



• Y separation axis correction magnet adjustment

1. Receive the cross-hatch signal, and adjust [PLX] to "MIN" and [BRT] to "standard".
2. Adjust the deflection yoke to the upright condition when it hits the CRT.
3. Adjust so that the Y separation axis correction magnet on the neck assembly is symmetrical at the top and bottom (open state).
4. Return the deflection yoke to its original position.

3. Move the deflection yoke as shown in the figure below and optimize the convergence.
4. Tighten the deflection yoke screws.
5. Install the deflection yoke spacer.




(3) Dynamic Convergence Circuit Adjustment (32 inch only)

SERVICE MODE PROCEDURE


- Standby mode.(Power off)
- DISPLAY** → **5** → **VOL (+)** → **POWER** on the Remote Commander. (Press each button within a second.)

SERVICE ADJUSTMENT MODE IN




- The CRT displays the item Being adjusted.
- Press **1** or **4** on the Remote Commander to select the item.
- Press **3** or **6** on the Remote Commander to change the data.
- Press **MUTING** then **ENTER** to write into memory.

SERVICE ADJUSTMENT MODE MEMORY



- Press **8** then **ENTER** on the Remote Commander to initialize.




- Turn set off and on to exit.

- Set to Service Mode.
- Input a cross-hatch signal.
- Press **1** and **4** select an item of adjustments.
- Adjust **3** and **6** to the best picture.

No.	Disp.	Item	Ave.Data
39	UYBO	Upper Y-Bow	31
40	LYBO	Lower Y-Bow	25
41	HAMP	H. Amp	33
42	HTIL	H. Tilt	33
43	UCBO	Upper C-Bow	38
44	UTIL	Upper Tilt	40
45	LCBO	Lower C-Bow	41
46	LTIL	Lower Tilt	46
47	DCSH	DC Shift	37


U. YBOW

Select UYBO with **1** and **4**




L. YBOW

Select LYBO with **1** and **4**




H. AMP

Select HAMP with **1** and **4**




H. TILT

Select HTILT with 1 and 4





(4) Screen-corner Convergence




U. CBOW

Select UCBO with 1 and 4



U. TILT

Select UTIL with 1 and 4





3-3. FOCUS ADJUSTMENT

Adjust FOCUS control on the flyback transformer for a best focus.


L. CBOW

Select LCBO with 1 and 4



L. TILT

Select L. TIL with 1 and 4



3-4. G2 (SCREEN) AND WHITE BALANCE ADJUSTMENTS

1. G2 (SCREEN) ADJUSTMENT (RV 702)

1. Set the PICTURE and BRIGHTNESS to normal.
2. Confirm G1 voltage is within 30.0 ± 5 V.
3. Apply DC voltage of 180 V to the cathodes of R, G and B from DC stabilized power source.
4. While watching the picture, adjust the G2 control (RV 702) to the just the retrace line disappears.


2. WHITE BALANCE ADJUSTMENTS

No.	Disp.	Item	Ave. Data
14	GAMP	Green Amp	20
15	BAMP	Blue Amp	17
16	GCUT	Green Cut-off	7
17	BCUT	Blue Cut-off	8
22	SBRT	Sub Bright	35

1. Input an entire white signal.
2. Set to service adjustment mode.
3. Set the PICTURE and BRIGHT to minimum.
4. Adjust with SBRT if necessary.
5. Select G CUT and B CUT with **[1]** and **[4]**.
6. Adjust with **[3]** and **[6]** for the best white balance.
7. Set the PICTURE and BRIGHT to maximum.
8. Select GAMP and BAMP with **[1]** and **[4]**.
9. Adjust with **[3]** and **[6]** for the best white balance.
10. Write into the memory by pressing **[MUTING]** then **[ENTER]**.

3. SUB BRIGHT ADJUSTMENT

1. Set to service mode.
2. Input a staircase signal of black and white from the pattern generator.
3. BRIGHTNESS ... RESET
 PICTURE minimum
4. Select SBRT with **[1]** and **[4]**, and adjust SUB BRIGHT level with **[3]** and **[6]** so that the stripe second from the right is dimly lit.



SECTION 4 SAFETY RELATED ADJUSTMENTS

KV-27TS29/27TS32/27TS36
RM-Y116 RM-Y117 RM-Y118
KV-32TS36/32TS46
RM-Y116 RM-Y118
SA-W200

KV-27TS29/27TS32/27TS36
RM-Y116 RM-Y117 RM-Y118
KV-32TS36/32TS46
RM-Y116 RM-Y118
SA-W200

☒ R511 CONFIRMATION METHOD (HOLD-DOWN CONFIRMATION) AND READJUSTMENTS

The following adjustments should always be performed when replacing the following components (marked with ☒ on the schematic diagram).
PM501, R338, R511, R632, R645, R650


- ①
 1. Preparation before confirmation
 - 1) Remove R635 on the D board and connect a variable resistor (RV1: about 22k Ω) between pin ① of IC601 and B+ line.
 - 2) Supply 130 \pm 2.0V AC to with variable auto-transformer.
 2. Hold-down operation confirmation
 - 1) Turn the POWER switch ON, and receive entirely white signals and adjust ABL current to 1760 \pm 50 μ A with PICTURE and BRIGHT etc controls.
 - 2) Increase B+ line voltage gradually by adjusting the resistor of RV1. Confirm that the minimum voltage is less than 142.5V DC (27 inch) 140.0V DC (32 inch) whereby the raster disappears during operation of hold-down circuit.

NOTE: When the hold-down circuit starts operating, switch OFF the POWER of the set immediately.

 - 3) Turn the POWER switch ON, and receive dot signals and adjust ABL current to 160 \pm 50 μ A with PICTURE and BRIGHT etc controls.
 - 4) Increase B+ line voltage gradually by adjusting the resistor of RV1. Confirm that the minimum voltage is less than 145.0V DC (27 inch), 143.5V DC (32 inch) whereby the raster disappears during operation of hold-down circuit.
- NOTE:** When the hold-down circuit starts operating, switch OFF the POWER of the set immediately.

3. Hold-down readjustment

When step 2 is not satisfied, readjustment should be performed by altering the resistance value of R511 (a component marked with ☒).



☒ R524 CONFIRMATION METHOD (HOLD-DOWN CONFIRMATION) AND READJUSTMENTS

The following adjustments should always be performed when replacing the following components (marked with ☒ on the schematic diagram).
IC601, PM501, D504, C598, R338, R509, R524, R632, R635, R645, T501

- ②
 1. Preparation before confirmation
 - 1) Turn the POWER switch ON, and receive entirely white signals and set the PICTURE and BRIGHT controls to maximum.
 - 2) Confirm that voltage of the check terminal of TP-85 (D BOARD) is more than 114.0V DC (27 inch) 122.3V DC (32inch) when the set is operating normally with 120.0 \pm 2.0V AC supply.
 2. Hold-down operation confirmation
 - 1) Turn the POWER switch ON, and receive entirely white signals and adjust ABL current to 1760 \pm 50 μ A with PICTURE and BRIGHT etc controls.
 - 2) Apply DC voltage of over 130.0V DC gradually to the check terminal of TP-85 (D BOARD) via 1T40 from the DC stabilized power source. Confirm that the minimum voltage is less than 137.5V DC (27inch) 143.5V DC (32inch) whereby the raster disappears during operation of hold-down circuit.

NOTE: When the hold-down circuit starts operating, switch OFF the POWER of the set immediately.

 - 3) Turn the POWER switch ON, and receive dot signals and adjust ABL current to 160 \pm 50 μ A with PICTURE and BRIGHT etc controls.
 - 4) Apply DC voltage of over 130.0V gradually to the check terminal of TP-85 (D BOARD) via 1T40 from the DC stabilized power source. Confirm that the minimum voltage is less than 138.0V DC (27inch) 144.1V DC (32inch) whereby the raster disappears during operation of hold-down circuit.
- NOTE:** When the hold-down circuit starts operating, switch OFF the POWER of the set immediately.


3. Hold-down readjustment

When step 2 is not satisfied, readjustment should be performed by altering the resistance value of R524 (a component marked with ☒).

B+ VOLTAGE CONFIRMATION

The following adjustments should always be performed when replacing IC601 and R635.

- 1) Supply 130 \pm 2.0 V AC to with variable autotransformer.
- 2) Receive entirely monoscope signal.
- 3) Set the PICTURE control and the BRIGHT controls in to initial reset.
- 4) Confirm the voltage of TP91 is less than 137.0V DC.
- 5) If step 4) is not satisfied, replace IC601 and R635 repeat above steps.



SECTION 5
CIRCUIT ADJUSTMENTS

KV-27TS29/27TS32/27TS36	KV-27TS29/27TS32/27TS36
RM-Y116 RM-Y117 RM-Y118	RM-Y116 RM-Y117 RM-Y118
KV-32TS36/32TS46	KV-32TS36/32TS46
RM-Y116 RM-Y118 SA-W200	RM-Y116 RM-Y118 SA-W200

5-1. ELECTRICAL ADJUSTMENT BY REMOTE COMMANDER

Use of Remote Commander can be performed circuit adjustments about this model.

NOTE : Test Equipment Required.


1. Pattern Generator
2. Frequency counter
3. Digital multimeter
4. Audio OSC

1. METHOD OF SETTING THE SERVICE
ADJUSTMENT MODE

SERVICE MODE PROCEDURE


1. Standby mode.(Power off)
2. **DISPLAY** → **5** → **VOL (+)** → **POWER** on the Remote Commander. (Press each button within a second.)

SERVICE ADJUSTMENT MODE IN




3. The CRT displays the item Being adjusted.
4. Press **1** or **4** on the Remote Commander to select the item.
5. Press **3** or **6** on the Remote Commander to change the data.
6. Press **MUTING** then **ENTER** to write into memory.

SERVICE ADJUSTMENT MODE MEMORY



7. Press **8** then **ENTER** on the Remote Commander to initialize.



Carry out step 7) when adjusting IDs 0 to 4 and when replacing and adjusting IC102.



Factory original setting

8. Turn set off and on to exit.

2. MEMORY WRITE CONFIRMATION METHOD

1. After adjustment, pull out the plug from AC outlet, and next place, plug in AC outlet again.
2. Turn the power switch ON and set to Service Mode.
3. Call the adjusted items again, confirm they were adjusted.

3. ADJUST BUTTONS AND INDICATOR



RM-Y117/RM-Y118

4. AN ITEM OF ADJUSTMENTS

No.	Disp.	Item	Data range	Ave. data (27 inch)	Ave. data (32 inch)
1	AFC	AFC Loop Gain	0~3	* 0	* 0
2	HFRE	H. Frequency	0~127	70	70
3	VFRE	V. Frequency	0~31	16	16
4	VPOS	V. Center	0~31	17	17
5	VSIZ	V. Size	0~63	28	12
6	VLIN	V. Linearity	0~15	8	7
7	VSCO	V. Correction	0~15	6	6
8	HPOS	H. Center	0~15	6	5
9	HSIZ	H. Size	0~31	31	27
10	PAMP	Pin Amp	0~31	24	31
11	CPIN	Corner Pin	0~7	3	0
12	PPHA	Pin Phase	0~15	6	4
13	VCOM	V. Compensation	0~7	* 2	* 2
14	GAMP	Green Amp	0~31	20	20
15	BAMP	Blue Amp	0~31	17	17
16	GCUT	Green Cut Off	0~15	7	7
17	BCUT	Blue Cut Off	0~15	8	8
18	CROM	Chroma Trap	0~63	* 28	* 28
19	SPIX	Sub Contrast	0~63	20	20
20	SHUE	Sub Hue	0~63	33	33
21	SCOL	Sub Color	0~63	32	32
22	SBRT	Sub Bright	0~63	35	35
23	RGBP	RGB Picture	0~63	* 10	* 10
24	SHAP	Sharpness	0~15	* 7	* 7
25	VSMO	V Pull in Range	0, 1	* 0	* 0
26	REF	Reference line	0~3	* 2	* 2
27	ROFF	Red Out	0, 1	1	1
28	GOFF	Green Out	0, 1	1	1
29	BOFF	Blue Out	0, 1	1	1
30	ABLM	ABL Mode	0, 1	* 0	* 0
31	NOTC	Notch On/Off	0, 1	* 1	* 1
32	DRGB	OSD intensity	0, 1	* 0	* 0
33	VANG	V. Angle	0~63	0	0
34	DISP	Display Position	0~63	40	40
35	SVOL	Sub Volume	0~15	* 0	* 0
36	SBAL	Sub Balance	0~15	7	7
37	BASS	Sub Bass	0~15	* 8	* 8
38	TRE	Sub Treble	0~15	* 7	* 7
39	UYBO	Upper Y. Bow	0~63	—	31
40	LYBO	Lower Y. Bow	0~63	—	25
41	HAMP	H. Amp	0~63	—	33
42	HTIL	H. Tilt	0~63	—	33
43	UCBO	Upper C. Bow	0~63	—	38
44	UTIL	Upper Tilt	0~63	—	40
45	LCBO	Lower C. Bow	0~63	—	41
46	LTIL	Lower Tilt	0~63	—	46
47	DCSH	DC. Shift	0~63	—	37
48	PHPO	PinP H Position	0~127	76	76
49	PHUE	PinP Hue	0~31	* 0	* 0
50	ID-0	Model ID	0~127	by Model	by Model
51	ID-1	Model ID	0~127	by Model	by Model
52	ID-2	Model ID	0~127	by Model	by Model
52	ID-2	Model ID	0~127	by Model	by Model
52	ID-2	Model ID	0~127	by Model	by Model
53	ID-3	Model ID	0~127	by Model	by Model
54	ID-4	Model ID	0~127	by Model	by Model

* : Set-up value

Note : No. from 1 to 54 is to show adjustment order.

SERVICE	ID 0	64
1000	1000 000	

Please adjust the function values as shown below when IC 102 on M board was replaced.

KV-27TS29 (US)

No.	Disp.	Disp.	Data
50	ID-0	1 0 0 0 0 0 0	64
51	ID-1	1 1 1 1 1 1 1	127
52	ID-2	1 0 0 0 0 0 0	64
53	ID-3	0 0 0 0 0 0 0	0
54	ID-4	0 0 1 0 0 0 0	16

KV-27TS29 (CND)

No.	Disp.	Disp.	Data
50	ID-0	1 0 0 0 0 0 0	64
51	ID-1	1 1 1 1 1 1 1	127
52	ID-2	0 0 0 0 0 0 0	0
53	ID-3	0 0 0 0 0 0 0	0
54	ID-4	0 0 1 0 0 0 0	16

KV-27TS32 (US)

No.	Disp.	Disp.	Data
50	ID-0	1 1 1 1 0 0 0	120
51	ID-1	1 1 1 1 1 1 1	127
52	ID-2	1 1 0 1 0 0 0	104
53	ID-3	0 0 0 0 0 0 0	0
54	ID-4	0 0 1 0 0 0 0	16

KV-27TS36/32TS36 (US)

No.	Disp.	Disp.	Data
50	ID-0	1 1 1 1 0 0 0	120
51	ID-1	1 1 1 1 1 1 1	127
52	ID-2	1 0 0 1 0 0 0	72
53	ID-3	1 0 0 0 0 0 0	64
54	ID-4	0 0 1 0 0 0 0	16

KV-27TS36/32TS36 (CND)

No.	Disp.	Disp.	Data
50	ID-0	1 1 1 1 0 0 0	120
51	ID-1	1 1 1 1 1 1 1	127
52	ID-2	0 0 0 1 0 0 0	8
53	ID-3	1 0 0 0 0 0 0	64
54	ID-4	0 0 1 0 0 0 0	16

KV-32TS46 (US)

No.	Disp.	Disp.	Data
50	ID-0	1 1 1 1 0 0 0	120
51	ID-1	1 1 1 1 1 1 1	127
52	ID-2	1 0 0 1 0 0 0	72
53	ID-3	0 1 0 0 1 0 0	36
54	ID-4	0 0 1 0 0 0 0	16

KV-32TS46 (CND)

No.	Disp.	Disp.	Data
50	ID-0	1 1 1 1 0 0 0	120
51	ID-1	1 1 1 1 1 1 1	127
52	ID-2	0 0 0 1 0 0 0	8
53	ID-3	0 1 0 0 1 0 0	36
54	ID-4	0 0 1 0 0 0 0	16

5-2. M BOARD ADJUSTMENTS

H.FREQUENCY ADJUSTMENT (HFRE)

1. Input a color-bar signal.
2. Set to Service adjustment Mode.
3. Connect a frequency counter to CN131 Pin⑬ (H. DRIVE) connector and ground.
4. Call the item of AFC, set to 3 level (free run).
5. Select HFRE with **[1]** and **[4]**.
6. Adjust with **[3]** and **[6]** for the $15734 \pm 60\text{Hz}$.
7. Call the item of AFC again, adjust the level "0".
8. Write into the memory by pressing **[MUTING]** then **[ENTER]**.


V.FREQUENCY ADJUSTMENT (VFRE)

1. Select video 1 with no connecting the signal.
2. Set to Service adjustment Mode.
3. Connect the frequency counter across connector CN131 Pin⑦ (V. DRIVE) connector and ground.
4. Select VFRE with **[1]** and **[4]**.
5. Adjust with **[3]** and **[6]** for the $55 \pm 0.5\text{Hz}$.
6. Write the memory by pressing **[MUTING]** then **[ENTER]**.


SUB CONTRAST ADJUSTMENT (SPIX)

1. Input a color-bar signal.
2. Set to Service adjustment Mode.
3. Set the conditions as follows.

PICTURE MAX
COLOR MIN
BRIGHT CENTER
R OFF ON (1)
G OFF OFF (0)
B OFF OFF (0)



4. Connect an oscilloscope to CN703 Pin① (R OUT) of C board and ground.
5. Select SPIX with [1] and [4].
6. Adjust with [3] and [6] for the 1.9 ± 0.1 Vp-p.




7. Write the memory by pressing [MUTING] then [ENTER].
8. Return the following back to normal after adjustment.

PICTURE MAX
BRIGHT CENTER
COLOR CENTER
R OFF ON
G OFF ON
B OFF ON

SUB HUE, SUB COLOR ADJUSTMENT (SHUE, SCOL)

1. Input a color-bar signal.
2. Set to service adjustment mode.
3. Connect an oscilloscope to CN703 Pin③ (B OUT) of C board.
4. Select SHUE and SCOL with [1] and [4].
5. Adjust with [3] and [6] for the $V1=V4$ (SCOL) and $V2=V3$ (SHUE).




6. Increase the data of SCOL by 5 steps.
7. Write into the memory by pressing [MUTING] then [ENTER].

SUB BARANCE ADJUSTMENT (SBAL)

1. Input a stereo signal.
2. Set to service adjustment mode.
3. Select SBAL with [1] and [4].
4. Adjust with [3] and [6] for the best sound balance
5. Write into the memory by pressing [MUTING] then [ENTER].

DISPLAY POSITION ADJUSTMENT (DISP)

1. Input a color-bar signal.
2. Set to service adjustment Mode.
3. Select DISP with [1] and [4].
4. Adjust with [3] and [6] for the bar center.
5. Write the memory by pressing [MUTING] then [ENTER].




H.CENTER ADJUSTMENT (H POS)

Note: Perform this adjustment after H.FREQUENCY ADJUSTMENT (HFRE).

1. Input a cross-hatch signal.
2. Set the Service adjustment mode.
3. Select HPOS with **[1]** and **[4]**.
4. Adjust with **[3]** and **[6]** to the best horizontal center.
5. Write into the memory by pressing **MUTING** then **ENTER**.


H. CENTER (HPOS)



H.SIZE ADJUSTMENT (HSIZ)

1. Input a cross-hatch signal.
2. Set to service adjustment Mode.
3. Select HSIZ with **[1]** and **[4]**.
4. Adjust with **[3]** and **[6]** for best horizontal size.
5. Write into the memory by pressing **MUTING** then **ENTER**.

H. SIZE (HSIZ)



V.CENTER ADJUSTMENT (VPOS)

1. Input a cross-hatch signal.
2. Set to service adjustment Mode.
3. Select VPOS with **[1]** and **[4]**.
4. Adjust with **[3]** and **[6]** for the best vertical center.
5. Write into the memory by pressing **MUTING** then **ENTER**.

V. CENTER (VPOS)



V.SIZE ADJUSTMENT (VSIZ)

1. Input a cross-hatch signal.
2. Set to service adjustment Mode.
3. Select VSIZ with **[1]** and **[4]**.
4. Adjust with **[3]** and **[6]** for the best vertical size.
5. Write into the memory by pressing **MUTING** then **ENTER**.


V. SIZE (VSIZ)




V LINEARITY(VLIN), VS CORRECTION(VSCO), PIN AMP(PAMP), CORNER PIN(CPIN), AND PIN PHASE(PPHA) ADJUSTMENTS

1. Input a cross-hatch signal.
2. Set to Service adjustment Mode.
3. Select VLIN, VSCO, PAMP, CPIN, and PPHA with **[1]** and **[4]**.
4. Adjust with **[3]** and **[6]** for the best picture.
5. Write the memory by Pressing **MUTING** then **ENTER**.


V LINEARITY (VLIN)



VS CORRECTION (VSCO)



PIN AMP (PAMP)



CORNER PIN (CPIN)




PIN PHASE (PPHA)



CROMA TRAP ADJUSTMENT (CROM)

1. Input a red signal
2. Set to Service adjustment Mode.
3. Connect an oscilloscope CN703 Pin① (R OUT) of C board ground.
4. Select CROM with **[1]** and **[4]**.
5. Adjust with **[3]** and **[6]** for the 0 level.




6. Write the memory by pressing **MUTING** then **ENTER**.

5-3. P BOARD ADJUSTMENTS

P IN P H. POSITION (PHPO)

1. Input a color-bar signal
2. Set to Service adjustment Mode.
3. Connect an oscilloscope CN150 Pin③ (Y OUT).
4. Select PHPO with **[1]** and **[4]**.
5. Adjust with **[3]** and **[6]** for the $43.0 \pm 3.0 \mu\text{sec}$ (H).




6. Write the memory by pressing **MUTING** then **ENTER**.

6-1. BLOCK DIAGRAMS (1)

SECTION 6
DIAGRAMS


KV-27TS29/27TS32/27TS36
RM-Y116 RM-Y117 RM-Y118
KV-32TS36/32TS46
RM-Y116 RM-Y118
SA-W200

KV-27TS29/27TS32/27TS36
RM-Y116 RM-Y117 RM-Y118
KV-32TS36/32TS46
RM-Y116 RM-Y118
SA-W200




KV-27TS29/27TS32/27TS36
RM-Y118 RM-Y117 RM-Y118

KV-32TS36/32TS46
RM-Y118 RM-Y118
SA-W200




KV-27TS29/27TS32/27TS36	KV-27TS29/27TS32/27TS36
RM-Y116 RM-Y117 RM-Y118	RM-Y116 RM-Y117 RM-Y118
KV-32TS36/32TS46	KV-32TS36/32TS46
RM-Y116 RM-Y118 SA-W200	RM-Y116 RM-Y118 SA-W200

BLOCK DIAGRAMS (2)



KV-27TS29/27TS32/27TS36
RM-Y116 RM-Y117 RM-Y118

KV-32TS36/32TS46
RM-Y118 RM-Y118
SA-W200



FOR CHECK

CHKCA	1	2	3	4	5	6	7	8	9	10	11
CC H/B	1	2	3	4	5	6	7	8	9	10	11
ABL	1	2	3	4	5	6	7	8	9	10	11
N.C.	1	2	3	4	5	6	7	8	9	10	11
R OUT	1	2	3	4	5	6	7	8	9	10	11
B OUT	1	2	3	4	5	6	7	8	9	10	11
B INT	1	2	3	4	5	6	7	8	9	10	11
B DAT	1	2	3	4	5	6	7	8	9	10	11
B CLK	1	2	3	4	5	6	7	8	9	10	11

CH104
11P
:8T08-S

MTS SAP

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32
MTS SAP	MTS MONO	AFT	DET OUT	AGC MUTE	BAT	C TV L	E	S BAT	S CLK	C DET OUT	MUTE	P TV R	P DET OUT	P TV L	LAT	CLK	ST LEQ	C LAT	AFT SW	C A MUTE	E	STBY 9V	C ANT SW	135V	135V	9V	12V	E	E		

MTS MONO

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32
MTS SAP	MTS MONO	AFT	DET OUT	AGC MUTE	BAT	C TV L	E	S BAT	S CLK	C DET OUT	MUTE	P TV R	P DET OUT	P TV L	LAT	CLK	ST LEQ	C LAT	AFT SW	C A MUTE	E	STBY 9V	C ANT SW	135V	135V	9V	12V	E	E		

ANT SW

1	2	3	4
ANT SW1	E	ANT SW2	9V

ANT SW

1	2	3	4
ANT SW1	E	ANT SW2	9V

MTS SAP

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32
MTS SAP	MTS MONO	AFT	DET OUT	AGC MUTE	BAT	C TV L	E	S BAT	S CLK	C DET OUT	MUTE	P TV R	P DET OUT	P TV L	LAT	CLK	ST LEQ	C LAT	AFT SW	C A MUTE	E	STBY 9V	C ANT SW	135V	135V	9V	12V	E	E		

MTS MONO

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32
MTS SAP	MTS MONO	AFT	DET OUT	AGC MUTE	BAT	C TV L	E	S BAT	S CLK	C DET OUT	MUTE	P TV R	P DET OUT	P TV L	LAT	CLK	ST LEQ	C LAT	AFT SW	C A MUTE	E	STBY 9V	C ANT SW	135V	135V	9V	12V	E	E		

ANT SW

1	2	3	4
ANT SW1	E	ANT SW2	9V

ANT SW


1	2	3	4
ANT SW1	E	ANT SW2	9V

MTS SAP

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32
MTS SAP	MTS MONO	AFT	DET OUT	AGC MUTE	BAT	C TV L	E	S BAT	S CLK	C DET OUT	MUTE	P TV R	P DET OUT	P TV L	LAT	CLK	ST LEQ	C LAT	AFT SW	C A MUTE	E	STBY 9V	C ANT SW	135V	135V	9V	12V	E	E		

MTS MONO

1	2
---	---



FOR CHECK

CHKA	1
CC H/B	2
ABL	3
N.C.	4
R OUT	5
B OUT	6
B INT	7
B INT	8
B DAT	9
B CLK	10

CN104
11P
:BT08-S

1000V	1	1000V	1
200V	2	200V	2
E	3	E	3
N.C.	4	N.C.	4
H1	5	H1	5
H2	6	H2	6

CN105
6P
WHT
:MINI

CN702
6P
WHT
:MINI LOCK

R	1	VCC (9V)	4
B	2	E	5
G	3	IK	6
V	4	SCREEN	7
V	5	V BLK	8

CN703
8P
WHT-L
:S-MICRO

H-DY (+)	1	H-DY (-)	2
H-DY (+)	3	H-DY (-)	4
H-DY (+)	5	H-DY (-)	6
V-DY (+)	7	V-DY (-)	8

CN107
6P
WHT
:BT

KV-32TS36/32TS46

CS1	1
CS1	2
CS2	3
CS2	4
CS3	5
CS3	6
CS4	7
CS4	8
HDR1	9
HDR2	10
E	10
15V	9
15V	8
E	7
E	6
H.P	5
V. BLK	4
S. BAT	3
S. CLK	2

CN108
10P
:BT08-P

CN109
8P
:BT08-P

CN154
5P
WHT-L
:S-MICRO

FRONT L	1
FRONT R	2
FRONT E	3
FRONT V	4
E	5

STBY 5V	1
SIRCS	2
KEY 0	3
POWER	4
TIMER LED	5
STEREO LED	6
9V	7

1	E
2	STBY 5V
3	SIRCS
4	KEY 0
5	POWER
6	TIMER LED
7	STEREO LED
8	9V

CN138
8P
WHT
:S-MICRO

CN129
8P
WHT-L
:S-MICRO

R	1	VCC (9V)	4
B	2	E	5
G	3	IK	6
V	4	SCREEN	7
V	5	V BLK	8

KV-27TS32/27TS36
/32TS36/32TS46
only

KV-32TS46 only

CN149
4P
WHT-L
:S-MICRO

ANT SW1	1
E	2
ANT SW2	3
9V	4

CN141
5P
WHT-L
:S-MICRO

FRONT L	1
FRONT R	2
FRONT E	3
FRONT V	4
E	5

CN143
32P
:BT08-S

CN137
32P
:BT08-P

VO	1	VO	1
V1	2	V1	2
S CLK	3	S CLK	3
S BAT	4	S BAT	4
I-SSW	5	I-SSW	5
E	6	E	6
E	7	E	7
C CH BLOCK	8	C CH BLOCK	8
EXT L	9	EXT L	9
BAT	10	BAT	10
AGC MUTE	11	AGC MUTE	11
BET OUT	12	BET OUT	12
AFT	13	AFT	13
EXT R	14	EXT R	14
MTS MONO	15	MTS MONO	15
MTS SAP	16	MTS SAP	16
E	17	E	17
SET SV	18	SET SV	18
V PULSE	19	V PULSE	19
H PULSE	20	H PULSE	20
C V PULSE	21	C V PULSE	21
YS	22	YS	22
Y	23	Y	23
E	24	E	24
C	25	C	25
VAR L	26	VAR L	26
VAR R	27	VAR R	27
MUTE	28	MUTE	28
V2	29	V2	29
ST LED	30	ST LED	30
CLK	31	CLK	31
LAT	32	LAT	32

M

CN130
20P
:BT08-S

CN115
20P
:BT08-P

R OUT	1	R OUT	1
B OUT	2	B OUT	2
E	3	E	3
L	4	L	4
R	5	R	5
MUTE	6	MUTE	6
E	7	E	7
B INT	8	B INT	8
B BAT	9	B BAT	9
B CLK	10	B CLK	10
BGC CONT	11	BGC CONT	11
SP MUTE	12	SP MUTE	12
S BAT	13	S BAT	13
S CLK	14	S CLK	14
E	15	E	15
STBY 5V	16	STBY 5V	16
9V	17	9V	17
RESET	18	RESET	18
12V	19	12V	19
E	20	E	20

CN131
15P
:BT08-S

CN116
15P
:BT08-P

ABL	1	ABL	1
ABL	2	ABL	2
E	3	E	3
SET SV	4	SET SV	4
RELAY	5	RELAY	5
E	6	E	6
V DRIVE	7	V DRIVE	7
E/W DRIVE	8	E/W DRIVE	8
V BLK	9	V BLK	9
IR 12V	10	IR 12V	10
E	11	E	11
9V	12	9V	12
H DRIVE	13	H DRIVE	13
H PULSE	14	H PULSE	14
VP OUT	15	VP OUT	15

CHK	1
CHK	2

CN112
2P
WHT
:MINI

BGC	1
N.C.	2
BGC	3

CN113
3P
WHT
:MINI

AC IN WHT	1
AC IN	2

CN114
2P
:AC

UA

CN147
32P
:BT08-S

CN144
18P
:BT08-S

CN146
18P
:BT08-S

CN148
18P
:BT08-S

CN149
18P
:BT08-S

CN150
18P
:BT08-P

CN151
18P
:BT08-P

CN152
18P
:BT08-P

CN153
18P
:BT08-P

CN154
18P
:BT08-P

CN155
18P
:BT08-P

CN156
18P
:BT08-P

CN157
18P
:BT08-P

CN158
18P
:BT08-P

CN159
18P
:BT08-P

CN160
18P
:BT08-P

CN161
18P
:BT08-P

CN162
18P
:BT08-P

CN163
18P
:BT08-P

CN164
18P
:BT08-P

CN165
18P
:BT08-P

CN166
18P
:BT08-P

CN167
18P
:BT08-P

CN168
18P
:BT08-P

CN169
18P
:BT08-P

CN170
18P
:BT08-P

CN171
18P
:BT08-P

CN172
18P
:BT08-P

CN173
18P
:BT08-P

CN174
18P
:BT08-P

CN175
18P
:BT08-P

CN176
18P
:BT08-P

CN177
18P
:BT08-P

CN178
18P
:BT08-P

CN179
18P
:BT08-P

CN180
18P
:BT08-P

CN181
18P
:BT08-P

CN182
18P
:BT08-P

CN183
18P
:BT08-P

CN184
18P
:BT08-P

CN185
18P
:BT08-P

CN186
18P
:BT08-P

CN187
18P
:BT08-P

CN188
18P
:BT08-P

CN189
18P
:BT08-P

CN190
18P
:BT08-P

CN191
18P
:BT08-P

CN192
18P
:BT08-P

CN193
18P
:BT08-P

CN194
18P
:BT08-P

CN195
18P
:BT08-P

CN196
18P
:BT08-P

CN197
18P
:BT08-P

CN198
18P
:BT08-P

CN199
18P
:BT08-P

CN200
18P
:BT08-P

CN201
18P
:BT08-P

CN202
18P
:BT08-P

CN203
18P
:BT08-P

CN204
18P
:BT08-P

CN205
18P
:BT08-P

CN206
18P
:BT08-P

CN207
18P
:BT08-P

CN208
18P
:BT08-P

CN209
18P
:BT08-P

CN210
18P
:BT08-P

CN211
18P
:BT08-P

CN212
18P
:BT08-P

CN213
18P
:BT08-P

CN214
18P
:BT08-P

CN215
18P
:BT08-P

CN216
18P
:BT08-P

CN217
18P
:BT08-P

CN218
18P
:BT08-P

CN219
18P
:BT08-P

CN220
18P
:BT08-P

CN221
18P
:BT08-P

CN222
18P
:BT08-P

CN223
18P
:BT08-P

CN224
18P
:BT08-P

CN225
18P
:BT08-P

CN226
18P
:BT08-P

CN227
18P
:BT08-P

CN228
18P
:BT08-P

CN229
18P
:BT08-P

CN230
18P
:BT08-P

CN231
18P
:BT08-P

CN232
18P
:BT08-P

CN233
18P
:BT08-P

CN234
18P
:BT08-P

CN235
18P
:BT08-P

CN236
18P
:BT08-P

CN237
18P
:BT08-P

CN238
18P
:BT08-P

CN239
18P
:BT08-P

CN240
18P
:BT08-P

CN241
18P
:BT08-P

CN242
18P
:BT08-P

CN243
18P
:BT08-P

CN244
18P
:BT08-P

CN245
18P
:BT08-P

CN246
18P
:BT08-P

CN247
18P
:BT08-P

CN248
18P
:BT08-P

CN249
18P
:BT08-P

CN250
18P
:BT08-P

CN251
18P
:BT08-P

CN252
18P
:BT08-P

CN253
18P
:BT08-P

CN254
18P
:BT08-P

CN255
18P
:BT08-P

CN256
18P
:BT08-P

CN257
18P
:BT08-P

CN258
18P
:BT08-P

CN259
18P
:BT08-P

CN260
18P
:BT08-P


CN261
18P
:BT08-P


CN262
18P
:BT08-P

CN263
18P
:BT08-P


CN264
18P
:BT08-P

CN265
18P
:BT08-P





6-3. CIRCUIT BOARDS LOCATION



6-4. PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS

Note:

- All capacitors are in μF unless otherwise noted.
- pF : μF 50WV or less are not indicated except for electrolytic and tantalums.
- All electrolytics are in 50V unless otherwise specified.
- Indication of resistance, which does not have one for rating electrical power, is as follows.

Pitch: 5 mm
Rating electrical power 1/4W

- Chips resistors are 1/10W.
- All resistors are in ohms.
- $\text{k}\Omega=1000\Omega$, $\text{M}\Omega=1000\text{k}\Omega$
- : nonflammable resistor.
- : fusible resistor.
- : internal component.
- : panel designation, and adjustment for repair.
- All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
- : earth-ground. (cool)
- : earth-chassis. (hot)
- The components identified by in this manual have been carefully factory-selected for each set in order to satisfy regulations regarding X-ray radiation.
- Should replacement be required, replace only with the value originally used.
- When replacing components identified by , make the necessary adjustments indicated. If results do not meet the specified value, change the component identified by and repeat the adjustment until the specified value is achieved. (Refer to R511 and R524 on page 41, 42)
- When replacing the part in below table be sure to perform the related adjustment.

Part replaced ()	Adjustment ()
PM501, R511, R632, R645, R650, R338	D BOARD M BOARD HOLD-DOWN (R511)
IC601, PM501, D504, C598, R509, R524, R632, R635, R645, T501, R338	D BOARD M BOARD HOLD-DOWN (R524)

- All voltages are in V.
- Voltage are dc with respect to ground unless otherwise noted.
- Readings are taken with a 10 M Ω digital multimeter.
- Readings are taken with a color-bar signal input.
- Voltage variations may be noted due to normal production tolerance.
- Circled numbers are waveform references.

- : B+ line.
- : B- line.
- : signal path.

Reference information

RESISTOR	: RN	METAL FILM
	: RC	SOLID
	: FPRD	NONFLAMMABLE CARBON
	: FUSE	NONFLAMMABLE FUSIBLE
	: RW	NONFLAMMABLE WIREWOUND
	: RS	NONFLAMMABLE METAL OXIDE
	: RB	NONFLAMMABLE CEMENT
	: *	ADJUSTMENT RESISTOR
COIL	: LF-8L	MICRO INDUCTOR
CAPACITOR	: TA	TANTALUM
	: PS	STYROL
	: PP	POLYPROPYLENE
	: PT	MYLAR
	: MPS	METALIZED POLYESTER
	: MPP	METALIZED POLYPROPYLENE
	: ALB	BIPOLAR
	: ALT	HIGH TEMPERATURE
	: ALR	HIGH RIPPLE


Note: The symbol display is on the component side.

The components identified by shading and mark are critical for safety. Replace only with part number specified.


The symbol indicate fast operating fuse. Replace only with fuse of same rating as marked.

Note: Les composants identifiés par un tramé et une marque sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

Le symbole indique une fusible à action rapide. Doit être remplacée par une fusible de même valeur, comme marqué.



ATION



DS AND
S

ise noted.
ed except for electrolytic
erwise specified.
not have one for rating

ent for repair.
ave characteristic curve
this manual have been
set in order to satisfy
lace only with the value

ied by \square , make the
results do not meet the
ent identified by \square and
ed value is achieved.
(42)
e be sure to perform the

Part replaced (\square)	Adjustment (\square)
PM501, R511, R632, R645, R650, R338	HOLD-DOWN (R511)
IC601, PM501, D504, C598, R509, R524, R632, R635, R645, T501, R338	HOLD-DOWN (R524)

- All voltages are in V.
- Voltage are dc with respect to ground unless otherwise noted.
- Readings are taken with a 10 M Ω digital multimeter.
- Readings are taken with a color-bar signal input.
- Voltage variations may be noted due to normal production tolerance.
- Circled numbers are waveform references.
- \square : B+ line.
- \square : B- line.
- \square : signal path.

Reference information

RESISTOR	: RN	METAL FILM
	: RC	SOLID
	: FPRD	NONFLAMMABLE CARBON
	: FUSE	NONFLAMMABLE FUSIBLE
	: RW	NONFLAMMABLE WIREWOUND
	: RS	NONFLAMMABLE METAL OXIDE
	: RB	NONFLAMMABLE CEMENT
	: *	ADJUSTMENT RESISTOR
COIL	: LF-8L	MICRO INDUCTOR
CAPACITOR	: TA	TANTALUM
	: PS	STYROL
	: PP	POLYPROPYLENE
	: PT	MYLAR
	: MPS	METALIZED POLYESTER
	: MPP	METALIZED POLYPROPYLENE
	: ALB	BIPOLAR
	: ALT	HIGH TEMPERATURE
	: ALR	HIGH RIPPLE


Note: The symbol \square display is on the component side.

The components identified by shading and mark Δ are critical for safety. Replace only with part number specified.


The symbol \square indicate fast operating fuse. Replace only with fuse of same rating as marked.

Note: Les composants identifiés par un tramé et une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.


Le symbole \square indique une fusible a action rapide. Doit être remplacée par une fusible de même yaleur, comme maque.




— A Board —



— C Board —



13 14 15 16 17 18 19 20 21 22 23




KV-27TS29/27TS32/27TS36
RM-Y116 RM-Y117 RM-Y118
KV-32TS36/32TS46
RM-Y116 RM-Y118
SA-W200

KV-27TS29/27TS32/27TS36
RM-Y116 RM-Y117 RM-Y118
KV-32TS36/32TS46
RM-Y116 RM-Y118
SA-W200



A [TUNER, VIF, MTS]

— A Board —



C [R.G.B. OUT]

— C Board —



NOTE:

The circuit indicated as left contains high voltage of over 600 Vp-p. Care must be paid to prevent an electric shock in inspection or repairing.


KV-27TS29/27TS32/27TS36	KV-27TS29/27TS32/27TS36
RM-Y116 RM-Y117 RM-Y118	RM-Y116 RM-Y117 RM-Y118
KV-32TS36/32TS46	KV-32TS36/32TS46
RM-Y118 RM-Y118 SA-W200	RM-Y118 RM-Y118 SA-W200

UA [AV SW, AV INPUT, AV OUTPUT]


— UA Board —

IC	
IC401	C-5
IC402	C-6
IC403	B-9
IC404	A-8
TRANSISTOR	
Q401	D-1
Q405	E-8
Q406	D-8
Q410	A-4
Q414	B-6
Q415	E-2
Q416	F-1
Q417	E-1
Q418	E-1
DIODE	
D401	D-2
D402	D-3
D405	C-4
D408	D-2
D436	B-5
D437	B-5


— UA Board —




UA Board IC401 M5470AP









UA Board IC403 MM114XFF




UA Board IC404 MM118XFF






<p>①</p>  <p>2.2 V_{p-p} (H)</p>	<p>②</p>  <p>2.3 V_{p-p} (H)</p>	<p>③</p>  <p>2.6 V_{p-p} (H)</p>
<p>④</p>  <p>2.4 V_{p-p} (H)</p>	<p>⑤</p>  <p>2.6 V_{p-p} (H)</p>	






— UA Board —





	KV-32TS46	KV-27TS36 KV-32TS36	KV-27TS32	KV-27TS29
C401	0.01 F: CHIP	0.01 F: CHIP	0.01 F: CHIP	-
C405	22 25V	22 25V	22 25V	-
C406	1	1	1	-
C407	1	1	1	-
C408	22 25V	22 25V	22 25V	-
C411	-	-	100 25V	100 25V
C420	0.01 F: CHIP	0.01 F: CHIP	0.01 F: CHIP	-
C421	22 25V	22 25V	0.47	-
C427	JW (5)	JW (5)	JW (5)	-
C428	JW (5)	JW (5)	JW (5)	-
C429	JW (5)	JW (5)	JW (5)	-
C430	1	-	-	-
C431	1	-	-	-
C432	22 25V	-	-	-
C433	33 25V	33 25V	-	-
C434	100P : CHIP	100P : CHIP	-	-
C440	10	10	-	-
C442	100P : CHIP	100P : CHIP	-	-
CN141	5P WHT-L : S-MICRO	5P WHT-L : S-MICRO	5P WHT-L : S-MICRO	-
CN144	6P WHT-L : S-MICRO	-	-	-
CN146	18P : BT08-S	18P : BT08-S	-	-
CN149	4P WHT-L : S-MICRO	-	-	-
D401	RD10ESB	RD10ESB	RD10ESB	-
D405	RD10ESB	RD10ESB	RD10ESB	-
D408	RD10ESB	RD10ESB	RD10ESB	-
D436	RD10ESB	RD10ESB	-	-
D437	RD10ESB	RD10ESB	-	-
IC401	-	-	M52470AP	M52470AP
IC402	CXA1545AS	CXA1545AS	-	-
IC403	-	-	M1114XFF	-
IC404	-	-	M1118XFF	-
J401	S TERMINAL BLOCK	S TERMINAL BLOCK	S TERMINAL BLOCK	PIN JACK BLOCK
J402	PIN JACK BLOCK	PIN JACK BLOCK	PIN JACK BLOCK	-
J403	-	-	PIN JACK BLOCK	-
JR400	-	-	0 : CHIP	0 : CHIP
JR401	-	-	0 : CHIP	0 : CHIP
JR415	0 : CHIP	0 : CHIP	0 : CHIP	-
JR419	0 : CHIP	0 : CHIP	0 : CHIP	-
JW403	10M	-	-	-
L401	18uH : FLR50	18uH : FLR50	-	-
L403	33uH : FLR50	33uH : FLR50	-	-
L404	JW (5)	JW (5)	-	-
L405	JW (5)	JW (5)	-	-
L452	JW (5)	-	-	-
L453	JW (5)	-	-	-
Q410	2SD601A	-	-	-
Q414	2SD601A	2SD601A	-	-
Q415	2SD601A	-	-	-
Q416	2SB709A	-	-	-
Q417	2SB709A	-	-	-
Q418	2SB709A	-	-	-
R401	75 : CHIP	75 : CHIP	75 : CHIP	-
R407	75 : CHIP	75 : CHIP	75 : CHIP	-
R408	470K : CHIP	470K : CHIP	470K : CHIP	-
R409	470K : CHIP	470K : CHIP	470K : CHIP	-
R410	4.7K	4.7K	4.7K	-
R411	4.7K	4.7K	4.7K	-
R414	75 : CHIP	75 : CHIP	75 : CHIP	-
R415	4.7K : CHIP	4.7K : CHIP	4.7K : CHIP	-
R417	560 : RN-CP	560 : RN-CP	470 : RN-CP	470 : RN-CP
R418	-	-	100 : CHIP	100 : CHIP
R420	JW (5)	JW (5)	JW (5)	-
R422	JW (5)	JW (5)	JW (5)	-
R431	1K : CHIP	1K : CHIP	680 : CHIP	1K : CHIP
R432	0 : CHIP	0 : CHIP	680 : CHIP	0 : CHIP
R434	1K : CHIP	1K : CHIP	680 : CHIP	1K : CHIP
R435	0 : CHIP	0 : CHIP	680 : CHIP	0 : CHIP
R440	-	-	100 : CHIP	-
R442	-	-	100 : CHIP	100 : CHIP
R443	-	-	100 : CHIP	100 : CHIP
R444	82K : CHIP	82K : CHIP	82K : CHIP	-
R445	10K : CHIP	10K : CHIP	-	-
R446	10K : CHIP	10K : CHIP	-	-
R450	470 : CHIP	470 : CHIP	100 : CHIP	100 : CHIP
R451	4.7K : CHIP	4.7K : CHIP	-	-
R452	100 : CHIP	-	-	-
R453	-	-	820 : RN-CP	820 : RN-CP
R454	0 : CHIP	0 : CHIP	100 : CHIP	100 : CHIP
R456	470 : CHIP	470 : CHIP	-	-
R457	220 : CHIP	220 : CHIP	-	-
R458	220 : CHIP	220 : CHIP	-	-
R459	22K : CHIP	-	-	-
R460	330 : CHIP	-	-	-
R461	4.7K : CHIP	-	-	-
R462	4.7K : CHIP	-	-	-
R463	680 : CHIP	-	-	-
R464	680 : CHIP	-	-	-
R475	1K : CHIP	1K : CHIP	-	-
R476	22K : CHIP	-	-	-
R477	-	-	1K : CHIP	1K : CHIP
R478	470 : CHIP	470 : CHIP	-	-
R479	22K : CHIP	-	-	-
R480	22K : CHIP	-	-	-
R481	22K : CHIP	-	-	-
R488	22K : CHIP	-	-	-
R489	22K : CHIP	-	-	-
R490	0 : CHIP	0 : CHIP	-	-
R491	0 : CHIP	0 : CHIP	-	-
R492	0 : CHIP	0 : CHIP	-	-



B-554439<U>...P..


— P Board —





B-SS4439(U...)-P..


- P Board -



KV-27TS29/27TS32/27TS36
RM-Y118 RM-Y117 RM-Y118

KV-32TS36/32TS46
RM-Y118 RM-Y118
SA-W200

— E Board —



V-27TS29/27TS32/27TS36
RM-Y116 RM-Y117 RM-Y118
V-32TS36/32TS46
RM-Y116 RM-Y118 SA-W200


KV-27TS29/27TS32/27TS36
RM-Y116 RM-Y117 RM-Y118
KV-32TS36/32TS46
RM-Y116 RM-Y118 SA-W200

KV-27TS29/27TS32/27TS36
RM-Y116 RM-Y117 RM-Y118
KV-32TS36/32TS46
RM-Y116 RM-Y118 SA-W200


7 8 9 10 11 12

E [DYNAMIC CONVERGENCE]


— E Board —



E <DYNAMIC CONVERGENCE>



— E Board —




KV-27TS29/27TS32/27TS36
RM-Y116 RM-Y117 RM-Y118



KV-32TS36/32TS46
RM-Y118 RM-Y118
SA-W200

KV-27TS29/27TS32/27TS36	KV-27TS29/27TS32/27
RM-Y116 RM-Y117 RM-Y118	RM-Y116 RM-Y117 RI
KV-32TS36/32TS46	KV-32TS36/32TS46
RM-Y118 RM-Y118 SA-W200	RM-Y118 RM-Y118 SA-W200


M Board IC150 MC144143





M Board IC301 CXA1465AS



H [USER CONTROL]
— H Board —




7 8




KV-27TS29/27TS32/27TS36
RM-Y116 RM-Y117 RM-Y118
KV-32TS36/32TS46
RM-Y116 RM-Y118
SA-W200

KV-27TS29/27TS32/27TS36
RM-Y116 RM-Y117 RM-Y118
KV-32TS36/32TS46
RM-Y116 RM-Y118
SA-W200


M Board IC150 MC144143



M Board IC202 LM358PS




M Board IC301 CXA1465AS



— M Board —


— M Board —


IC	DIODE
IC101 C-3	D001 E-3
IC102 B-2	D002 E-3
IC150 B-4	D004 F-4
IC201 C-7	D005 D-2
IC202 G-7	D006 B-2
IC301 C-5	D007 B-2
	D008 B-2
	D009 B-2
	D150 C-4
	D201 J-7
	D202 I-7
	D205 C-7
	D206 B-6
	D301 B-5
	D304 B-5
	D305 F-5
	D306 F-4
TRANSISTOR	
Q001 F-3	
Q002 D-4	
Q004 C-2	
Q005 C-2	
Q151 D-4	
Q201 A-7	
Q301 I-6	
Q302 I-6	
Q307 G-4	
Q308 F-5	
Q314 E-4	




M Y/C/J, CONTROL, AUDIO CONTROL,
CLOSED CAPTION


— M Board —










D Board IC602 L78LR05D




— D Board —












— D Board —






— D Board —


IC		
IC501	B-5	D603 B-13
IC504	D-5	D605 E-13
IC601	D-10	D607 F-12
IC602	E-10	D608 A-10
IC604	D-7	D609 A-10
IC605	B-8	D610 A-10
IC606	A-7	D611 A-10
IC610	G-12	D612 B-9
IC2200	I-11	D613 B-9
		D614 D-10
		D615 C-9
		D616 C-9
		D617 C-9
		D618 D-10
		D619 D-10
		D622 D-11
		D623 D-10
		D624 E-10
		D626 D-10
		D627 D-9
		D628 E-9
		D629 F-9
		D630 F-9
		D631 F-8
		D632 F-8
		D633 C-9
		D634 C-9
		D635 D-9
		D636 D-11
		D637 F-12
		D638 F-12
		D2201 H-8
TRANSISTOR		
Q502	A-2	
Q503	D-4	
Q505	D-5	
Q591	F-1	
Q601	B-12	
Q602	C-12	
Q603	F-12	
Q604	D-10	
Q605	D-9	
Q611	F-12	
Q613	D-9	
Q614	E-10	
Q2202	F-10	
Q2203	G-10	
DIODE		
D501	F-3	
D502	H-5	
D503	F-5	
D504	F-5	
D505	G-4	
D506	E-2	
D507	E-2	
D508	C-2	
D509	D-4	
D510	C-1	
D511	C-1	
D512	D-7	
D513	A-5	
D514	E-6	
D515	D-6	
D601	E-13	
D602	D-14	
TEST POINT		
TP82	E-4	
TP84	F-1	
TP85	I-8	
TP90	A-9	
TP91	D-8	
TP92	B-8	
TP93	A-7	
TP94	D-7	
TP95	E-10	
TP96	G-4	
TP97	F-3	
TP98	G-5	
TP99	F-5	



NOTE:
The circuit indicated as left contains high voltage of over 600 Vp-p. Care must be paid to prevent an electric shock in inspection or repairing.



7 8 9 10 11 12 13 14 15 16 17 18 19



SUPER WOOFER

— SUPER WOOFER Board —

KV-27TS29/27TS32/27TS36

RM-Y116 RM-Y117 RM-Y118

KV-32TS36/32TS46


RM-Y116 RM-Y118
SA-W200

KV-27TS29/27TS32/27TS36

RM-Y116 RM-Y117 RM-Y118

KV-32TS36/32TS46

RM-Y116 RM-Y118
SA-W200




KV-27TS29/27TS32/27TS36
RM-Y116 RM-Y117 RM-Y118
KV-32TS36/32TS46
RM-Y116 RM-Y118
SA-W200


KV-27TS29/27TS32/27TS36
RM-Y116 RM-Y117 RM-Y118
KV-32TS36/32TS46
RM-Y116 RM-Y118
SA-W200

6-5. SEMICONDUCTORS


BU4053BF
CXA1315M




LM358PS
MM1114XFF
MM1118XFF




MB86144




TDA2009A




2SA1175
2SA1309A
2SC2785-HFE
2SC3311A




2SC3271F



Ø4SB60L
RBA-402LF-A



HVU359-TRU




CXA1465AS
CXA1545AS




LM7805CT
LM7812CT
MC7809CT
RC7809FA



MC144143
Z86128120PSC




TDA8172




2SB1370
2SC4159
2SB2012
2SB2061




2SC4834MNP




Ø5SC4MR



MA110
1T33



CXA1526P




L78LR05Ø-MA




M5233L




TDA8429




2SB709A
2SB601A




2SC4927



EGR20G
EGR20G-TKG23
EL1Z
ERA81-004TP1
G08Ø
RGP02-17
RGP02-17PKG23
RGP10GPK23
ISS176




SHOR3Ø42




CXP80424-SV4397



MB3512PF-EF




M52470AP




TS7SU04F



µPC78L05T




NJM2068S




2SB734
2SB774



Ø1NS4
Ø1N20R
ERA15-02
ERA82-004
ERA83-006
RØ10ESB
RØ10ESB2
RØ12ESB3
RØ13ESB
RØ13ESB2
RØ33ESB1
RØ33ESB2
RØ3.6ESB1
RØ5.1ESB
RØ5.1ESB1
RØ8.2ESB3
RØ9R1ES
ISS119




ERC06-15S
RU-3AM
S2L20UF
S3V105S



ØM-48
PM-38
PM-39



MB40176PF-EF



SBX1618-51




2SA1091
2SA1091R




2SC2060




LM358P
µPC358C
µPC393C
24C02A1/P



MB81461-12-PSZ-G-BF2



TA8225L




2SA1048
2SA2458




2SC2688



Ø2S4MF
Ø2S4MTA1



ERØ29-Ø8J



SECTION 7

EXPLODED VIEWS

NOTE:

- Items with no part number and no description are not stocked because they are seldom required for routine service.
- The construction parts of an assembled part are indicated with a collation number in the remark column.
- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.


The components identified by shading and mark Δ are critical for safety.
Replace only with part number specified.

Les composants identifiés par une trame et une marque Δ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

7-1. CHASSIS

Δ : BVTP4x12 7-685-661-14

■: BVTP4x16 7-685-663-79



REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
1	4-394-048-01	EMBLEM (NO.9), SONY		15	*A-1306-433-A	M BOARD, COMPLETE (KV-32TS46 (CND))	
2	4-039-458-01	FILTER, REMOTE		15	*A-1306-434-A	M BOARD, COMPLETE (KV-32TS46 (US))	
3	4-039-457-01	GUIDE, LED		16	*A-1341-622-A	E BOARD, COMPLETE (KV-32TS46/32TS36)	
4	4-039-525-01	BUTTON, MULTI		17	*A-1394-415-A	UA BOARD, COMPLETE (KV-32TS36/27TS36)	
5	*1-646-717-11	H BOARD		17	*A-1394-441-A	UA BOARD, COMPLETE (KV-27TS32)	
6	4-319-520-11	SCREW, SPECIAL (+PW4X30)		17	*A-1394-437-A	UA BOARD, COMPLETE (KV-27TS29)	
7	*A-1346-112-A	D BOARD, COMPLETE (KV-32TS46/32TS36)		17	*A-1394-435-A	UA BOARD, COMPLETE (KV-32TS46)	
7	*A-1346-129-A	D BOARD, COMPLETE (KV-27TS36/27TS32/27TS29)		18	*A-1195-062-A	P BOARD, COMPLETE (KV-32TS46/32TS36/27TS36)	
8	Δ 1-453-146-11	TRANSFORMER ASSY, FLYBACK (NX-2604A3)		19	4-039-517-01	TERMINAL BOARD, ANTENNA (KV-32TS46)	
9	*A-1297-065-A	A BOARD, COMPLETE (KV-32TS36/27TS36/27TS32/27TS29)		19	4-039-524-01	TERMINAL BOARD, ANTENNA (KV-32TS36/27TS36/27TS29/27TS29)	
9	*A-1297-112-A	A BOARD, COMPLETE (KV-32TS46)		20	4-040-090-01	LABEL, TERMINAL (KV-27TS32)	
10	Δ 8-598-039-00	TUNER BTF-WA401		20	4-039-903-01	LABEL, TERMINAL (KV-27TS29)	
11	Δ 8-598-047-00	TUNER BTF-WA401		20	4-039-834-01	LABEL, TERMINAL (KV-32TS46/32TS36/27TS36)	
12	*1-751-136-11	CABLE, PIN (KV-32TS46)		21	4-382-854-11	SCREW (M3X10), P, SW (+)	
13	*1-751-135-11	CABLE, PIN (KV-32TS46)		22	1-573-657-11	PLUG, P-PIN (KV-32TS36/27TS36/27TS29/27TS29)	
14	1-417-178-11	SELECTOR, ANTENNA (AS-2) (KV-32TS46)		23	1-751-059-11	CORD, POWER (WITH CONNECTOR) 10A/120V	
15	*A-1306-427-A	M BOARD, COMPLETE (KV-32TS36/27TS36/27TS32/27TS29 (US))		24	4-039-463-01	COVER, REAR (KV-27TS36/27TS29/27TS29)	
15	*A-1306-432-A	M BOARD, COMPLETE (KV-32TS36 (CND)/27TS36 (CND)/27TS32/27TS29 (CND))		24	4-039-634-01	COVER, REAR (KV-32TS36/32TS36)	

KV-27TS29/27TS32/27TS36

RM-Y116 RM-Y117 RM-Y118

KV-32TS36/32TS46


RM-Y118 RM-Y118
SA-W200

Les composants identifiés par une trame et une
marque Δ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le
numéro spécifié.

The components identified by shading and mark Δ
are critical for safety.
Replace only with part number specified.


7-2. PICTURE TUBE

■ : BVTP4x16 7-685-663-79



REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
51	X-4031-018-1	GRILLE ASSY, SPEAKER (KV-32TS46/32TS36)		62	3-704-495-01	SPACER, DY (KV-32TS46/32TS36)	
51	X-4031-029-1	GRILLE ASSY, SPEAKER (KV-27TS36/27TS32/27TS29)		63	Δ 1-451-315-41	DEFLECTION YOKE (Y34FXA) (KV-32TS46/32TS36)	
52	X-4031-039-1	BEZNET ASSY (KV-27TS36)	53	63	Δ 1-451-275-41	DEFLECTION YOKE (Y34FXA) (KV-27TS36/27TS32/27TS29)	
52	X-4031-038-2	BEZNET ASSY (KV-27TS32)	53	64	*A-1331-264-A	C BOARD, COMPLETE	
52	X-4031-026-1	BEZNET ASSY (KV-27TS29)	53	65	4-036-329-01	SPRING (B), TENSION (KV-27TS36/27TS32/27TS29)	
52	X-4031-019-1	BEZNET ASSY (KV-32TS36)	53	66	Δ 1-402-952-11	COIL, DEMAGNETIZATION (KV-32TS46/32TS36)	
52	X-4031-019-2	BEZNET ASSY (KV-32TS46)	53	67	*4-371-629-01	STOPPER, WIRE (KV-32TS46/32TS36)	
53	4-039-462-01	DOOR, CONTROL (KV-32TS36/27TS36)		68	4-033-681-01	HOLDER, LEAD (KV-32TS46/32TS36)	
53	4-039-462-11	DOOR, CONTROL (KV-27TS32)		69	4-387-204-01	NUT, SPECIAL, PICTURE TUBE (KV-32TS46/32TS36)	
53	4-039-459-01	PANEL (KV-27TS29)		70	1-406-726-11	COIL, DEGAUSSING (KV-27TS36/27TS32/27TS29)	
53	4-039-462-21	DOOR, CONTROL (KV-32TS46)		71	4-040-388-01	HOLDER(S), DGC (KV-27TS36/27TS32/27TS29)	
54	1-544-549-11	SPEAKER		72	4-040-537-01	HOLDER(A), DGC (KV-27TS36/27TS32/27TS29)	
55	4-388-477-01	SCREW(3X16), TAPPING, +BV WASHER		73	4-040-387-01	HOLDER(M), DGC (KV-27TS36/27TS32/27TS29)	
56	*4-031-428-01	SUPPORT (RIGHT) (PICTURE TUBE) (KV-32TS46/32TS36)		74	4-308-870-00	CLIP, LEAD WIRE	
57	*4-031-430-01	SUPPRT (LEFT) (PICTURE TUBE) (KV-32TS46/32TS36)		75	1-452-032-00	MAGNET, DISK	
58	4-031-429-01	BRACKET, PICTURE TUBE		76	1-452-094-00	MAGNET, ROTATABLE; 15MM ϕ	
59	Δ 8-733-723-05	PICTURE TUBE (A80JYV50X) (KV-32TS46/32TS36)		77	X-4306-312-0	PERMALLOY ASSY, CONVERGENCE	
59	Δ 8-733-838-05	PICTURE TUBE (A68KZJ50X) (KV-27TS36/27TS32/27TS29)					
60	4-390-505-01	SCREW(7), TAPPING (KV-27TS36/27TS32/27TS29)					
61	*3-704-372-01	HOLDER, HV CABLE (KV-27TS36/27TS32/27TS29)					

7-3. SPEAKER (KV-32TS46 (US/CND))



The components identified by shading and mark **▲** are critical for safety. Replace only with part number specified.

Les composants identifiés par une trame et une marque **▲** sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	RE MARK
101	9-904-749-01	VOLUME NOB		102	108	9-900-278-01	SPEAKER
102	9-904-748-01	FELT WASHER		109	9-904-754-01	AMP KIT (TWY1019-A)	
103	9-904-745-01	FRONT CASE	104	110	▲ 9-904-752-01	FUSE	
104	9-904-747-01	ENCLOSURE SEALANT TUBE		111	9-904-744-01	CABINET	112
105	▲ 9-904-751-01	TRANSFORMER, POWER		112	9-904-746-01	ENCLOSURE SEALANT PACKING	
106	▲ 9-904-750-01	CORD, POWER		113	4-040-527-01	FOOT	
107	▲ 9-904-753-01	AC OUTLET					

KV-27TS29/27TS32/27TS36

RM-Y116 RM-Y117 RM-Y118

KV-32TS36/32TS46

RM-Y118 RM-Y118
SA-W200

SECTION 8

ELECTRICAL PARTS LIST

P

NOTE:

The components identified by shading and mark Δ are critical for safety.
Replace only with part number specified.

Les composants identifiés par une trame et une marque Δ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

• Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

• All variable and adjustable resistors have characteristic curve B, unless otherwise noted.

RESISTORS

• All resistors are in ohms
• F: nonflammable

When indicating parts by reference number, please include the board name.

CAPACITORS

MF: μ F, PF: μ F

COILS

MMH: mH, UH: μ H

• The components identified by Δ in this manual have been carefully factory-selected for each set in order to satisfy regulations regarding X-ray radiation.

Should replacement be required, replace only with the value originally used.

REF. NO.	PART NO.	DESCRIPTION	REMARK	REF. NO.	PART NO.	DESCRIPTION	REMARK
*A-1195-062-A P BOARD, COMPLETE (KV-32TS36/32TS46 /27TS36)				C3249	1-163-117-00	CERAMIC CHIP 100PF	5% 50V
<CAPACITOR>				C3250	1-163-113-00	CERAMIC CHIP 68PF	5% 50V
C3201	1-124-477-11	ELECT 47MF	20% 16V	C3251	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V
C3203	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V	C3252	1-163-103-00	CERAMIC CHIP 27PF	5% 50V
C3204	1-124-907-11	ELECT 10MF	20% 50V	C3253	1-163-101-00	CERAMIC CHIP 22PF	5% 50V
C3205	1-124-907-11	ELECT 10MF	20% 50V	C3254	1-163-141-00	CERAMIC CHIP 0.001MF	5% 50V
C3206	1-124-907-11	ELECT 10MF	20% 50V	C3255	1-163-101-00	CERAMIC CHIP 22PF	5% 50V
C3207	1-163-117-00	CERAMIC CHIP 100PF	5% 50V	C3256	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V
C3208	1-163-117-00	CERAMIC CHIP 100PF	5% 50V	C3257	1-163-117-00	CERAMIC CHIP 100PF	5% 50V
C3209	1-123-382-00	ELECT 3.3MF	20% 50V	C3258	1-163-113-00	CERAMIC CHIP 68PF	5% 50V
C3210	1-124-477-11	ELECT 47MF	20% 16V	C3259	1-163-111-00	CERAMIC CHIP 56PF	5% 50V
C3212	1-123-382-00	ELECT 3.3MF	20% 50V	C3260	1-163-119-00	CERAMIC CHIP 120PF	5% 50V
C3213	1-164-346-11	CERAMIC CHIP 1MF	16V	C3261	1-163-141-00	CERAMIC CHIP 0.001MF	5% 50V
C3214	1-164-346-11	CERAMIC CHIP 1MF	16V	C3263	1-163-141-00	CERAMIC CHIP 0.001MF	5% 50V
C3215	1-164-346-11	CERAMIC CHIP 1MF	16V	C3264	1-165-319-11	CERAMIC CHIP 0.1MF	50V
C3216	1-164-005-11	CERAMIC CHIP 0.47MF	25V	C3265	1-163-141-00	CERAMIC CHIP 0.001MF	5% 50V
C3217	1-164-346-11	CERAMIC CHIP 1MF	16V	C3266	1-163-141-00	CERAMIC CHIP 0.001MF	5% 50V
C3218	1-164-346-11	CERAMIC CHIP 1MF	16V	C3267	1-163-141-00	CERAMIC CHIP 0.001MF	5% 50V
C3219	1-126-103-11	ELECT 470MF	20% 16V	C3268	1-163-141-00	CERAMIC CHIP 0.001MF	5% 50V
C3220	1-164-346-11	CERAMIC CHIP 1MF	16V	C3269	1-163-141-00	CERAMIC CHIP 0.001MF	5% 50V
C3221	1-164-346-11	CERAMIC CHIP 1MF	16V	C3270	1-165-319-11	CERAMIC CHIP 0.1MF	50V
C3222	1-164-336-11	CERAMIC CHIP 0.33MF	25V	C3271	1-165-319-11	CERAMIC CHIP 0.1MF	50V
C3223	1-164-336-11	CERAMIC CHIP 0.33MF	25V	C3272	1-165-319-11	CERAMIC CHIP 0.1MF	50V
C3224	1-164-222-11	CERAMIC CHIP 0.22MF	25V	C3273	1-163-109-00	CERAMIC CHIP 47PF	5% 50V
C3225	1-164-222-11	CERAMIC CHIP 0.22MF	25V	C3274	1-163-101-00	CERAMIC CHIP 22PF	5% 50V
C3226	1-164-005-11	CERAMIC CHIP 0.47MF	25V	C3275	1-163-101-00	CERAMIC CHIP 22PF	5% 50V
C3227	1-164-346-11	CERAMIC CHIP 1MF	16V	C3276	1-163-111-00	CERAMIC CHIP 56PF	5% 50V
C3228	1-163-117-00	CERAMIC CHIP 100PF	5% 50V	C3277	1-163-101-00	CERAMIC CHIP 22PF	5% 50V
C3229	1-163-093-00	CERAMIC CHIP 10PF	5% 50V	C3278	1-163-101-00	CERAMIC CHIP 22PF	5% 50V
C3230	1-163-141-00	CERAMIC CHIP 0.001MF	5% 50V	C3279	1-163-141-00	CERAMIC CHIP 0.001MF	5% 50V
C3231	1-163-125-00	CERAMIC CHIP 220PF	5% 50V	C3280	1-124-907-11	ELECT 10MF	20% 50V
C3232	1-163-117-00	CERAMIC CHIP 100PF	5% 50V	C3282	1-164-346-11	CERAMIC CHIP 1MF	16V
C3233	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V	<CONNECTOR>			
C3234	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V	CN150	1-573-297-11	CONNECTOR, BOARD TO BOARD 18P	
C3235	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V	<DIODE>			
C3236	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V	D3202	8-719-031-68	DIODE HVU359-TRU	
C3237	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V	D3203	8-719-404-46	DIODE MA110	
C3238	1-163-101-00	CERAMIC CHIP 22PF	5% 50V	D3208	8-719-110-17	DIODE RD10ESB2	
C3239	1-163-141-00	CERAMIC CHIP 0.001MF	5% 50V	D3209	8-719-110-17	DIODE RD10ESB2	
C3240	1-163-101-00	CERAMIC CHIP 22PF	5% 50V	<IC>			
C3241	1-163-103-00	CERAMIC CHIP 27PF	5% 50V	IC3200	8-759-517-74	IC MB81461-12-PSZ-G-BF2	
C3242	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V	IC3201	8-759-093-29	IC MB86144	
C3243	1-163-117-00	CERAMIC CHIP 100PF	5% 50V	IC3202	8-759-093-28	IC MB40176PF-EF	
C3244	1-163-113-00	CERAMIC CHIP 68PF	5% 50V	IC3203	8-759-093-28	IC MB40176PF-EF	
C3245	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V	IC3204	8-759-093-26	IC MB3512PF-EF	
C3246	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V				
C3247	1-163-033-00	CERAMIC CHIP 0.022MF	50V				
C3248	1-163-125-00	CERAMIC CHIP 220PF	5% 50V				

V-27TS29/27TS32/27TS36

RM-Y116 RM-Y117 RM-Y118

V-32TS36/32TS46

RM-Y118 RM-Y118
SA-W200

Les composants identifiés par une
trame et une marque Δ sont
critiques pour la sécurité.
Ne les remplacer que par une pièce
portant le numéro spécifié.

The components identified by
shading and mark Δ are critical
for safety.
Replace only with part number
specified.

REF. NO.	PART NO.	DESCRIPTION	REMARK	REF. NO.	PART NO.	DESCRIPTION	REMARK
<CONNECTOR>				*****			
CN103	*1-564-519-11	PLUG, CONNECTOR 4P		*A-1306-427-A	M BOARD, COMPLETE		
CN151	*1-573-979-11	CONNECTOR, BOARD TO BOARD 11P			(KV-32TS36(US)/27TS36(US)/27TS32/27TS29(US))		
CN152	1-750-394-11	PIN, CONNECTOR (STAKING) 32P		*A-1306-432-A	M BOARD, COMPLETE		
CN164	*1-564-505-11	PLUG, CONNECTOR 2P			(KV-32TS36(CND)/27TS36(CND)/27TS29(CND))		
CN165	*1-564-505-11	PLUG, CONNECTOR 2P		*A-1306-433-A	M BOARD, COMPLETE (KV-32TS46(CND))		
<DIODE>					(KV-32TS46(US))		
D170	8-719-110-78	DIODE RD33ESB2		*A-1306-434-A	M BOARD, COMPLETE (KV-32TS46(US))		
D175	8-719-110-76	DIODE RD33ESB1	(KV-32TS46)		(KV-32TS46(US))		
<IC>				<CAPACITOR>			
IC172	8-759-932-67	IC BU4053BF	(KV-32TS46)	C002	1-163-809-11	CERAMIC CHIP 0.047MF	10% 25V
<COIL>				C003	1-163-001-11	CERAMIC CHIP 220PF	10% 50V
L170	1-408-408-00	INDUCTOR 8.2UH		C005	1-163-125-00	CERAMIC CHIP 220PF	5% 50V
L171	1-408-408-00	INDUCTOR 8.2UH		C006	1-163-125-00	CERAMIC CHIP 220PF	5% 50V
L172	1-408-408-00	INDUCTOR 8.2UH		C007	1-124-903-11	ELECT 1MF	20% 50V
L173	1-408-408-00	INDUCTOR 8.2UH	(KV-32TS46)	C008	1-163-125-00	CERAMIC CHIP 220PF	5% 50V
<TRANSISTOR>				C009	1-163-125-00	CERAMIC CHIP 220PF	5% 50V
Q172	8-729-422-36	TRANSISTOR 2SB709A-Q	(KV-32TS46)	C010	1-163-125-00	CERAMIC CHIP 220PF	5% 50V
Q173	8-729-422-36	TRANSISTOR 2SB709A-Q	(KV-32TS46)	C012	1-163-125-00	CERAMIC CHIP 220PF	5% 50V
<RESISTOR>				C013	1-163-125-00	CERAMIC CHIP 220PF	5% 50V
R170	1-216-025-00	METAL GLAZE 100 5% 1/10W		C014	1-163-125-00	CERAMIC CHIP 220PF	5% 50V
		(KV-32TS36/27TS36/27TS32/27TS29)		C015	1-163-125-00	CERAMIC CHIP 220PF	5% 50V
R173	1-216-295-00	METAL GLAZE 0 5% 1/10W		C016	1-163-125-00	CERAMIC CHIP 220PF	5% 50V
		(KV-32TS46)		C017	1-163-125-00	CERAMIC CHIP 220PF	5% 50V
R174	1-216-689-11	METAL GLAZE 39K 5% 1/10W		C018	1-163-125-00	CERAMIC CHIP 220PF	5% 50V
R175	1-215-900-11	METAL OXIDE 22K 5% 2W F		C019	1-163-125-00	CERAMIC CHIP 220PF	5% 50V
		(KV-32TS46)		C021	1-163-125-00	CERAMIC CHIP 220PF	5% 50V
R176	1-216-295-00	METAL GLAZE 0 5% 1/10W		C022	1-163-125-00	CERAMIC CHIP 220PF	5% 50V
		(KV-32TS36/27TS36/27TS32/27TS29)		C023	1-163-125-00	CERAMIC CHIP 220PF	5% 50V
R177	1-215-900-11	METAL OXIDE 22K 5% 2W F		C025	1-163-125-00	CERAMIC CHIP 220PF	5% 50V
		(KV-32TS46)		C028	1-163-125-00	CERAMIC CHIP 220PF	5% 50V
R179	1-216-065-00	METAL GLAZE 4.7K 5% 1/10W		C029	1-163-125-00	CERAMIC CHIP 220PF	5% 50V
R181	1-216-025-00	METAL GLAZE 100 5% 1/10W		C034	1-163-125-00	CERAMIC CHIP 220PF	5% 50V
		(KV-32TS46)		C035	1-163-125-00	CERAMIC CHIP 220PF	5% 50V
R185	1-216-025-00	METAL GLAZE 100 5% 1/10W		C041	1-163-009-11	CERAMIC CHIP 0.001MF	10% 50V
		(KV-32TS46)		C043	1-163-159-00	CERAMIC CHIP 12PF	2% 50V
R187	1-216-083-00	METAL GLAZE 27K 5% 1/10W		C045	1-124-119-00	ELECT 330MF	20% 16V
R188	1-216-689-11	METAL GLAZE 39K 5% 1/10W		C047	1-104-896-91	CERAMIC CHIP 24PF	2% 50V
		(KV-32TS46)		C049	1-163-125-00	CERAMIC CHIP 220PF	5% 50V
R189	1-216-083-00	METAL GLAZE 27K 5% 1/10W		C050	1-163-125-00	CERAMIC CHIP 220PF	5% 50V
		(KV-32TS46)		C051	1-163-031-11	CERAMIC CHIP 0.01MF	5% 50V
R190	1-216-065-00	METAL GLAZE 4.7K 5% 1/10W		C052	1-163-125-00	CERAMIC CHIP 220PF	5% 50V
		(KV-32TS46)		C053	1-163-121-00	CERAMIC CHIP 150PF	5% 50V
R191	1-216-065-00	METAL GLAZE 4.7K 5% 1/10W		C054	1-163-125-00	CERAMIC CHIP 220PF	5% 50V
		(KV-32TS46)		C055	1-163-125-00	CERAMIC CHIP 220PF	5% 50V
R193	1-216-037-00	METAL GLAZE 330 5% 1/10W		C056	1-163-125-00	CERAMIC CHIP 220PF	5% 50V
		(KV-32TS46)		C057	1-163-017-00	CERAMIC CHIP 0.0047MF	10% 50V
R196	1-216-037-00	METAL GLAZE 330 5% 1/10W		C058	1-163-037-11	CERAMIC CHIP 0.022MF	10% 25V
		(KV-32TS46)		C059	1-163-125-00	CERAMIC CHIP 220PF	5% 50V
<TUNER>				C060	1-124-903-11	ELECT 1MF	20% 50V
TU101A	8-598-039-00	TUNER BTF-WA401		C061	1-163-117-00	CERAMIC CHIP 100PF	5% 50V
TU102A	8-598-047-00	TUNER BTF-WA401	(KV-32TS46)	C062	1-124-907-11	ELECT 10MF	20% 50V
				C150	1-136-165-00	FILM 0.1MF 5% 50V	(KV-32TS46(US)/32TS36(US))
				C151	1-136-175-00	FILM 0.068MF 5% 50V	(KV-32TS46(US)/32TS36(US))

M

REF. NO.	PART NO.	DESCRIPTION	REMARK	REF. NO.	PART NO.	DESCRIPTION	REMARK
C152	1-124-907-11	ELECT	10MF 20% 50V (KV-32TS46(US)/32TS36(US))	<CONNECTOR>			
C153	1-137-367-11	FILM	0.0033MF 5% 50V (KV-32TS46(US)/32TS36(US))	CN129	*1-564-523-11	PLUG, CONNECTOR 8P	
C154	1-163-038-00	CERAMIC CHIP	0.1MF 25V (KV-32TS46(US)/32TS36(US))	CN130	1-573-301-11	CONNECTOR, BOARD TO BOARD 20P	
C155	1-124-907-11	ELECT	10MF 20% 50V (KV-32TS46(US)/32TS36(US))	CN131	*1-691-632-11	CONNECTOR, BOARD TO BOARD 15P	
C156	1-163-135-00	CERAMIC CHIP	560PF 5% 50V (KV-32TS46(US)/32TS36(US))	CN134	*1-564-521-11	PLUG, CONNECTOR 6P	(KV-32TS46)
C157	1-163-038-00	CERAMIC CHIP	0.1MF 25V (KV-32TS46(US)/32TS36(US))	CN137	1-750-394-11	PIN, CONNECTOR (STAKING) 32P	
C158	1-124-903-11	ELECT	1MF 20% 50V (KV-32TS46(US)/32TS36(US))	CN138	*1-564-511-31	PLUG, CONNECTOR 8P	
C160	1-124-903-11	ELECT	1MF 20% 50V	CN168	*1-564-505-11	PLUG, CONNECTOR 2P	
C201	1-163-017-00	CERAMIC CHIP	0.0047MF 10% 50V	<DIODE>			
C202	1-163-125-00	CERAMIC CHIP	220PF 5% 50V	D001	8-719-404-46	DIODE MA110	
C203	1-163-989-11	CERAMIC CHIP	0.033MF 10% 25V	D002	8-719-404-46	DIODE MA110	(KV-32TS46(US))
C204	1-126-101-11	ELECT	100MF 20% 16V	D004	8-719-404-46	DIODE MA110	
C205	1-163-125-00	CERAMIC CHIP	220PF 5% 50V	D005	8-713-300-57	DIODE 1T33	
C211	1-163-989-11	CERAMIC CHIP	0.033MF 10% 25V	D006	8-719-110-17	DIODE RD10ESB2	
C212	1-124-902-00	ELECT	0.47MF 20% 50V	D007	8-719-110-17	DIODE RD10ESB2	
C213	1-124-902-00	ELECT	0.47MF 20% 50V	D008	8-719-110-17	DIODE RD10ESB2	
C214	1-163-017-00	CERAMIC CHIP	0.0047MF 10% 50V	D009	8-719-110-17	DIODE RD10ESB2	
C216	1-124-478-11	ELECT	100MF 20% 25V	D150	8-719-404-46	DIODE MA110 (KV-32TS46(US)/32TS36(US))	
C301	1-163-117-00	CERAMIC CHIP	100PF 5% 50V	D201	8-719-404-46	DIODE MA110	
C305	1-124-907-11	ELECT	10MF 20% 50V	D202	8-719-404-46	DIODE MA110	
C306	1-124-902-00	ELECT	0.47MF 20% 50V	D205	8-719-110-17	DIODE RD10ESB2	
C307	1-163-125-00	CERAMIC CHIP	220PF 5% 50V	D206	8-719-110-17	DIODE RD10ESB2	
C308	1-163-099-00	CERAMIC CHIP	18PF 5% 50V	D301	8-719-110-17	DIODE RD10ESB2	
C310	1-124-916-11	ELECT	22MF 20% 25V	D304	8-719-110-17	DIODE RD10ESB2	
C311	1-124-903-11	ELECT	1MF 20% 50V	<IC>			
C313	1-163-003-11	CERAMIC CHIP	330PF 10% 50V	IC101	8-752-841-16	IC CXP80424-SV4397	
C315	1-124-907-11	ELECT	10MF 20% 50V (KV-32TS46(US))	IC102	8-759-057-38	IC 24C02A1/P	
C316	1-124-907-11	ELECT	10MF 20% 50V (KV-32TS46(US))	IC150	8-759-084-09	IC Z8612812PSC	(KV-32TS46(US)/32TS36(US))
C317	1-124-907-11	ELECT	10MF 20% 50V (KV-32TS46(US))	IC201	8-759-090-21	IC TDA8424	
C318	1-136-165-00	FILM	0.1MF 5% 50V	IC202	8-759-983-69	IC UPC358PS	
C319	1-136-165-00	FILM	0.1MF 5% 50V	IC301	8-752-059-67	IC CXA1465AS	
C320	1-136-165-00	FILM	0.1MF 5% 50V	<JUMPER RESISTOR>			
C321	1-124-360-00	ELECT	1000MF 20% 16V	JR200	1-216-295-00	METAL GLAZE 0 5% 1/10W	
C322	1-136-153-00	FILM	0.01MF 5% 50V	<COIL>			
C323	1-126-176-11	ELECT	220MF 20% 10V	L001	1-410-470-11	INDUCTOR 10UH	
C324	1-163-003-11	CERAMIC CHIP	330PF 10% 50V	L002	1-408-414-00	INDUCTOR 27UH	
C325	1-163-037-11	CERAMIC CHIP	0.022MF 10% 25V	L150	1-410-470-11	INDUCTOR 10UH	(KV-32TS46(US)/32TS36(US))
C326	1-136-169-00	FILM	0.22MF 5% 50V	<TRANSISTOR>			
C327	1-136-169-00	FILM	0.22MF 5% 50V	Q001	8-729-422-36	TRANSISTOR 2SB709A-Q	
C328	1-124-902-00	ELECT	0.47MF 20% 50V	Q002	8-729-422-36	TRANSISTOR 2SB709A-Q	
C329	1-124-903-11	ELECT	1MF 20% 50V	Q004	8-729-422-36	TRANSISTOR 2SB709A-Q	
C330	1-124-907-11	ELECT	10MF 20% 50V	Q005	8-729-422-27	TRANSISTOR 2SD601A-Q	
C331	1-124-907-11	ELECT	10MF 20% 50V	Q151	8-729-422-27	TRANSISTOR 2SD601A-Q	(KV-32TS46(US)/32TS36(US))
C332	1-164-489-11	CERAMIC CHIP	0.22MF 10% 16V	Q201	8-729-422-27	TRANSISTOR 2SD601A-Q	
C333	1-163-011-11	CERAMIC CHIP	0.0015MF 10% 50V	Q301	8-729-422-36	TRANSISTOR 2SB709A-Q	
C334	1-124-902-00	ELECT	0.47MF 20% 50V	Q302	8-729-422-36	TRANSISTOR 2SB709A-Q	
C335	1-163-001-11	CERAMIC CHIP	220PF 10% 50V	Q307	8-729-422-27	TRANSISTOR 2SD601A-Q	
C336	1-124-903-11	ELECT	1MF 20% 50V	Q308	8-729-422-27	TRANSISTOR 2SD601A-Q	
C337	1-124-902-00	ELECT	0.47MF 20% 50V				
C338	1-136-153-00	FILM	0.01MF 5% 50V				
C340	1-124-903-11	ELECT	1MF 20% 50V				
C341	1-163-005-11	CERAMIC CHIP	470PF 10% 50V				
C342	1-137-414-91	FILM	0.0047MF 10% 100V				

V-27TS29/27TS32/27TS36

RM-Y116 RM-Y117 RM-Y118

V-32TS36/32TS46

RM-Y118 RM-Y118
SA-W200

M

REF. NO.	PART NO.	DESCRIPTION	REMARK	REF. NO.	PART NO.	DESCRIPTION	REMARK
<RESISTOR>				R074	1-216-295-00	METAL GLAZE 0 5% 1/10W	
R002	1-216-073-00	METAL GLAZE 10K 5% 1/10W		R075	1-216-295-00	METAL GLAZE 0 5% 1/10W	
R003	1-216-033-00	METAL GLAZE 220 5% 1/10W		R076	1-216-295-00	METAL GLAZE 0 5% 1/10W	
R004	1-216-033-00	METAL GLAZE 220 5% 1/10W		R078	1-216-073-00	METAL GLAZE 10K 5% 1/10W	
R005	1-216-033-00	METAL GLAZE 220 5% 1/10W		R079	1-216-295-00	METAL GLAZE 0 5% 1/10W	
R006	1-216-049-00	METAL GLAZE 1K 5% 1/10W		R080	1-216-073-00	METAL GLAZE 10K 5% 1/10W	
R007	1-216-033-00	METAL GLAZE 220 5% 1/10W		R082	1-216-073-00	METAL GLAZE 10K 5% 1/10W	
R008	1-216-033-00	METAL GLAZE 220 5% 1/10W		R083	1-216-089-00	METAL GLAZE 47K 5% 1/10W	
R009	1-216-033-00	METAL GLAZE 220 5% 1/10W		R086	1-216-089-00	METAL GLAZE 47K 5% 1/10W	
R011	1-216-033-00	METAL GLAZE 220 5% 1/10W		R087	1-216-049-00	METAL GLAZE 1K 5% 1/10W	
R012	1-216-033-00	METAL GLAZE 220 5% 1/10W		R089	1-216-083-00	METAL GLAZE 27K 5% 1/10W	
R013	1-216-033-00	METAL GLAZE 220 5% 1/10W		R090	1-216-073-00	METAL GLAZE 10K 5% 1/10W	
R016	1-216-033-00	METAL GLAZE 220 5% 1/10W		R091	1-216-073-00	METAL GLAZE 10K 5% 1/10W	
R017	1-216-033-00	METAL GLAZE 220 5% 1/10W		R092	1-216-073-00	METAL GLAZE 10K 5% 1/10W	
R018	1-216-033-00	METAL GLAZE 220 5% 1/10W		R093	1-216-295-00	METAL GLAZE 0 5% 1/10W	
R019	1-216-033-00	METAL GLAZE 220 5% 1/10W		R150	1-216-097-00	METAL GLAZE 100K 5% 1/10W (KV-32TS46(US)/32TS36(US))	
R020	1-216-033-00	METAL GLAZE 220 5% 1/10W		R151	1-216-049-00	METAL GLAZE 1K 5% 1/10W (KV-32TS46(US)/32TS36(US))	
RC21	1-216-073-00	METAL GLAZE 10K 5% 1/10W		R152	1-216-049-00	METAL GLAZE 1K 5% 1/10W (KV-32TS46(US)/32TS36(US))	
R022	1-216-073-00	METAL GLAZE 10K 5% 1/10W		R153	1-216-069-00	METAL GLAZE 6.8K 5% 1/10W (KV-32TS46(US)/32TS36(US))	
R023	1-216-033-00	METAL GLAZE 220 5% 1/10W		R154	1-216-041-00	METAL GLAZE 470 5% 1/10W (KV-32TS46(US)/32TS36(US))	
R025	1-216-033-00	METAL GLAZE 220 5% 1/10W		R155	1-216-049-00	METAL GLAZE 1K 5% 1/10W (KV-32TS46(US)/32TS36(US))	
R026	1-216-097-00	METAL GLAZE 100K 5% 1/10W		R156	1-216-073-00	METAL GLAZE 10K 5% 1/10W	
R027	1-216-121-00	METAL GLAZE 1M 5% 1/10W		R157	1-216-073-00	METAL GLAZE 10K 5% 1/10W (KV-32TS46(US)/32TS36(US))	
R028	1-216-073-00	METAL GLAZE 10K 5% 1/10W		R158	1-216-073-00	METAL GLAZE 10K 5% 1/10W (KV-32TS46(US)/32TS36(US))	
R029	1-216-065-00	METAL GLAZE 4.7K 5% 1/10W		R159	1-216-049-00	METAL GLAZE 1K 5% 1/10W (KV-32TS46(US)/32TS36(US))	
R030	1-216-073-00	METAL GLAZE 10K 5% 1/10W		R160	1-216-049-00	METAL GLAZE 1K 5% 1/10W (KV-32TS46(US)/32TS36(US))	
R031	1-216-033-00	METAL GLAZE 220 5% 1/10W		R161	1-216-049-00	METAL GLAZE 1K 5% 1/10W (KV-32TS46(US)/32TS36(US))	
R032	1-216-033-00	METAL GLAZE 220 5% 1/10W		R162	1-216-065-00	METAL GLAZE 4.7K 5% 1/10W (KV-32TS46(US)/32TS36(US))	
R033	1-216-033-00	METAL GLAZE 220 5% 1/10W		R163	1-216-065-00	METAL GLAZE 4.7K 5% 1/10W (KV-32TS46(US)/32TS36(US))	
R034	1-216-033-00	METAL GLAZE 220 5% 1/10W		R164	1-216-065-00	METAL GLAZE 4.7K 5% 1/10W (KV-32TS46(US)/32TS36(US))	
R035	1-216-033-00	METAL GLAZE 220 5% 1/10W		R165	1-216-065-00	METAL GLAZE 4.7K 5% 1/10W (KV-32TS46(US)/32TS36(US))	
R036	1-216-033-00	METAL GLAZE 220 5% 1/10W		R166	1-216-049-00	METAL GLAZE 1K 5% 1/10W (KV-32TS46(US)/32TS36(US))	
R037	1-216-033-00	METAL GLAZE 220 5% 1/10W		R168	1-216-049-00	METAL GLAZE 1K 5% 1/10W (KV-32TS46(US)/32TS36(US))	
R038	1-216-033-00	METAL GLAZE 220 5% 1/10W		R201	1-216-073-00	METAL GLAZE 10K 5% 1/10W	
R039	1-216-295-00	METAL GLAZE 0 5% 1/10W		R202	1-216-073-00	METAL GLAZE 10K 5% 1/10W	
R040	1-216-049-00	METAL GLAZE 1K 5% 1/10W		R203	1-216-089-00	METAL GLAZE 47K 5% 1/10W	
R041	1-216-033-00	METAL GLAZE 220 5% 1/10W		R204	1-216-089-00	METAL GLAZE 47K 5% 1/10W	
R042	1-216-049-00	METAL GLAZE 1K 5% 1/10W		R205	1-216-295-00	METAL GLAZE 0 5% 1/10W	
R043	1-216-049-00	METAL GLAZE 1K 5% 1/10W		R206	1-216-295-00	METAL GLAZE 0 5% 1/10W	
R044	1-216-065-00	METAL GLAZE 4.7K 5% 1/10W		R207	1-216-085-00	METAL GLAZE 33K 5% 1/10W	
R045	1-216-065-00	METAL GLAZE 4.7K 5% 1/10W		R208	1-216-089-00	METAL GLAZE 47K 5% 1/10W	
R046	1-216-065-00	METAL GLAZE 4.7K 5% 1/10W		R209	1-216-085-00	METAL GLAZE 33K 5% 1/10W	
R047	1-216-065-00	METAL GLAZE 4.7K 5% 1/10W		R210	1-216-089-00	METAL GLAZE 47K 5% 1/10W	
R048	1-216-073-00	METAL GLAZE 10K 5% 1/10W		R211	1-216-033-00	METAL GLAZE 220 5% 1/10W	
R049	1-216-049-00	METAL GLAZE 1K 5% 1/10W		R212	1-216-025-00	METAL GLAZE 100 5% 1/10W	
R050	1-216-049-00	METAL GLAZE 1K 5% 1/10W		R213	1-216-025-00	METAL GLAZE 100 5% 1/10W	
R051	1-216-073-00	METAL GLAZE 10K 5% 1/10W		R218	1-216-073-00	METAL GLAZE 10K 5% 1/10W	
R052	1-216-065-00	METAL GLAZE 4.7K 5% 1/10W					
R053	1-216-049-00	METAL GLAZE 1K 5% 1/10W					
R054	1-216-049-00	METAL GLAZE 1K 5% 1/10W					
R055	1-216-033-00	METAL GLAZE 220 5% 1/10W (KV-32TS46)					
R058	1-216-073-00	METAL GLAZE 10K 5% 1/10W					
R059	1-216-065-00	METAL GLAZE 4.7K 5% 1/10W					
R061	1-216-077-00	METAL GLAZE 15K 5% 1/10W					
R062	1-216-057-00	METAL GLAZE 2.2K 5% 1/10W					
R063	1-216-033-00	METAL GLAZE 220 5% 1/10W (KV-32TS46)					
R064	1-216-065-00	METAL GLAZE 4.7K 5% 1/10W					
R065	1-216-065-00	METAL GLAZE 4.7K 5% 1/10W					
R066	1-216-025-00	METAL GLAZE 100 5% 1/10W					
R067	1-216-025-00	METAL GLAZE 100 5% 1/10W					
R069	1-216-033-00	METAL GLAZE 220 5% 1/10W (KV-32TS46)					

The components identified by shading and mark Δ are critical for safety.
Replace only with part number specified.

Les composants identifiés par une trame et une marque Δ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.


M **C**

REF. NO.	PART NO.	DESCRIPTION	REMARK	REF. NO.	PART NO.	DESCRIPTION	REMARK
R219	1-216-073-00	METAL GLAZE	10K 5% 1/10W	C707	1-102-129-00	CERAMIC	0.01MF 10% 50V
R220	1-216-033-00	METAL GLAZE	220 5% 1/10W	C711	1-164-083-11	CERAMIC	680PF 10% 50V
R222	1-216-089-00	METAL GLAZE	47K 5% 1/10W	C712	1-164-081-11	CERAMIC	470PF 10% 50V
R223	1-216-045-00	METAL GLAZE	680 5% 1/10W	C731	1-164-083-11	CERAMIC	680PF 10% 50V
R301	1-216-025-00	METAL GLAZE	100 5% 1/10W	C732	1-164-081-11	CERAMIC	470PF 10% 50V
R302	1-216-049-00	METAL GLAZE	1K 5% 1/10W	C751	1-164-083-11	CERAMIC	680PF 10% 50V
R303	1-216-065-00	METAL GLAZE	4.7K 5% 1/10W	C752	1-164-083-11	CERAMIC	680PF 10% 50V
R306	1-216-057-00	METAL GLAZE	2.2K 5% 1/10W	<CONNECTOR>			
R312	1-216-119-00	METAL GLAZE	820K 5% 1/10W	CN701	1-695-915-11	TAB (CONTACT)	
R313	1-216-079-00	METAL GLAZE	18K 5% 1/10W	CN702	*1-508-768-00	PIN, CONNECTOR (5MM PITCH) 6P	
R321	1-216-041-00	METAL GLAZE	470 5% 1/10W	CN703	*1-564-511-11	PLUG, CONNECTOR 8P	
R323	1-216-041-00	METAL GLAZE	470 5% 1/10W	<DIODE>			
R324	1-216-041-00	METAL GLAZE	470 5% 1/10W	D711	8-719-911-19	DIODE 1SS119	
R327	1-216-653-11	METAL CHIP	1.2K 0.50% 1/10W	D712	8-719-911-19	DIODE 1SS119	
R328	1-216-033-00	METAL GLAZE	220 5% 1/10W	D731	8-719-911-19	DIODE 1SS119	
R329	1-216-033-00	METAL GLAZE	220 5% 1/10W	D732	8-719-911-19	DIODE 1SS119	
R330	1-216-295-00	METAL GLAZE	0 5% 1/10W	D751	8-719-911-19	DIODE 1SS119	
R331	1-216-678-11	METAL CHIP	13K 0.50% 1/10W	D752	8-719-911-19	DIODE 1SS119	
R332	1-216-057-00	METAL GLAZE	2.2K 5% 1/10W	D770	8-719-911-19	DIODE 1SS119	
R333	1-216-025-00	METAL GLAZE	100 5% 1/10W	D771	8-719-911-19	DIODE 1SS119	
R334	1-216-687-11	METAL CHIP	33K 0.50% 1/10W	D772	8-719-911-19	DIODE 1SS119	
R335	1-216-121-00	METAL GLAZE	1M 5% 1/10W	D773	8-719-911-19	DIODE 1SS119	
R336	1-216-295-00	METAL GLAZE	0 5% 1/10W	D777	8-719-109-68	DIODE RD3.6ESB1	
R337	1-216-049-00	METAL GLAZE	1K 5% 1/10W	D790	8-719-911-19	DIODE 1SS119	
R338	1-249-417-11	CARBON	1K 5% 1/4W F	D791	8-719-911-19	DIODE 1SS119	
R339	1-216-049-00	METAL GLAZE	1K 5% 1/10W	D792	8-719-911-19	DIODE 1SS119	
R340	1-216-077-00	METAL GLAZE	15K 5% 1/10W	D793	8-719-911-19	DIODE 1SS119	
R341	1-216-085-00	METAL GLAZE	33K 5% 1/10W	D794	8-719-911-19	DIODE 1SS119	
R342	1-216-295-00	METAL GLAZE	0 5% 1/10W	D795	8-719-911-19	DIODE 1SS119	
R343	1-216-053-00	METAL GLAZE	1.5K 5% 1/10W	<SOCKET>			
R344	1-216-043-00	METAL GLAZE	560 5% 1/10W	J701	Δ 1-540-071-13	SOCKET, PICTURE TUBE	
R345	1-216-109-00	METAL GLAZE	330K 5% 1/10W	<COIL>			
R346	1-216-071-00	METAL GLAZE	8.2K 5% 1/10W	L701	1-410-478-11	INDUCTOR	47UH
R347	1-249-409-91	CARBON	220 5% 1/4W F	<TRANSISTOR>			
R348	1-216-097-00	METAL GLAZE	100K 5% 1/10W	Q711	8-729-926-73	TRANSISTOR 2SC3271-N	
R349	1-216-089-00	METAL GLAZE	47K 5% 1/10W	Q712	8-729-119-78	TRANSISTOR 2SC2785-HFE	
R350	1-216-089-00	METAL GLAZE	47K 5% 1/10W	Q731	8-729-926-73	TRANSISTOR 2SC3271-N	
R351	1-216-065-00	METAL GLAZE	4.7K 5% 1/10W	Q732	8-729-119-78	TRANSISTOR 2SC2785-HFE	
R352	1-216-089-00	METAL GLAZE	47K 5% 1/10W	Q751	8-729-926-73	TRANSISTOR 2SC3271-N	
R353	1-216-089-00	METAL GLAZE	47K 5% 1/10W	Q752	8-729-119-78	TRANSISTOR 2SC2785-HFE	
R354	1-216-033-00	METAL GLAZE	220 5% 1/10W	Q770	8-729-119-76	TRANSISTOR 2SA1175-HFE	
R356	1-216-295-00	METAL GLAZE	0 5% 1/10W	Q771	8-729-200-17	TRANSISTOR 2SA1071-0	
R374	1-216-033-00	METAL GLAZE	220 5% 1/10W	Q772	8-729-200-17	TRANSISTOR 2SA1071-0	
R375	1-216-033-00	METAL GLAZE	220 5% 1/10W	Q773	8-729-200-17	TRANSISTOR 2SA1071-0	
<CRYSTAL>				Q790	8-729-119-78	TRANSISTOR 2SC2785-HFE	
X001	1-579-917-21	VIBRATOR, CRYSTAL		<RESISTOR>			
X001	1-579-917-41	VIBRATOR, CRYSTAL		R700	1-247-739-11	CARBON	100 5% 1/2W
X301	1-567-505-11	OSCILLATOR, CRYSTAL		R701	1-244-941-00	CARBON	680K 5% 1/2W
*****				R702	1-249-496-11	CARBON	100K 5% 1/2W
*A-1331-264-A C BOARD, COMPLETE				R703	1-249-496-11	CARBON	100K 5% 1/2W
*****				R704	1-216-398-11	METAL OXIDE	5.6 5% 3W
<CAPACITOR>							
C700	1-102-074-00	CERAMIC	0.001MF 10% 50V				
C701	1-162-114-00	CERAMIC	0.0047MF 2KV				
C702	1-106-375-12	MYLAR	0.022MF 99% 200V				
C703	1-106-375-12	MYLAR	0.022MF 99% 200V				
C704	1-162-116-00	CERAMIC	680PF 10% 2KV				
C705	1-123-946-00	ELECT	4.7MF 20% 250V				
C706	1-126-101-11	ELECT	100MF 20% 16V				

RM-Y116 RM-Y117 RM-Y118

BM-Y11A BM-Y11B

C | E

Les composants identifiés par une trame et une marque  sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifique.

The components identified by shading and mark **A** are critical for safety.
Replace only with part number specified.

REF.NO.	PART NO.	DESCRIPTION	REMARK				REF.NO.	PART NO.	DESCRIPTION	REMARK			
R705	1-216-398-11	METAL OXIDE	5.6	5%	3W	F	C1532	1-124-477-11	ELECT	47MF	20%	16V	
R706	1-214-921-00	CARBON	220K	5%	1/2W		C1533	1-124-916-11	ELECT	22MF	20%	25V	
R710	1-247-758-11	CARBON	3.3K	5%	1/2W		C1542	1-124-477-11	ELECT	47MF	20%	16V	
R711	1-249-405-11	CARBON	100	5%	1/4W		C1550	1-136-756-11	FILM	0.24MF	5%	200V	
R712	1-215-924-00	METAL OXIDE	15K	5%	3W	F							
R714	1-249-425-11	CARBON	4.7K	5%	1/4W				<CONNECTOR>				
R716	1-249-417-11	CARBON	1K	5%	1/4W								
R717	1-249-393-11	CARBON	10	5%	1/4W		CN122	*1-573-299-11	CONNECTOR, BOARD TO BOARD	10P			
R718	1-249-413-11	CARBON	470	5%	1/4W		CN123	*1-573-299-11	CONNECTOR, BOARD TO BOARD	10P			
R730	1-247-758-11	CARBON	3.3K	5%	1/2W								
R731	1-249-405-11	CARBON	100	5%	1/4W				<DIODE>				
R732	1-215-924-00	METAL OXIDE	15K	5%	3W	F	D1501	8-719-911-19	DIODE	ISS119			
R734	1-249-425-11	CARBON	4.7K	5%	1/4W		D1502	8-719-801-35	THYRISTOR	SHOR3D42			
R736	1-249-411-11	CARBON	330	5%	1/4W		D1503	8-719-980-78	DIODE	ERA83-006			
R737	1-249-393-11	CARBON	10	5%	1/4W		D1504	8-719-300-33	DIODE	RU-3AM			
							D1505	8-719-911-19	DIODE	ISS119			
R750	1-247-758-11	CARBON	3.3K	5%	1/2W		D1506	8-719-911-19	DIODE	ISS119			
R751	1-249-405-11	CARBON	100	5%	1/4W		D1507	8-719-911-19	DIODE	ISS119			
R752	1-215-924-00	METAL OXIDE	15K	5%	3W	F	D1508	8-719-110-17	DIODE	RD10ESB2			
R754	1-249-425-11	CARBON	4.7K	5%	1/4W		D1509	8-719-110-17	DIODE	RD10ESB2			
R756	1-249-411-11	CARBON	330	5%	1/4W		D1510	8-719-911-19	DIODE	ISS119			
R757	1-249-393-11	CARBON	10	5%	1/4W		D1513	8-719-300-33	DIODE	RU-3AM			
R770	1-249-433-11	CARBON	22K	5%	1/4W		D1515	8-719-911-19	DIODE	ISS119			
R771	1-249-409-91	CARBON	220	5%	1/4W	F	D1516	8-719-913-44	DIODE	ERA82-004			
R772	1-249-409-91	CARBON	220	5%	1/4W	F	D1517	8-719-911-19	DIODE	ISS119			
R773	1-249-409-91	CARBON	220	5%	1/4W	F							
									<IC>				
R774	1-249-437-11	CARBON	47K	5%	1/4W		IC1501	8-752-052-88	IC	CXA1526P			
R775	1-249-417-11	CARBON	1K	5%	1/4W	F	IC1502	8-759-982-10	IC	RC7809FA			
R776	1-249-409-91	CARBON	220	5%	1/4W	F	IC1504	8-759-135-80	IC	UPC358C			
R790	1-249-413-11	CARBON	470	5%	1/4W								
R791	1-249-412-11	CARBON	390	5%	1/4W								
									<COIL>				
R792	1-249-424-11	CARBON	3.9K	5%	1/4W		L1502	1-459-592-11	COIL (WITH CORE)	(PMC)			
R794	1-249-424-11	CARBON	3.9K	5%	1/4W		L1504	1-459-474-11	COIL (WITH CORE)				
R796	1-249-424-11	CARBON	3.9K	5%	1/4W								
R798	1-249-437-11	CARBON	47K	5%	1/4W								
R799	1-249-437-11	CARBON	47K	5%	1/4W								

The components identified by shading and mark Δ are critical for safety.
Replace only with part number specified.

Les composants identifiés par une trame et une marque Δ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

E

D

REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
R1511	1-216-379-11	METAL OXIDE	6.8 5% 2W F	C524	1-102-212-00	CERAMIC	820PF 10% 500V
R1513	1-249-423-11	CARBON	3.3K 5% 1/4W	C525	1-124-902-00	ELECT	0.47MF 20% 50V
R1514	1-247-885-00	CARBON	180K 5% 1/4W	C526	1-106-395-00	MYLAR	0.15MF 10% 200V
R1515	1-215-905-11	METAL OXIDE	10 5% 3W F	C527	1-124-341-00	ELECT	1MF 20% 200V
R1519	1-249-417-11	CARBON	1K 5% 1/4W	C528	1-136-113-00	FILM	2MF 5% 200V
R1520	1-249-417-11	CARBON	1K 5% 1/4W	C529	1-137-410-11	FILM	0.001MF 10% 100V
R1522	1-249-417-11	CARBON	1K 5% 1/4W F	C530	1-104-770-11	FILM	0.62MF 5% 200V
R1527	1-249-417-11	CARBON	1K 5% 1/4W	C530	1-104-844-11	CAP. FILM (S)	0.62MF
R1528	1-249-438-11	CARBON	56K 5% 1/4W	C531	1-124-477-11	ELECT	47MF 20% 25V
R1529	1-249-434-11	CARBON	27K 5% 1/4W	C532	1-136-165-00	FILM	0.1MF 5% 50V
R1530	1-249-432-11	CARBON	18K 5% 1/4W	C533	1-124-927-11	ELECT	4.7MF 20% 50V
R1533	1-249-427-11	CARBON	6.8K 5% 1/4W	C534	1-136-161-00	FILM	0.047MF 5% 50V
R1534	1-249-424-11	CARBON	3.9K 5% 1/4W	C535	1-124-911-11	ELECT	220MF 20% 50V
R1535	1-249-425-11	CARBON	4.7K 5% 1/4W	C536	1-137-421-91	FILM	0.068MF 10% 100V
R1536	1-215-857-11	METAL OXIDE	10 5% 1W F	C538	1-136-161-00	FILM	0.047MF 5% 50V
R1537	1-249-404-00	CARBON	82 5% 1/4W	C540	1-137-366-11	FILM	0.0022MF 5% 50V
R1538	1-216-379-11	METAL OXIDE	6.8 5% 2W F	C541	1-137-366-11	FILM	0.0022MF 5% 50V
R1541	1-249-441-11	CARBON	100K 5% 1/4W	C542	1-130-481-00	FILM	0.0068MF 5% 50V
R1543	1-249-414-11	CARBON	560 5% 1/4W	C545	1-124-927-11	ELECT	4.7MF 20% 50V
R1546	1-215-885-00	METAL OXIDE	68 5% 2W F	C547	1-164-079-11	CERAMIC	330PF 10% 50V
R1552	1-249-426-11	CARBON	5.6K 5% 1/4W	C548 Δ	1-162-116-91	CERAMIC	680PF 10% 2KV
R1554	1-249-393-11	CARBON	10 5% 1/4W	C550	1-106-387-00	MYLAR	0.068MF 10% 200V
R1556	1-249-438-11	CARBON	56K 5% 1/4W	C553	1-164-079-11	CERAMIC	330PF 10% 50V
R1559	1-249-429-11	CARBON	10K 5% 1/4W	C561	1-162-815-11	CERAMIC	47PF 5% 500V
R1564	1-249-435-11	CARBON	33K 5% 1/4W	C595	1-123-932-00	ELECT	4.7MF 20% 160V
R1568	1-247-891-00	CARBON	330K 5% 1/4W	C598	1-124-342-00	ELECT	3.3MF 20% 160V
R1569	1-249-413-11	CARBON	470 5% 1/4W	C600	1-124-907-11	ELECT	10MF 20% 50V
R1578	1-249-423-11	CARBON	3.3K 5% 1/4W	C601 Δ	1-136-311-51	FILM	0.47MF 20% 125V
R1582	1-249-411-11	CARBON	330 5% 1/4W	C602 Δ	1-136-311-51	FILM	0.47MF 20% 125V
R1583	1-249-421-11	CARBON	2.2K 5% 1/4W	C603 Δ	1-136-311-51	FILM	0.47MF 20% 125V
R1585	1-249-441-11	CARBON	100K 5% 1/4W	C604 Δ	1-162-578-81	CERAMIC	0.0047MF 20% 400V
R1586	1-247-891-00	CARBON	330K 5% 1/4W	C607	1-104-757-11	ELECT	470MF 20% 200V
*****				C608	1-104-757-11	ELECT	470MF 20% 200V
*A-1346-112-A	D BOARD, COMPLETE (KV-27TS36/27TS32 /27TS29)			C609	1-136-169-00	FILM	0.22MF 5% 50V
*A-1346-129-A	D BOARD, COMPLETE (KV-32TS46/32TS36)			C610	1-136-169-00	FILM	0.22MF 5% 50V
1-533-223-11	CLIP, FUSE			C611	1-136-169-00	FILM	0.22MF 5% 50V
4-382-854-11	SCREW (M3X10), P, SW (+)			C612	1-136-169-00	FILM	0.22MF 5% 50V
<CAPACITOR>				C613	1-164-625-11	CERAMIC	680PF 10% 500V
C501	1-124-557-11	ELECT	1000MF 20% 25V	C614	1-164-625-11	CERAMIC	680PF 10% 500V
C502	1-162-131-11	CERAMIC	220PF 10% 2KV	C616	1-124-907-11	ELECT	10MF 20% 50V
C503	1-124-557-11	ELECT	1000MF 20% 25V	C617	1-124-618-11	ELECT	2200MF 20% 35V
C504	1-137-366-11	FILM	0.0022MF 5% 50V	C618	1-124-557-11	ELECT	1000MF 20% 25V
C505	1-124-916-11	ELECT	22MF 20% 25V	C619	1-124-360-00	ELECT	1000MF 20% 16V
C506	1-124-929-11	ELECT	22MF 20% 100V	C620	1-164-644-11	CERAMIC	330PF 10% 500V
C507	1-124-046-00	ELECT	10MF 20% 160V	C621	1-126-356-11	ELECT	220MF 20% 160V
C509	1-124-916-11	ELECT	22MF 20% 25V	C623	1-162-117-00	CERAMIC	100PF 10% 500V
C511	1-123-024-21	ELECT	33MF 160V	C624	1-136-487-81	FILM	0.015MF 5% 50V
C512	1-102-212-00	CERAMIC	820PF 10% 500V	C625	1-129-744-91	FILM	0.027MF 10% 400V
C513	1-102-212-00	CERAMIC	820PF 10% 500V	C626	1-124-478-11	ELECT	100MF 20% 25V
C514	1-102-244-00	CERAMIC	220PF 10% 500V	C627	1-124-443-00	ELECT	100MF 20% 10V
C515	1-137-416-11	FILM	0.01MF 10% 100V	C628 Δ	1-164-497-51	CERAMIC	470PF 20% 400V
C517	1-162-116-00	CERAMIC	680PF 10% 2KV	C634	1-165-127-11	CERAMIC	470PF 10% 500V
C518	1-162-116-00	CERAMIC	680PF 10% 2KV	C635	1-124-477-11	ELECT	47MF 20% 16V
C519 Δ	1-137-024-11	FILM	0.02MF 3% 2KV	C636	1-137-374-11	FILM	0.047MF 5% 50V
C520 Δ	1-162-134-91	CERAMIC	470PF 10% 2KV	C637	1-124-916-11	ELECT	22MF 20% 25V
C521 Δ	1-136-316-51	FILM	0.056MF 5% 630V	C640	1-124-902-00	ELECT	0.47MF 20% 50V
C522	1-106-383-00	MYLAR	0.047MF 99% 200V	C641	1-124-443-00	ELECT	100MF 20% 10V
C523	1-102-002-00	CERAMIC	680PF 10% 500V	C642	1-137-217-11	FILM	0.01MF 5% 1.25KV
				C643	1-137-218-11	FILM	0.012MF 5% 1.25KV
				C645	1-102-125-00	CERAMIC	0.0047MF 10% 50V
				C646	1-126-101-11	ELECT	100MF 20% 16V
				C647	1-124-916-11	ELECT	22MF 20% 25V
				C684	1-124-907-11	ELECT	10MF 20% 50V

KV-27TS29/27TS32/27TS36

RM-Y116 RM-Y117 RM-Y118

KV-32TS36/32TS46

RM-Y118 RM-Y118
SA-W200

D

Les composants identifiés par une
trame et une marque Δ sont
critiques pour la sécurité.
Ne les remplacer que par une pièce
portant le numéro spécifié.

The components identified by
shading and mark Δ are critical
for safety.
Replace only with part number
specified.

REF. NO.	PART NO.	DESCRIPTION	REMARK	REF. NO.	PART NO.	DESCRIPTION	REMARK
C695	1-124-907-11	ELECT	10MF 20% 50V	D622	8-719-911-19	DIODE 1SS119	
C2205	1-124-925-11	ELECT	2.2MF 20% 50V	D623	8-719-911-19	DIODE 1SS119	
C2208	1-124-925-11	ELECT	2.2MF 20% 50V	D624	8-719-911-19	DIODE 1SS119	
C2210	1-124-120-11	ELECT	220MF 20% 25V	D626	8-719-510-48	DIODE D1N20R	
C2211	1-124-477-11	ELECT	47MF 20% 25V	D627	8-719-510-48	DIODE D1N20R	
C2212	1-124-120-11	ELECT	220MF 20% 25V	D628	8-719-911-19	DIODE 1SS119	
C2213	1-136-173-00	FILM	0.47MF 5% 50V	D633	8-719-110-09	DIODE RD8.2ESB3	
C2215	1-136-169-00	FILM	0.22MF 5% 50V	D634	8-719-911-19	DIODE 1SS119	
C2216	1-124-480-11	ELECT	470MF 20% 25V	D635	8-719-911-19	DIODE 1SS119	
C2217	1-136-169-00	FILM	0.22MF 5% 50V	D636	8-719-510-48	DIODE D1N20R	
C2218	1-124-557-11	ELECT	1000MF 20% 25V	D637	8-719-911-19	DIODE 1SS119	
C2219	1-124-557-11	ELECT	1000MF 20% 25V	D638	8-719-911-19	DIODE 1SS119	
C2220	1-124-925-11	ELECT	2.2MF 20% 50V				
<CONNECTOR>				<FUSE>			
CN104	*1-573-979-11	CONNECTOR, BOARD TO BOARD 11P		F601	Δ 1-532-748-11	FUSE, GLASS TUBE (6.3A/125V)	
CN105	*1-508-768-00	PIN, CONNECTOR (5MM PITCH) 6P					
CN107	*1-580-798-11	CONNECTOR PIN (DY) 6P		<FERRITE BEAD>			
CN108	1-573-296-11	CONNECTOR, BOARD TO BOARD 10P (KV-32TS46/32TS36)		FB501	1-412-911-11	INDUCTOR, FERRITE BEAD	
CN109	1-573-296-11	CONNECTOR, BOARD TO BOARD 10P (KV-32TS46/32TS36)		FB502	1-412-911-11	INDUCTOR, FERRITE BEAD	
CN112	*1-508-786-00	PIN, CONNECTOR (5MM PITCH) 2P		FB601	1-412-911-11	INDUCTOR, FERRITE BEAD	
CN113	*1-508-765-00	PIN, CONNECTOR (5MM PITCH) 3P		FB602	1-412-911-11	INDUCTOR, FERRITE BEAD	
CN114	*1-580-843-11	PIN, CONNECTOR (POWER)		FB603	1-412-911-11	INDUCTOR, FERRITE BEAD	
CN115	1-573-298-11	CONNECTOR, BOARD TO BOARD 20P		FB604	1-412-911-11	INDUCTOR, FERRITE BEAD	
CN116	*1-691-616-11	CONNECTOR, BOARD TO BOARD 15P		FB605	1-412-911-11	INDUCTOR, FERRITE BEAD	
CN117	*1-573-978-11	CONNECTOR, BOARD TO BOARD 11P		FB606	1-412-911-11	INDUCTOR, FERRITE BEAD	
				FB613	1-412-911-11	INDUCTOR, FERRITE BEAD	
				FB614	1-412-911-11	INDUCTOR, FERRITE BEAD	
<DIODE>				<IC>			
D501	8-719-976-64	DIODE RGP02-17		IC501	8-759-980-58	IC TDA8172	
D502	8-719-979-85	DIODE EGP20G		IC504	8-759-103-93	IC UPC393C	
D503	8-719-979-85	DIODE EGP20G					
D504	Δ 8-719-302-44	DIODE EL1Z-V1		<POWER MODULE>			
D505	8-719-936-84	DIODE RGP10GPKG3		IC601	Δ 1-810-051-11	POWER MODULE DM-48	
D506	8-719-945-80	DIODE ERC06-15S					
D507	8-719-945-80	DIODE ERC06-15S		<IC>			
D508	8-719-900-26	DIODE ERD29-08J		IC602	8-759-805-37	IC L78LR05D-MA	
D509	8-719-936-84	DIODE RGP10GPKG3		IC604	8-759-924-12	IC LM7805CT	
D510	8-719-908-03	DIODE GP08D		IC605	8-759-701-79	IC LM7812CT	
D511	8-719-908-03	DIODE GP08D		IC606	8-759-982-10	IC RC7809FA	
D512	8-719-109-84	DIODE RD5.1ESB1		IC610	8-759-150-61	IC UPC78L05T	
D513	8-719-908-03	DIODE GP08D		IC2200	8-759-980-43	IC TDA2009A	
D514	8-719-911-19	DIODE 1SS119					
D515	8-719-911-19	DIODE 1SS119		<COIL>			
D601	8-719-911-19	DIODE 1SS119		L502	1-421-465-00	COIL, FERRITE CHOKE 68UH	
D602	Δ 8-719-510-63	DIODE D4SB60L-F		L503	1-412-524-11	INDUCTOR 8.2UH	
D603	8-719-500-69	DIODE S3V10SS		L504	1-410-669-31	INDUCTOR 33UH	
D605	8-719-500-69	DIODE S3V10SS		L505	1-459-104-00	COIL, WITH CORE	
D607	8-719-510-02	DIODE D1NS4		L506	1-422-613-11	COIL, AIR CORE	
D608	8-719-510-02	DIODE D1NS4		L508	1-412-553-11	INDUCTOR 3.3MMH	
D609	8-719-510-02	DIODE D1NS4		L509	Δ 1-460-173-21	COIL, HORIZONTAL LINEARITY (HLC)	
D610	8-719-510-02	DIODE D1NS4		L510	1-406-607-11	COIL, CHOKE 15MMH	
D611	8-719-510-02	DIODE D1NS4		L513	1-412-524-11	INDUCTOR 8.2UH	
D612	8-719-031-80	DIODE D5SC4MR					
D613	8-719-022-97	DIODE D2S4MF					
D614	8-719-110-33	DIODE RD12ESB3					
D615	8-719-027-43	DIODE S2L20UF					
D616	8-719-027-43	DIODE S2L20UF					
D617	8-719-027-43	DIODE S2L20UF					
D618	8-719-027-43	DIODE S2L20UF					
D619	8-719-510-02	DIODE D1NS4					

The components identified by shading and mark Δ are critical for safety. Replace only with part number specified.

Les composants identifiés par une trame et une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

The components identified by Δ in this manual have been carefully factory-selected for each set in order to satisfy regulations regarding X-ray radiation. Should replacement be required, replace only with the value originally used.

KV-27TS29/27TS32/27TS36

RM-Y116 RM-Y117 RM-Y118

KV-32TS36/32TS46

RM-Y116 RM-Y118 SA-W200

D

REF. NO.	PART NO.	DESCRIPTION	REMARK	REF. NO.	PART NO.	DESCRIPTION	REMARK
<PROTECTOR MODULE>				R547	1-247-883-00	CARBON 150K 5%	1/4W
PM501	1-810-061-11	PROTECTOR MODULE PM-39		R550	1-249-429-11	CARBON 10K 5%	1/4W
		(KV-27TS36/27TS32/27TS29)		R551	1-249-429-11	CARBON 10K 5%	1/4W
PM501	1-810-061-21	PROTECTOR MODULE PM-39		R554	1-216-371-00	METAL OXIDE 1.5 5%	2W F
		(KV-32TS46/32TS36)		R556	1-249-411-11	CARBON 330 5%	1/4W
				R557	1-249-415-11	CARBON 680 5%	1/4W F
<IC LINK>				R561	1-249-429-11	CARBON 10K 5%	1/4W
PS2201A1	1-532-675-91	LINK, IC		R562	1-215-437-00	METAL 4.7K 1%	1/4W
				R563	1-249-429-11	CARBON 10K 5%	1/4W
				R564	1-249-433-11	CARBON 22K 5%	1/4W
				R566	1-249-435-11	CARBON 33K 5%	1/4W
<TRANSISTOR>				R580	1-249-411-11	CARBON 330 5%	1/4W
Q502	8-729-119-80	TRANSISTOR 2SC2688-LK		R601 Δ	1-202-888-91	SOLID 2.2M 20%	1/2W
Q503	8-729-809-29	TRANSISTOR 2SC4159-E		R602 Δ	1-202-888-91	SOLID 2.2M 20%	1/2W
Q505	8-729-119-78	TRANSISTOR 2SC2785-HFE		R603	1-249-419-11	CARBON 1.5K 5%	1/4W
Q591	8-729-016-32	TRANSISTOR 2SC4927-01		R605	1-247-893-11	CARBON 390K 5%	1/4W
Q601	8-729-019-51	TRANSISTOR 2SC4834MNP		R606	1-247-893-11	CARBON 390K 5%	1/4W
Q602	8-729-019-51	TRANSISTOR 2SC4834MNP		R607 Δ	1-202-933-61	FUSIBLE 0.1 10%	1/2W F
Q603	8-729-119-76	TRANSISTOR 2SA1175-HFE		R608	1-215-860-11	METAL OXIDE 33 5%	1W F
Q604	8-729-119-78	TRANSISTOR 2SC2785-HFE		R609	1-216-352-11	METAL OXIDE 1.8 5%	1W F
Q605	8-729-119-78	TRANSISTOR 2SC2785-HFE		R610	1-216-352-11	METAL OXIDE 1.8 5%	1W F
Q611	8-729-119-78	TRANSISTOR 2SC2785-HFE		R611	1-216-468-91	METAL OXIDE 82K 5%	2W F
Q613	8-729-924-90	TRANSISTOR 2SB1370-EF		R612	1-216-468-91	METAL OXIDE 82K 5%	2W F
Q614	8-729-119-78	TRANSISTOR 2SC2785-HFE		R613	1-215-860-11	METAL OXIDE 33 5%	1W F
Q2202	8-729-119-78	TRANSISTOR 2SC2785-HFE		R614	1-215-860-11	METAL OXIDE 33 5%	1W F
Q2203	8-729-119-76	TRANSISTOR 2SA1175-HFE		R615	1-249-421-11	CARBON 2.2K 5%	1/4W
<RESISTOR>				R616	1-249-417-11	CARBON 1K 5%	1/4W
R501	1-249-378-11	CARBON 0.56 5%	1/4W F	R617	1-249-377-11	CARBON 0.47 5%	1/4W F
R503	1-215-862-11	METAL OXIDE 68 5%	1W F	R618	1-249-377-11	CARBON 0.47 5%	1/4W F
R504	1-215-872-11	METAL OXIDE 3.3K 5%	1W F	R619	1-249-377-11	CARBON 0.47 5%	1/4W F
R505	1-249-377-11	CARBON 0.47 5%	1/4W F	R621	1-249-377-11	CARBON 0.47 5%	1/4W F
R506	1-215-886-11	METAL OXIDE 100 5%	2W F	R622	1-249-377-11	CARBON 0.47 5%	1/4W F
R507	1-249-429-11	CARBON 10K 5%	1/4W	R623	1-249-377-11	CARBON 0.47 5%	1/4W F
R508	1-249-425-11	CARBON 4.7K 5%	1/4W	R624	1-249-377-11	CARBON 0.47 5%	1/4W F
R509	1-249-389-11	CARBON 4.7 5%	1/4W F	R625	1-249-377-11	CARBON 0.47 5%	1/4W F
Δ R511 Δ		CARBON	1/4W	R627	1-249-377-11	CARBON 0.47 5%	1/4W F
R512	1-249-389-11	CARBON 4.7 5%	1/4W F	R628	1-249-377-11	CARBON 0.47 5%	1/4W F
R513	1-216-393-00	METAL OXIDE 2.2 5%	3W F	R629	1-249-388-11	CARBON 3.9 5%	1/4W F
R514	1-249-429-11	CARBON 10K 5%	1/4W	R630	1-215-857-11	METAL OXIDE 10 5%	1W F
R515	1-216-363-00	METAL OXIDE 0.33 5%	2W F	R632	1-249-417-11	CARBON 1K 5%	1/4W F
R516	1-249-401-11	CARBON 47 5%	1/4W	R633	1-249-405-11	CARBON 100 5%	1/4W F
R517	1-215-916-00	METAL OXIDE 680 5%	3W F	R635	1-249-413-11	CARBON 470 5%	1/4W F
R518	1-215-916-00	METAL OXIDE 680 5%	3W F	R636	1-249-383-11	CARBON 1.5 5%	1/4W F
R519	1-249-426-11	CARBON 5.6K 5%	1/4W F	R637	1-249-421-11	CARBON 2.2K 5%	1/4W
R520	1-249-423-11	CARBON 3.3K 5%	1/4W	R638	1-249-423-11	CARBON 3.3K 5%	1/4W
R521	1-249-411-11	CARBON 330 5%	1/4W	R639	1-249-423-11	CARBON 3.3K 5%	1/4W
R522	1-215-886-11	METAL OXIDE 100 5%	2W F	R640 Δ	1-202-893-91	SOLID 8.2M 20%	1/2W
R523	1-215-862-11	METAL OXIDE 68 5%	1W F	R643	1-216-379-11	METAL OXIDE 6.8 5%	2W F
Δ R524 Δ		CARBON	1/4W	R644 Δ	1-212-853-61	FUSIBLE 6.8 5%	1/4W F
R526	1-247-887-00	CARBON 220K 5%	1/4W	R645	1-249-377-11	CARBON 0.47 5%	1/4W F
R527	1-215-861-00	METAL OXIDE 47 5%	1W F	R646	1-249-429-11	CARBON 10K 5%	1/4W
R528	1-260-326-71	CARBON 680 5%	1/2W	R647	1-249-433-11	CARBON 22K 5%	1/4W
R530	1-215-445-00	METAL 10K 1%	1/4W	R648	1-249-414-11	CARBON 560 5%	1/4W
R531	1-247-903-91	CARBON 1M 5%	1/4W	R649	1-216-431-11	METAL OXIDE 560 5%	1W F
R532	1-215-446-00	METAL 11K 1%	1/4W	R650	1-249-405-11	CARBON 100 5%	1/4W F
R534	1-249-385-11	CARBON 2.2 5%	1/4W F	R651 Δ	1-212-954-61	FUSIBLE 6.8 5%	1/2W F
R535	1-216-453-00	METAL OXIDE 270 5%	2W F	R652 Δ	1-212-954-61	FUSIBLE 6.8 5%	1/2W F
R536	1-249-389-11	CARBON 4.7 5%	1/4W F	R653	1-249-381-11	CARBON 1 5%	1/4W
R539	1-215-459-00	METAL 39K 1%	1/4W	R654	1-216-385-11	METAL OXIDE 0.47 5%	3W F
R543	1-249-419-11	CARBON 1.5K 5%	1/4W	R655	1-249-417-11	CARBON 1K 5%	1/4W F
R546	1-249-431-11	CARBON 15K 5%	1/4W	R656	1-249-381-11	CARBON 1 5%	1/4W
				R657	1-249-417-11	CARBON 1K 5%	1/4W
				R658	1-249-389-11	CARBON 4.7 5%	1/4W F

KV-27TS29/27TS32/27TS36

RM-Y116 RM-Y117 RM-Y118

KV-32TS36/32TS46

RM-Y118 RM-Y118
SA-W200

D H

Les composants identifiés par une
trame et une marque Δ sont
critiques pour la sécurité.
Ne les remplacer que par une pièce
portant le numéro spécifié.

The components identified by
shading and mark Δ are critical
for safety.
Replace only with part number
specified.

REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
R659	1-247-883-00	CARBON	150K 5% 1/4W	C1002	1-124-903-11	ELECT 1MF 20% 50V (KV-32TS46/32TS36/27TS36/27TS32)	
R660	1-249-435-11	CARBON	22K 5% 1/4W	C1003	1-124-903-11	ELECT 1MF 20% 50V (KV-32TS46/32TS36/27TS36/27TS32)	
R661	1-249-406-11	CARBON	120 5% 1/4W	C1004	1-124-122-11	ELECT 100MF 20% 50V	
R690	1-249-423-11	CARBON	3.3K 5% 1/4W				
R691	1-249-423-11	CARBON	3.3K 5% 1/4W				
R2209	1-249-427-11	CARBON	6.8K 5% 1/4W				
R2210	1-249-435-11	CARBON	33K 5% 1/4W				
R2211	1-249-427-11	CARBON	6.8K 5% 1/4W				
R2212	1-249-435-11	CARBON	33K 5% 1/4W				
R2215	1-249-425-11	CARBON	4.7K 5% 1/4W				
R2216	1-249-437-11	CARBON	47K 5% 1/4W				
R2217	1-249-435-11	CARBON	33K 5% 1/4W				
R2218	1-249-441-11	CARBON	100K 5% 1/4W				
R2219	1-249-413-11	CARBON	470 5% 1/4W				
R2220	1-249-430-11	CARBON	12K 5% 1/4W				
R2221	1-249-430-11	CARBON	12K 5% 1/4W				
R2222	1-249-398-11	CARBON	27 5% 1/4W				
R2223	1-249-418-11	CARBON	1.2K 5% 1/4W				
R2224	1-249-418-11	CARBON	1.2K 5% 1/4W				
R2225	1-249-398-11	CARBON	27 5% 1/4W				
R2226	1-249-385-11	CARBON	2.2 5% 1/4W F				
R2227	1-249-385-11	CARBON	2.2 5% 1/4W F				
R2228	1-249-421-11	CARBON	2.2K 5% 1/4W				
R2229	1-249-421-11	CARBON	2.2K 5% 1/4W				
		<RELAY>					
RY601A	1-515-684-22	RELAY					
RY602	1-515-516-00	RELAY					
		<SWITCH>					
S501	1-572-707-11	SWITCH, LEVER					
S502	1-572-707-11	SWITCH, LEVER					
		<TRANSFORMER>					
T501	1-453-146-11	TRANSFORMER ASSY, FLYBACK (NX-2604A3)					
T502	1-437-195-14	TRANSFORMER, HORIZONTAL DRIVE (HDT)					
T503	1-424-545-22	TRANSFORMER, FERRITE (PMT)					
T601	1-423-593-11	TRANSFORMER, LINE FILTER (LFT)					
T602	1-424-220-21	TRANSFORMER, LINE FILTER (LFT)					
T603	1-423-563-11	TRANSFORMER, CONVERTER DRIVE (CDT)					
T604	1-423-615-11	TRANSFORMER, CONVERTER (PIT)					
T605	1-423-582-11	TRANSFORMER, FERRITE (SBT)					
		<THERMISTOR>					
THP601A	1-809-539-11	THERMISTOR, POSITIVE					
		<VARISTOR>					
VDR601	1-807-288-11	VARISTOR					
VDR602	1-810-053-21	VARISTOR					
VDR603	1-810-053-21	VARISTOR					
		<CAPACITOR>					
C1001	1-124-916-11	ELECT 22MF 20% 25V (KV-32TS46/32TS36/27TS36/27TS32)					

KV-27TS29/27TS32/27TS36
RM-Y116 RM-Y117 RM-Y118KV-32TS36/32TS46
RM-Y116 RM-Y118
SA-W200

UA

REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
*A-1394-415-A	UA BOARD, COMPLETE	(KV-32TS36/27TS36)		CN143	1-750-395-11	SOCKET, CONNECTOR 32P	
*****				CN144	*1-564-521-11	PLUG, CONNECTOR 6P	(KV-32TS46)
*A-1394-435-A	UA BOARD, COMPLETE	(KV-32TS46)		CN146	1-573-300-11	CONNECTOR, BOARD TO BOARD 18P	(KV-32TS46/32TS36/27TS32)

*A-1394-437-A	UA BOARD, COMPLETE	(KV-27TS29)		CN147	1-750-395-11	SOCKET, CONNECTOR 32P	
*****				CN148	*1-564-517-11	PLUG, CONNECTOR 2P	
*A-1394-441-A	UA BOARD, COMPLETE	(KV-27TS32)		CN149	*1-564-519-11	PLUG, CONNECTOR 4P	(KV-32TS46)

<CAPACITOR>				<DIODE>			
C401	1-163-031-11	CERAMIC CHIP 0.01MF	50V	D401	8-719-110-17	DIODE RD10ESB2	
		(KV-32TS46/32TS36/27TS32)				(KV-32TS46/32TS36/27TS36/27TS32)	
C402	1-124-916-11	ELECT 22MF	20% 25V	D402	8-719-110-17	DIODE RD10ESB2	
C405	1-124-916-11	ELECT 22MF	20% 25V	D403	8-719-110-17	DIODE RD10ESB2	
		(KV-32TS46/32TS36/27TS32)		D404	8-719-110-17	DIODE RD10ESB2	
C406	1-124-903-11	ELECT 1MF	20% 50V	D405	8-719-110-17	DIODE RD10ESB2	
		(KV-32TS46/32TS36/27TS32)				(KV-32TS46/32TS36/27TS36/27TS32)	
C407	1-124-903-11	ELECT 1MF	20% 50V	D408	8-719-110-17	DIODE RD10ESB2	
		(KV-32TS46/32TS36/27TS32)				(KV-32TS46/32TS36/27TS36/27TS32)	
C408	1-124-916-11	ELECT 22MF	20% 25V	D410	8-719-110-17	DIODE RD10ESB2	
		(KV-32TS46/32TS36/27TS32)		D411	8-719-110-17	DIODE RD10ESB2	
C409	1-124-903-11	ELECT 1MF	20% 50V	D429	8-719-110-17	DIODE RD10ESB2	
C410	1-124-903-11	ELECT 1MF	20% 50V	D430	8-719-110-17	DIODE RD10ESB2	
C411	1-124-478-11	ELECT 100MF	20% 25V	D431	8-719-110-17	DIODE RD10ESB2	
		(KV-27TS32/27TS29)		D436	8-719-110-17	DIODE RD10ESB2	(KV-32TS46/32TS36/27TS36)
C412	1-124-916-11	ELECT 22MF	20% 25V	D437	8-719-110-17	DIODE RD10ESB2	(KV-32TS46/32TS36/27TS36)
C413	1-124-907-11	ELECT 10MF	20% 50V	<IC>			
C414	1-124-499-11	ELECT 1MF	20% 50V	IC401	8-759-634-69	IC M52470P	(KV-27TS32/27TS29)
C415	1-124-499-11	ELECT 1MF	20% 50V	IC402	8-752-062-86	IC CXA1545AS	(KV-32TS46/32TS36/27TS36)
C416	1-124-907-11	ELECT 10MF	20% 50V	IC403	8-759-088-00	IC MM1114XFF	(KV-27TS32)
C417	1-124-902-00	ELECT 0.47MF	20% 50V	IC404	8-759-164-18	IC MM1118XFF	(KV-27TS32)
C418	1-124-902-00	ELECT 0.47MF	20% 50V	<JACK>			
C419	1-124-477-11	ELECT 47MF	20% 16V	J401	1-750-515-11	TERMINAL BLOCK, S 3P	
C420	1-163-031-11	CERAMIC CHIP 0.01MF	50V			(KV-32TS46/32TS36/27TS36/27TS32)	
		(KV-32TS46/32TS36/27TS32)		J401	1-750-517-11	JACK BLOCK, PIN 3P	(KV-27TS29)
C421	1-124-916-11	ELECT 22MF	20% 25V	J402	1-750-517-11	JACK BLOCK, PIN 3P	(KV-32TS46/32TS36/27TS36/27TS32)
		(KV-32TS46/32TS36/27TS32)					
C430	1-124-499-11	ELECT 1MF	20% 50V	J403	1-750-516-11	JACK BLOCK, PIN 2P	(KV-27TS29)
		(KV-32TS46)		J404	1-750-516-11	JACK BLOCK, PIN 2P	
C431	1-124-499-11	ELECT 1MF	20% 50V	<JUMPER RESISTOR>			
		(KV-32TS46)		JR400	1-216-295-00	METAL GLAZE 0 5% 1/10W	(KV-27TS29)
C432	1-124-916-11	ELECT 22MF	20% 25V	JR401	1-216-295-00	METAL GLAZE 0 5% 1/10W	(KV-27TS29)
		(KV-32TS46)					
C433	1-124-482-11	ELECT 33MF	20% 25V	JR402	1-216-295-00	METAL GLAZE 0 5% 1/10W	
		(KV-32TS46/32TS36/27TS32)		JR403	1-216-295-00	METAL GLAZE 0 5% 1/10W	
C434	1-163-117-00	CERAMIC CHIP 100PF	5% 50V	JR408	1-216-295-00	METAL GLAZE 0 5% 1/10W	
		(KV-32TS46/32TS36/27TS32)		JR410	1-216-295-00	METAL GLAZE 0 5% 1/10W	
C440	1-124-907-11	ELECT 10MF	20% 50V	JR411	1-216-295-00	METAL GLAZE 0 5% 1/10W	
		(KV-32TS46/32TS36/27TS32)		JR412	1-216-295-00	METAL GLAZE 0 5% 1/10W	
C441	1-124-477-11	ELECT 47MF	20% 16V	JR414	1-216-295-00	METAL GLAZE 0 5% 1/10W	
C442	1-163-117-00	CERAMIC CHIP 100PF	5% 50V	JR415	1-216-295-00	METAL GLAZE 0 5% 1/10W	
		(KV-32TS46/32TS36/27TS32)				(KV-32TS46/32TS36/27TS36/27TS32)	
C462	1-126-101-11	ELECT 100MF	20% 16V	JR416	1-216-295-00	METAL GLAZE 0 5% 1/10W	
				JR418	1-216-295-00	METAL GLAZE 0 5% 1/10W	
<FILTER BLOCK>				<CONNECTOR>			
CM402	1-466-912-21	FILTER BLOCK, COMB		CN141	*1-564-520-11	PLUG, CONNECTOR 5P	(KV-32TS46/32TS36/27TS36/27TS32)

(SUPER WOOFER BOARD)

REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
*A-1331-264-A SUPER WOOFER BOARD, COMPLETE (KV-32TS46 only)				<IC>			
<CAPACITOR>				IC001	9-904-756-01	IC NJM2068S	
C001	1-102-114-00	CERAMIC	470PF 10% 50V	IC002	9-904-756-01	IC NJM2068S	
C002	1-102-114-00	CERAMIC	470PF 10% 50V	IC003	9-904-756-01	IC NJM2068S	
C003	1-124-903-11	ELECT	1MF 20% 50V	IC004	9-904-757-01	IC M5233L	
C004	1-124-903-11	ELECT	1MF 20% 50V	IC005	9-904-755-01	IC TA8225L(PA10-K)	
C005	1-130-494-11	FILM	0.082MF 5% 50V	<JACK>			
C006	1-130-490-11	FILM	0.039MF 5% 50V	J001	9-904-759-01	RCA JACK	
C007	1-130-494-11	FILM	0.082MF 5% 50V	<TRANSISTOR>			
C008	1-130-490-11	FILM	0.039MF 5% 50V	Q001	8-729-140-96	TRANSISTOR 2SD774-34	
C009	1-124-903-11	ELECT	1MF 20% 50V	Q002	8-729-119-78	TRANSISTOR 2SC2785-HFE	
C010	1-124-903-11	ELECT	1MF 20% 50V	Q003	8-729-119-76	TRANSISTOR 2SA1175-HFE	
C011	1-102-973-00	CERAMIC	100PF 10% 50V	Q004	8-729-119-76	TRANSISTOR 2SA1175-HFE	
C012	1-124-903-11	ELECT	1MF 20% 50V	<RESISTOR>			
C013	1-124-908-00	ELECT	0.47MF 20% 50V	R001	1-249-405-11	CARBON 100 5% 1/4W	
C014	1-124-907-11	ELECT	10MF 20% 50V	R002	1-249-405-11	CARBON 100 5% 1/4W	
C015	1-124-910-11	ELECT	47MF 20% 50V	R003	1-249-426-11	CARBON 56K 5% 1/4W	
C016	1-124-472-11	ELECT	470MF 20% 10V	R004	1-249-426-11	CARBON 56K 5% 1/4W	
C017	1-124-472-11	ELECT	470MF 20% 10V	R005	1-247-862-11	CARBON 20K 5% 1/4W	
C018	1-124-120-11	ELECT	220MF 20% 25V	R006	1-247-862-11	CARBON 20K 5% 1/4W	
C019	1-124-120-11	ELECT	220MF 20% 25V	R007	1-247-862-11	CARBON 20K 5% 1/4W	
C020	1-102-074-00	CERAMIC	0.001MF 10% 50V	R008	1-247-862-11	CARBON 20K 5% 1/4W	
C021	1-130-491-00	FILM	0.047MF 5% 50V	R009	1-247-862-11	CARBON 20K 5% 1/4W	
C022	1-130-491-00	FILM	0.047MF 5% 50V	R010	1-247-862-11	CARBON 20K 5% 1/4W	
C023	1-124-360-00	ELECT	1000MF 20% 16V	R011	1-249-431-11	CARBON 15K 5% 1/4W	
C024	1-124-360-00	ELECT	1000MF 20% 16V	R012	1-249-413-11	CARBON 470 5% 1/4W	
C025	1-124-636-91	ELECT	3300MF 20% 25V	R013	1-247-864-11	CARBON 24K 5% 1/4W	
C026	1-124-472-11	ELECT	470MF 20% 10V	R014	1-247-864-11	CARBON 24K 5% 1/4W	
C027	1-124-472-11	ELECT	470MF 20% 10V	R015	1-247-864-11	CARBON 24K 5% 1/4W	
C028	1-124-472-11	ELECT	470MF 20% 10V	R016	1-247-864-11	CARBON 24K 5% 1/4W	
C029	1-124-907-11	ELECT	10MF 20% 50V	R017	1-249-417-11	CARBON 1K 5% 1/4W	
C030	1-102-129-00	CERAMIC	0.01MF 10% 50V	R018	1-249-429-11	CARBON 10K 5% 1/4W	
<CONNECTOR>				R019	1-247-903-91	CARBON 1M 5% 1/4W	
CN001	9-904-761-01	PIN, TERMINAL		R020	1-249-426-11	CARBON 5.6K 5% 1/4W	
<DIODE>				R021	1-249-417-11	CARBON 1K 5% 1/4W	
D001	9-904-758-01	DIODE RBA-402LF-A		R022	1-249-429-11	CARBON 10K 5% 1/4W	
D002	9-904-765-01	DIODE ERA15-02VH-T		R023	1-249-429-11	CARBON 10K 5% 1/4W	
D003	9-904-766-01	DIODE RD9R1ES(B2)-T		R024	1-249-417-11	CARBON 1K 5% 1/4W	
D004	9-904-766-01	DIODE RD9R1ES(B2)-T		R025	1-247-839-11	CARBON 2.2K 5% 1/4W	
D005	8-719-802-30	DIODE 1SS176		R026	1-249-429-11	CARBON 10K 5% 1/4W	
D006	8-719-802-30	DIODE 1SS176		R027	1-249-417-11	CARBON 1K 5% 1/4W	
				R028	1-247-903-91	CARBON 1M 5% 1/4W	
				R029	1-249-433-11	CARBON 22K 5% 1/4W	
				R030	1-249-440-11	CARBON 82K 5% 1/4W	
				R031	1-249-433-11	CARBON 22K 5% 1/4W	
				R032	1-247-839-11	CARBON 2.2K 5% 1/4W	
				R033	1-249-433-11	CARBON 22K 5% 1/4W	

KV-27TS29 / 27TS32 / 27TS36
 RM-Y116 RM-Y117 RM-Y118

KV-32TS36 / 32TS46
 RM-Y118 RM-Y118
 SA-W200

SONY SERVICE MANUAL

US Model

KV-27TS29 Chassis No. SCC-F84C-A
 KV-27TS32 Chassis No. SCC-F84E-A
 KV-27TS36 Chassis No. SCC-F84D-A
 KV-32TS36 Chassis No. SCC-F84A-A
 KV-32TS46 Chassis No. SCC-F84B-A

Canadian Model

KV-27TS29 Chassis No. SCC-F85C-A
 KV-27TS36 Chassis No. SCC-F85D-A
 KV-32TS36 Chassis No. SCC-F85A-A
 KV-32TS46 Chassis No. SCC-F85B-A

CORRECTION-1

Correct the service manual as shown below.
 File this collection with the service manual.




 : Corrected portion

SECTION 3 SET-UP ADJUSTMENTS (See page 40)

Incorrect	Correct
3-4. G2 (SCREEN) AND WHITE BALANCE ADJUSTMENTS 1. G2 (SCREEN) ADJUSTMENT(RV702) 1. Set the PICTURE and BRIGHTNESS to normal. 2. Confirm G1 voltage is within $30.0 \pm 5V$. 3. Apply DC voltage of 180V to the cathodes of R, G and B from DC stabilized power source. 4. While watching the picture, adjust the G2 control (RV702) to the just the retrace line disappears.	3-4. G2 (SCREEN) AND WHITE BALANCE ADJUSTMENTS 1. G2 (SCREEN) ADJUSTMENT(RV702) 1. Set the PICTURE and BRIGHTNESS to normal. 2. Confirm G1 voltage is within $30.0 \pm 5V$. 3. Apply DC voltage of 170V to the cathodes of R, G and B from DC stabilized power source. 4. While watching the picture, adjust the G2 control (RV702) to the just the retrace line disappears.


SECTION 7 EXPLODED VIEWS

7-2. PICTURE TUBE (See page 102)





Incorrect	Correct
63  1-451-275-41 DEFLECTION YOKE (Y34FXA) (KV-27TS36/27TS32/27TS29)	63  1-451-275-41 DEFLECTION YOKE (Y28PFA)  (KV-27TS36/27TS32/27TS29)

SECTION 8 ELECTRICAL PARTS LIST

D BOARD (See page 113)

Incorrect	Correct
PM501 1-810-061-11 PROTECTOR MODULE PM-39 (KV-27TS36/27TS32/27TS29)	PM501 1-810-061-11 PROTECTOR MODULE PM-38  (KV-27TS36/27TS32/27TS29)

MISCELLANEOUS (See page 117)

Incorrect	Correct
 1-451-275-41 DEFLECTION YOKE (Y34FXA) (KV-27TS36/32TS32/27TS29)	 1-451-275-41 DEFLECTION YOKE (Y28PFA)  (KV-27TS36/27TS32/27TS29) 

KV-27TS29/27TS32/27TS36

RM-Y116

RM-Y117

RM-Y118

KV-32TS36/32TS46

RM-Y121

RM-Y116

SA-W200

SONY SERVICE MANUAL SUPPLEMENT-1

SUBJECT : PARTS CHANGE

Supplement the service manual as shown below.

File this supplement with the service manual.

US Model

KV-27TS29 Chassis No. SCC-F84C-A

KV-27TS32 Chassis No. SCC-F84E-A

KV-27TS36 Chassis No. SCC-F84D-A

KV-32TS36 Chassis No. SCC-F84A-A

KV-32TS46 Chassis No. SCC-F84B-A

Canadian Model

KV-27TS29 Chassis No. SCC-F85C-A

KV-27TS36 Chassis No. SCC-F85D-A

KV-32TS36 Chassis No. SCC-F85A-A

KV-32TS46 Chassis No. SCC-F85B-A


INTRODUCTION

PART CHANGE : KV-32TS36/32TS46 only

SECTION 6 DIAGRAM

6-3. PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS (See page 64)

C BOARD



SECTION 7 EXPLODED VIEW

7-2. PICTURE TUBE (See page 102)

REF. NO.	PART. NO.	DESCRIPTION
59	△8-733-734-05	PICTURE TUBE (A80JYV50X) (KV-32TS46/32TS36)
	△8-733-848-05	PICTURE TUBE (A68KZJ50X) (KV-27TS36/27TS32/27TS29)

SECTION 8 ELECTRICAL PARTS LIST

MISCELLANEOUS (See page 117)

REF. NO.	PART. NO.	DESCRIPTION
V901	△8-733-734-05	PICTURE TUBE (A80JYV50X) (KV-32TS36/32TS46)
	△8-733-848-05	PICTURE TUBE (A68KZJ50X) (KV-27TS36/27TS32/27TS29)



9-964-933-81

Sony Corporation
Consumer A&V Products Company
TV & Display Products Div.

English
94JE24-93-1
Printed in Japan
© 1984. 10

KV-27TS29/27TS32/27TS36

RM-Y116

RM-Y117

RM-Y118

KV-32TS36/32TS46

RM-Y118

RM-Y119

SA-W200

SONY SERVICE MANUAL

US Model

KV-27TS29 Chassis No. SCC-F84C-A
KV-27TS32 Chassis No. SCC-F84E-A
KV-27TS36 Chassis No. SCC-F84D-A
KV-32TS36 Chassis No. SCC-F84A-A
KV-32TS46 Chassis No. SCC-F84B-A

CORRECTION-2

SUBJECT : PART CHANGE

Correct the service manual as shown below.
File this collection with the service manual.

Canadian Model

KV-27TS29 Chassis No. SCC-F85C-A
KV-27TS36 Chassis No. SCC-F85D-A
KV-32TS36 Chassis No. SCC-F85A-A
KV-32TS46 Chassis No. SCC-F85B-A

 : Corrected portion

SECTION 8 ELECTRICAL PARTS LIST

D BOARD (See page 112)

Incorrect			Correct		
REF. NO.	PART. NO.	DESCRIPTION	REF. NO.	PART. NO.	DESCRIPTION
D612	8-719-031-80	DIODE D5SC4MR	D612	8-719-031-79	DIODE D5SC4M



9-964-933-92

Sony Corporation
TV Group

English
94AE0245-1
Printed in Japan
© 1994 1

KV-27TS29 / 27TS32 / 27TS36
RM-Y116 RM-Y117 RM-Y118

KV-32TS36 / 32TS46
RM-Y118 RM-Y119
SA-W200

SONY SERVICE MANUAL

US Model

KV-27TS29 Chassis No. SCC-F84C-A
KV-27TS32 Chassis No. SCC-F84E-A
KV-27TS36 Chassis No. SCC-F84D-A
KV-32TS36 Chassis No. SCC-F84A-A
KV-32TS46 Chassis No. SCC-F84B-A

Canadian Model

KV-27TS29 Chassis No. SCC-F85C-A
KV-27TS36 Chassis No. SCC-F85D-A
KV-32TS36 Chassis No. SCC-F85A-A
KV-32TS46 Chassis No. SCC-F85B-A

CORRECTION-3

SUBJECT : PART CHANGE

Correct the service manual as shown below.
File this collection with the service manual.

 : Corrected portion

SECTION 8 ELECTRICAL PARTS LIST D BOARD (See page 112)

Incorrect			Correct		
REF. NO.	PART. NO.	DESCRIPTION	REF. NO.	PART. NO.	DESCRIPTION
IC610	8-759-150-61	IC UPC78L05T	IC610	8-759-708-05	IC NJM78L05A



9-964-933-93

Sony Corporation
Consumer A&V Products Company
TV&Display Products Div

English
94CH02493-1
Printed in Japan
© 1994. 7

SONY[®] SERVICE MANUAL


AA-1 CHASSIS

MODEL	COMMANDER	DEST.	CHASSIS NO.	MODEL	COMMANDER	DEST.	CHASSIS NO.
KV-27TS29	RM-Y116	US	SCC-F84C-A	KV-32TS36	RM-Y118	US	SCC-F84A-A
KV-27TS29	RM-Y116	Canadian	SCC-F85C-A	KV-32TS36	RM-Y118	Canadian	SCC-F85A-A
KV-27TS32	RM-Y117	US	SCC-F84E-A	KV-32TS46	RM-Y118 SA-W200	US	SCC-F84B-A
KV-27TS36	RM-Y118	US	SCC-F84D-A	KV-32TS46	RM-Y118 SA-W200	Canadian	SCC-F85B-A
KV-27TS36	RM-Y118	Canadian	SCC-F85D-A				


CORRECTION-4

SUBJECT: ADJUSTMENT CHANGE

File this correction with the Service manual.

 : Corrected portion

SECTION 3 SET-UP ADJUSTMENT Preparations(See page 35)

INCORRECT	CORRECT
<p>(1) In order to reduce the influence of geomagnetism on the set's picture tube face it east or west.</p> <p>(2) Switch on the set's power and degauss with the degausser.</p>	<p>(1) In order to reduce the influence of geomagnetism on the set's picture tube face it east or west.</p> <p>Note: Please do not use the hand degausser, because the hand degausser effects a spot on a CRT and magnetizes CRT around. </p>



9-964-933-94

※ Please file according to model size.

27 34

Sony Corporation
Consumer A&V Products Company
TV & Display Products Div.

English
96BE05 366-1
Printed in JAPAN
© 1996.2

(SUPER WOOFER BOARD)

REF.NO.	PART NO.	DESCRIPTION	REMARK
R034	1-249-429-11	CARBON 10K 5%	1/4W
R035	1-249-429-11	CARBON 10K 5%	1/4W
R036	1-249-433-11	CARBON 22K 5%	1/4W
R037	1-249-417-11	CARBON 1K 5%	1/4W
R038	1-247-866-11	CARBON 30K 5%	1/4W
R039	1-249-405-11	CARBON 100 5%	1/4W
R040	1-247-842-11	CARBON 3K 5%	1/4W
R041	1-249-405-11	CARBON 100 5%	1/4W
R042	1-247-842-11	CARBON 3K 5%	1/4W
R043	9-904-764-01	METAL OXIDE 1 5%	1/2W
R044	9-904-764-01	METAL OXIDE 1 5%	1/2W
R046	9-904-762-01	METAL OXIDE 10 5%	1/4W
R047	9-904-763-01	METAL OXIDE 1.8K 5%	1/2W
R048	1-249-429-11	CARBON 10K 5%	1/4W
R049	1-249-429-11	CARBON 10K 5%	1/4W

<VARIABLE RESISTOR>

VR001 9-904-760-01 VOLUME

MISCELLANEOUS

△ 9-904-750-01 CORD, POWER
 △ 9-904-753-01 AC OUTLET
 F001 △ 9-904-752-01 FUSE
 SP901 9-900-278-01 SPEAKER
 T901 △ 9-904-751-01 TRANSFORMER, POWER